

# RENAULT

## 1 Engine and peripherals

**10A ENGINE AND CYLINDER BLOCK ASSEMBLY**

**11A TOP AND FRONT OF ENGINE**

**12A FUEL MIXTURE**

**12B TURBOCHARGING**

**13A FUEL SUPPLY**

**13B DIESEL INJECTION**

**13C PREHEATING**

**14A ANTIPOLLUTION**

**16A STARTING - CHARGING**

**17A IGNITION**

**17B PETROL INJECTION**

---

**X79**

---

**NOVEMBER 2009**

**EDITION ANGLAISE**

---

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which the vehicles are constructed".

All rights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

**19A COOLING**

**19B EXHAUST**

**19C TANK**

**19D ENGINE MOUNTING**

Dacia Duster Explorers UK

---

**X79**

---

**NOVEMBER 2009**

**EDITION ANGLAISE**

---

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which the vehicles are constructed".

All rights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

# DUSTER - Chapitre 1

## Contents

Pages

<b>10A ENGINE AND CYLINDER BLOCK ASSEMBLY</b>		<b>11A TOP AND FRONT OF ENGINE</b>	
Crankshaft seal on timing end: Removal - Refitting	10A-1	Pressure at end of compression: Check	11A-1
Crankshaft seal, gearbox end: Removal - Refitting	10A-5	Accessories belt: Removal - Refitting	11A-2
Lower cover: Removal - Refitting	10A-9	Crankshaft accessories pulley: Removal - Refitting	11A-10
Conrod bearing shell: Removal - Refitting	10A-24	Timing belt: Removal - Refitting	11A-17
Engine oil: Draining - Refilling	10A-32	Rocker cover: Removal - Refitting	11A-42
Oil filter: Removal - Refitting	10A-34	Camshaft: Removal - Refitting	11A-49
Oil-coolant heat exchanger: Removal - Refitting	10A-37	Camshaft seal, timing end: Removal - Refitting	11A-56
Oil pressure sensor: Removal - Refitting	10A-42	Oil decanter: Removal - Refitting	11A-68
Oil pump: Removal - Refitting	10A-44		
Oil pressure: Check	10A-46		
Multifunction support: Removal - Refitting	10A-48		
Engine - gearbox assembly: Removal - Refitting	10A-54		
Flywheel: Removal - Refitting	10A-75		
		<b>12A FUEL MIXTURE</b>	
		Air inlet: Description	12A-1
		Air resonator: Removal - Refitting	12A-2
		Air filter: Removal - Refitting	12A-3
		Air filter unit: Removal - Refitting	12A-6
		Air flowmeter: Removal - Refitting	12A-10

---

# Contents

<b>12A</b>	<b>FUEL MIXTURE</b>		<b>13B</b>	<b>DIESEL INJECTION</b>	
	Throttle valve: Removal - Refitting	12A-11		Crankshaft position sensor: Removal - Refitting	13B-8
	Inlet distributor: Removal - Refitting	12A-12		High pressure pump: Removal - Refitting	13B-9
	Injector holder shim: Removal - Refitting	12A-14		Flow actuator: Removal - Refitting	13B-14
	Exhaust manifold: Removal - Refitting	12A-16		Venturi: Removal - Refitting	13B-16
				High pressure pipe: Check	13B-18
				High pressure pipe between pump and rail: Removal - Refitting	13B-19
<b>12B</b>	<b>TURBOCHARGING</b>			High pressure pipe between rail and injector: Removal - Refitting	13B-22
	Turbocharger: Removal - Refitting	12B-1		Injector rail: Removal - Refitting	13B-25
	Turbocharger oil pipe: Removal - Refitting	12B-4		Fuel temperature sensor: Removal - Refitting	13B-28
	Intercooler: Removal - Refitting	12B-8		Injector leak flow: Check	13B-30
				Diesel injector: Removal - Refitting	13B-32
<b>13A</b>	<b>FUEL SUPPLY</b>			Accelerometer: Removal - Refitting	13B-37
	Fuel circuit: Operating diagram	13A-1			
	Manual priming pump: Removal - Refitting	13A-3	<b>13C</b>	<b>PREHEATING</b>	
	Diesel filter: Removal - Refitting	13A-5		Pre-postheating unit: Removal - Refitting	13C-1
	Fuel pressure: Check	13A-9		Heater plugs: Removal - Refitting	13C-2
	Fuel flow: Check	13A-11			
<b>13B</b>	<b>DIESEL INJECTION</b>		<b>14A</b>	<b>ANTIPOLLUTION</b>	
	Diesel injection: List and location of components	13B-1		Exhaust gas recirculation: List and location of components	14A-1
	Diesel injection computer: Removal - Refitting	13B-5		Fuel vapour absorber: Removal - Refitting	14A-2
	Camshaft position sensor: Removal - Refitting	13B-7			

---

# Contents

<b>14A</b>	<b>ANTI POLLUTION</b>		<b>19A</b>	<b>COOLING</b>	
	Exhaust gas recirculation solenoid valve: Removal - Refitting	14A-4		Engine cooling system: Operating diagram	19A-1
	Exhaust gas cooler: Removal - Refitting	14A-7		Engine cooling system: Specifications	19A-2
	Exhaust gas recirculation assembly: Removal - Refitting	14A-9		Engine cooling system: Check	19A-3
	Exhaust gas recirculation rigid pipe: Removal - Refitting	14A-12		Engine cooling circuit: List and location of components	19A-5
				Cooling system: Draining - Refilling	19A-6
				Cooling radiator: Removal - Refitting	19A-9
<b>16A</b>	<b>STARTING - CHARGING</b>			Coolant pump: Removal - Refitting	19A-13
	Alternator: Removal - Refitting	16A-1		Thermostat: Removal - Refitting	19A-19
	Starter: Removal - Refitting	16A-8		Water chamber: Removal - Refitting	19A-22
	Alternator pulley: Removal - Refitting	16A-12		Engine cooling fan assembly: Removal - Refitting	19A-27
				Coolant pump inlet pipe: Removal - Refitting	19A-34
<b>17A</b>	<b>IGNITION</b>			Expansion bottle: Removal - Refitting	19A-38
	Coils: Removal - Refitting	17A-1		Coolant temperature sensor: Removal - Refitting	19A-40
<b>17B</b>	<b>PETROL INJECTION</b>		<b>19B</b>	<b>EXHAUST</b>	
	Petrol injection: List and location of components	17B-1		Exhaust: List and location of components	19B-1
	Oxygen sensors: Removal - Refitting	17B-4		Exhaust: Precautions for the repair	19B-6
	Throttle valve potentiometer: Removal - Refitting	17B-6		Catalytic converter: Removal - Refitting	19B-10
	Petrol injection computer: Removal - Refitting	17B-7		Expansion chamber: Removal - Refitting	19B-17
	Crankshaft position sensor: Removal - Refitting	17B-9			
	Injector rail - Injectors: Removal - Refitting	17B-10			

---

# Contents

## 19B EXHAUST

Intermediate pipe: Removal - Refitting	19B-18
Silencer: Removal - Refitting	19B-20

## 19C TANK

Fuel tank: Draining	19C-1
Fuel tank: Removal - Refitting	19C-3
Fuel level sensor module: Removal - Refitting	19C-8

## 19D ENGINE MOUNTING

Suspended engine mounting: Tightening torque	19D-1
Left-hand suspended engine mounting: Removal - Refitting	19D-2
Right-hand suspended engine mounting: Removal - Refitting	19D-4
Lower engine tie-bar: Removal - Refitting	19D-8

Facia Duster Explorers UK


K9K

### REMOVAL


#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the timing belt sprocket (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) .


#### II - REMOVAL OPERATION



- Fit the end piece (2) onto the tool (3) .




- Position the jaws of the tool onto the crankshaft nose (4) .




- Push on the tool until contact is made between the ends (5) of the jaws and the crankshaft seal.

K9K



- Separate the jaws by screwing the nut of the tool (6).



- Screw down the threaded rod (7) of the.
- Refit the crankshaft seal at the timing end using the tool.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Crankshaft seal on timing end.


#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:

- the crankshaft seal mating face,
- the crankshaft seal housing in the crankshaft closure panel.

### II - REFITTING OPERATION



- 

#### Note:

This type of seal is extremely fragile.


Only touch the protective part (8) when handling the gasket. It is strictly forbidden to touch the seal (9); this is to prevent any oil leaks once the oil seal is fitted to the engine.

# ENGINE AND CYLINDER BLOCK ASSEMBLY


## Crankshaft seal on timing end: Removal - Refitting

# 10A


K9K




- Screw the threaded rod (10) of the into the crankshaft.



- Fit the protector with the new seal in place on the spacer, taking care not to touch the seal.




- On the crankshaft, fit the spacer (11) of the.




- Fit the cover (12) and nut (13) (with the thread (14) of the nut towards the outside of the engine) of the.

K9K



20768




20766

- ❑ Remove the nut, the cup, the protector and the threaded rod.

### III - FINAL OPERATION

- ❑ Refit:
  - the timing belt sprocket (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the timing belt (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- ❑ Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).



20767

- ❑ Screw on the nut until the cover touches the spacer.

K4M or K9K


### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the gearbox (see **Manual gearbox: Removal - Refitting**) (21A, Manual gearbox),
  - the clutch (see **Pressure plate - Disc: Removal - Refitting**) (20A, Clutch),
  - the flywheel (see **10A, Engine and cylinder block assembly, Flywheel: Removal - Refitting**, page **10A-75**) (20A, Clutch).

#### II - REMOVAL OPERATION

K4M




- Remove the crankshaft seal (1) at the gearbox end using a screwdriver.


Note:

Take care not to damage the crankshaft mating face.

K9K




- Fit the extractor to the shaft, adjusting the fingers (2) to the diameter of the shaft using the knurled plate (3).



- Screw knurled plate (5) until it is locked to knurled plate (4) to keep the fingers in position on the shaft.
- Screw the extractor into the seal using the hexagonal nut (6).

K4M or K9K



22760

- ❑ Extract the crankshaft seal at the gearbox end by screwing the threaded rod (7) .

## REFITTING

### I - REFITTING PREPARATION OPERATION

- ❑ **parts always to be replaced: Crankshaft seal on gearbox end.**


#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- ❑ Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the crankshaft seal mating face,
  - the crankshaft seal housing on the cylinder block.

### II - REFITTING OPERATION

K9K



18687

18687

- ❑

#### Note:

This type of seal is extremely fragile.


Only touch the protective part (8) when handling the gasket. It is strictly forbidden to touch the seal (9) ; this is to prevent any oil leaks once the oil seal is fitted to the engine.

# ENGINE AND CYLINDER BLOCK ASSEMBLY


## Crankshaft seal, gearbox end: Removal - Refitting

# 10A


K4M or K9K




- Mount theon the crankshaft, securing it using bolts (10) .



- Fit the cover (11) and nut (12) (with the thread (13) of the nut towards the outside of the engine) of the.




- Fit the protector with its seal in place on the, taking care not to touch the seal.




- Tighten the nut until the cover touches the cylinder block.

K4M or K9K




20764



20765

- ❑ Remove the nut, the cover, the protector and the base plate.

K4M



134544

- ❑ Refit the crankshaft seal at the gearbox end, using the tool (14).

### III - FINAL OPERATION

- ❑ Refit:
  - the flywheel (see **10A, Engine and cylinder block assembly, Flywheel: Removal - Refitting**, page **10A-75**) (20A, Clutch),
  - the clutch (see **Pressure plate - Disc: Removal - Refitting**) (20A, Clutch),
  - the gearbox (see **Manual gearbox: Removal - Refitting**) (21A, Manual gearbox).
- ❑ Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- ❑ Perform the following operations:
  - fill the manual gearbox (see **Manual gearbox oils: Draining - Filling**) (21A, Manual gearbox),
  - bleed the clutch control circuit (see **Clutch circuit: Bleed**) (37A, Mechanical component controls).

## Lower cover: Removal - Refitting

K9K

### Special tooling required

**Tav. 1747** Threaded rods for carrying out subframe operations.

### Tightening torques


oil pump bolts	<b>25 N.m</b>
sump bolts on the cylinder block	<b>14 N.m</b>
sump bolts on the gear-box	<b>44 N.m</b>
sump bolts on the multi-function support	<b>25 N.m</b>
power assisted steering pump support bolt on the sump	<b>25 N.m</b>
bracket bolts	<b>62 N.m</b>
relay bearing bolts	<b>44 N.m</b>
right-hand driveshaft flange bolt(s) on the relay bearing	<b>21 N.m</b>
front axle subframe tie-rod upper bolts	<b>21 N.m</b>
power-assisted steering low pressure pipe bolt on the front axle subframe	<b>25 N.m</b>

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55, Exterior protection).
- Remove:
  - the engine undertray bolts,
  - the engine undertray.
- Drain the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**).

- Remove:
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front wheel arch side liners,
  - the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page **19D-8**).
- Extract the lower arm ball joints from the stub axle carrier (see **Front driveshaft lower arm: Removal - Refitting**) (31A, Front axle components).
- Remove (see **Steering box: Removal - Refitting**) (36A, Steering assembly):
  - the heat shield bolts on the steering box,
  - the steering box heat shield,
  - the steering box bolts on the front axle subframe.
- Attach the steering rack to the body.




106546


- Remove:
  - the catalytic converter upstream strut bolts (1),
  - the catalytic converter upstream strut.

## Lower cover: Removal - Refitting


K9K




- Remove the power-assisted steering low pressure pipe bolt (2) on the front axle subframe.



- Remove the cooling pipe support bolt (3) on the sump.




- Remove the front axle subframe tie-rod upper bolts (5).



- Remove:
  - the right-hand driveshaft flange bolt (9) on the relay bearing,
  - the bolts (10) from the relay bearing,
  - the relay bearing.

## Lower cover: Removal - Refitting

K9K




144755

 Remove:

- the bracket bolts (12) ,
- one by one, the front axle subframe bolts (11) and replace them in turn with the threaded rods of the (Tav. 1747).


## Note:

Make sure the threaded rod of the (Tav. 1747) is sufficiently screwed into the threaded hole and that the nut of the tool is correctly resting on the front axle subframe.



108645

108645



108644

108644


- 
- Lower the front axle subframe 120 mm, gradually loosening the nuts of the (Tav. 1747).

## Lower cover: Removal - Refitting

K9K

## II - REMOVAL OPERATION


## STANDARD HEATING RECIRCULATION



- Remove the power-assisted steering pump support bolt (13) on the sump.

## AIR CONDITIONING

- Remove the bolt from the sump on the multifunction support.



107936

- Remove:
  - the engine-gearbox coupling bolts (14) ,
  - the sump bolts,
  - the sump.

## Note:

If the sump cannot be extracted because it is in contact with the oil pump strainer, do not force the removal of the sump as this may damage the oil splash plate.

Loosen the oil pump bolts by a few turns (the tip of your finger should pass between the bolt head and the oil pump casing) using 10 mm and 13 mm open-jawed spanners and while tilting the sump towards the front of the vehicle.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- parts always to be replaced: engine oil sump seal.
- parts always to be replaced: Front sub-frame bolt.

## WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

## Lower cover: Removal - Refitting

K9K

- Clean the cylinder block joint face using **SUPER CLEANING AGENT FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

**WARNING**


To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease:


- the sump joint face if it is to be reused,
- the cylinder block gasket face.

**WARNING**

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).



20166



20167


- Apply:

- four beads (15) of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) with a diameter of **5 mm**,
- two drops (16) of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) with a diameter of **5 mm** at the intersection between the cylinder block and the crankshaft closure panel.

## Lower cover: Removal - Refitting

K9K

## II - REFITTING OPERATION



□

## Note:


When refitting the sump, ensure that:

- the oil splash plate tabs (17) are positioned correctly in the slots (18) ,
- the coupling faces of the sump and cylinder block are correctly aligned, to prevent the clutch housing being deformed when fitting the gear-box.


Refit the oil splash plate.

## Lower cover: Removal - Refitting

K9K



107936



20171

- Refit the oil sump fitted with a new seal.

**Note:**

If the oil pump was loosened beforehand in order to extract the sump, position the sump in order to slide the oil pump strainer into the oil splash plate of the sump.

Position a component jack to support the sump.

Lean the sump towards the front of the vehicle in order to access the oil pump bolts.

Torque tighten the **oil pump bolts (25 N.m)** using the small torque wrench **77 11 226 888**.

**Note:**

Before pressing the sump on the cylinder block, check that the sump seal is still in place and that it has not come out of the grooves on the sides.

- Tighten until contact:
  - the sump bolts on the cylinder block,
  - the sump bolts on the gearbox.
- Torque tighten:
  - in order the **sump bolts on the cylinder block (14 N.m)**,
  - the **sump bolts on the gearbox (44 N.m)**.

### AIR CONDITIONING

- Refit the sump bolt on the multifunction support.
- Torque tighten the **sump bolts on the multifunction support (25 N.m)**.

### STANDARD HEATING RECIRCULATION

- Refit the power-assisted steering pump support on the sump.
- Torque tighten the **power assisted steering pump support bolt on the sump (25 N.m)**.

### III - FINAL OPERATION

- Fit the front axle subframe.
- Refit the brackets.
- Torque tighten the **bracket bolts (62 N.m)**.

## Lower cover: Removal - Refitting

K9K

- One by one, remove the threaded rods of the (**Tav. 1747**) and replace them in turn with new front axle subframe bolts.
- Refit:
  - the relay bearing bolts,
  - the right-hand driveshaft flange bolt(s) on the relay bearing.
- Tighten to torque and in order:
  - the **relay bearing bolts (44 N.m)**,
  - the **right-hand driveshaft flange bolt(s) on the relay bearing (21 N.m)**.
- Refit the front axle subframe tie-rod upper bolts.
- Torque tighten the **front axle subframe tie-rod upper bolts (21 N.m)**.
- Refit the cooling pipe support bolt on the sump.
- Refit the power-assisted steering low pressure pipe bolt on the front axle subframe.
- Torque tighten the **power-assisted steering low pressure pipe bolt on the front axle subframe (25 N.m)**.
- Refit the catalytic converter upstream stay (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page **19B-10**).
- Refit the steering box bolts on the front axle subframe (see **Steering box: Removal - Refitting**) (36A, Steering assembly).
- Refit:
  - the steering box heat shield,
  - the lower arm ball joints (see **Front driveshaft lower arm: Removal - Refitting**) (31A, Front axle components),
  - the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page **19D-8**).
- Refit the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55, Exterior protection).
- Refit:
  - the engine undertray,
  - the front wheel arch side liners,
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**).

## Lower cover: Removal - Refitting

K4M

### Special tooling required

**Tav. 1747** Threaded rods for carrying out subframe operations.

### Tightening torques


sump bolts on the cylinder block	<b>14 N.m</b>
sump bolts on the gear-box	<b>44 N.m</b>
sump bolt on the multi-function support	<b>25 N.m</b>
bracket bolts	<b>62 N.m</b>
front axle subframe bolts	<b>110 N.m</b>
relay bearing bolts	<b>44 N.m</b>
right-hand driveshaft flange bolt(s) on the relay bearing	<b>21 N.m</b>
front axle subframe tie-rod upper bolts	<b>21 N.m</b>
power-assisted steering low pressure pipe bolt on the front axle subframe	<b>21 N.m</b>
steering box bolts on the front axle subframe	<b>105 N.m</b>

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Remove:
  - the engine undertray bolts,
  - the engine undertray.
- Drain the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**).

- Remove:
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front wheel arch side liners,
  - the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page **19D-8**).
- Extract the lower arm ball joints from the stub axle carrier (see **Front driveshaft lower arm: Removal - Refitting**) (31A, Front axle components).
- Unclip the downstream oxygen sensor wiring on the heat shield on the steering box.
- Remove (see **Steering box: Removal - Refitting**) (36A, Steering assembly):
  - the heat shield bolts on the steering box,
  - the steering box heat shield,
  - the steering box bolts on the front axle subframe.
- Attach the steering rack to the body.




24762

- Remove the power-assisted steering low pressure pipe bolt (1) on the front axle subframe.


## Lower cover: Removal - Refitting

K4M




145789

- ❑ Remove the cooling pipe support bolt (2) on the sump.



135708

- ❑ Remove:
  - the right-hand driveshaft flange bolt (5) on the relay bearing,
  - the bolts (6) from the relay bearing,
  - the relay bearing.




144756

- ❑ Remove the front axle subframe tie-rod upper bolts (4).

## Lower cover: Removal - Refitting

K4M




144755

 Remove:

- the bracket bolts (11) ,
- one by one, the front axle subframe bolts (10) and replace them in turn with the threaded rods of the (Tav. 1747).


## Note:

Make sure the threaded rod of the (Tav. 1747) is sufficiently screwed into the threaded hole and that the nut of the tool is correctly resting on the front axle subframe.



108645

108645



108644


108644

- 
- Lower the front axle subframe by at least
- 120 mm**
- , gradually loosening the nuts of the (Tav. 1747).

## Lower cover: Removal - Refitting

K4M

## II - REMOVAL OPERATION



107936

 Remove:

- the sump bolt from the multifunction support,
- the engine-gearbox coupling bolts (12) ,
- the sump bolts on the cylinder block,
- the sump,
- the oil splash plate.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- parts always to be replaced: engine oil sump seal.
- parts always to be replaced: Front sub-frame bolt.

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Clean the cylinder block joint face using **SUPER CLEANING AGENT FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).


- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease:

- the sump joint face if it is to be reused,
- the cylinder block gasket face.


**WARNING**

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).

K4M



20166




20167

□ Apply:

- four beads (13) of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) with a diameter of **5 mm**,
- two drops (14) of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) with a diameter of **5 mm** at the intersection between the cylinder block and the crankshaft closure panel.

## II - REFITTING OPERATION



20170



## Note:


When removing the sump, ensure that:

- the oil splash plate tabs (15) are positioned correctly in the slots (16) ,
- the coupling faces of the sump and cylinder block are correctly aligned, to prevent the clutch housing being deformed when fitting the gear-box.


Refit the oil splash plate.

## Lower cover: Removal - Refitting

K4M



107936



20171

- Refit the oil sump fitted with a new seal.
- Tighten until contact:
  - the sump bolts on the cylinder block,
  - the bolts from the sump on the gearbox,
  - the sump bolts from the multifunction support.
- Torque tighten:
  - in order the **sump bolts on the cylinder block (14 N.m)**,
  - the **sump bolts on the gearbox (44 N.m)**,

- the **sump bolt on the multifunction support (25 N.m)**.

### III - FINAL OPERATION

- Fit the front axle subframe.
- Refit the brackets.
- Torque tighten the **bracket bolts (62 N.m)**.
- One by one, remove the threaded rods of the (**Tav. 1747**) and replace them in turn with new front axle subframe bolts.

K4M

- Torque tighten the **front axle subframe bolts (110 N.m)**.
- Refit:
  - the relay bearing bolts,
  - the right-hand driveshaft flange bolt(s) on the relay bearing.
- Tighten to torque and in order:
  - the **relay bearing bolts (44 N.m)**,
  - the **right-hand driveshaft flange bolt(s) on the relay bearing (21 N.m)**.
- Refit the front axle subframe tie-rod upper bolts.
- Torque tighten the **front axle subframe tie-rod upper bolts (21 N.m)**.
- Refit the cooling pipe support bolt on the sump.
- Refit the power-assisted steering low pressure pipe bolt on the front axle subframe.
- Torque tighten the **power-assisted steering low pressure pipe bolt on the front axle subframe (21 N.m)**.
- Refit the steering box bolts on the front axle subframe.
- Tighten to torque the **steering box bolts on the front axle subframe (105 N.m)**.
- Refit:
  - the steering box heat shield,
  - the lower arm ball joints (see **Front driveshaft lower arm: Removal - Refitting**) (31A, Front axle components),
  - the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page 19D-8) .

## Lower cover: Removal - Refitting

K4M

- Refit the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Refit:
  - the engine undertray,
  - the front wheel arch side liners,
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**).

Dacia Duster Explorers UK

K9K

### Equipment required

safety strap(s)

component jack

indelible pencil

torque wrench

Diagnostic tool

### Tightening torques

con rod cap bolts	20 N.m + 45° ± 6°
-------------------	-------------------

oil pump bolts	25 N.m
----------------	--------

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Vehicle: Precautions for the repair**).

### IMPORTANT


Wear leaktight gloves (Nitrile type) for this operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the engine undertray.
- Drain the oil from the engine (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32).
- Remove the oil filter (see **10A, Engine and cylinder block assembly, Oil filter: Removal - Refitting**, page 10A-34).
- Remove the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page 19D-8).

- Strap the radiator to the vehicle using **safety strap(s)**.
- Remove the front axle subframe (see **Front axle subframe: Removal - Refitting**) (31A, Front axle components).



123834


- Remove the relay bearing of the front right-hand wheel driveshaft.



123834


- Disconnect the oil level sensor connector (if equipped) (2).

K9K



112328

- ❑ Remove the catalytic converter upstream stay (3) .



140940


❑

### WARNING

Failure to observe the following procedure may damage the oil pump strainer.

Undo the bolts of the engine oil sump.

- ❑ Fit a **component jack** to support the engine oil sump.
- ❑ Remove the bolts from the engine oil sump.
- ❑ Detach the engine oil sump, while supporting it with the **component jack**.




140917

- ❑ Tilt the engine oil sump forwards in order to access the oil pump bolts.
- ❑ Partially loosen the oil pump bolts **3 mm to 5 mm**.
- ❑ Detach the oil pump from its position in order to remove the engine oil sump.
- ❑ Remove:
  - the engine oil sump,
  - the engine oil sump seal,
  - the oil pump.


K9K

## II - REMOVAL OPERATION FOR THE CON ROD BEARING SHELLS NO.2



139306

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean the big ends.
- Mark the position of the con rod cap in relation to the con rod body using a **indelible pencil**.
- Position the crankshaft at Top Dead Centre.



139300


- Remove:
  - the con rod bolts,
  - the con rod cap,
  - the lower con rod bearing shell.

**Note:**

If reusing the con rod bearing shells, mark the position of the lower con rod bearing shell in relation to the con rod cap.


- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - products) to clean the bearing mating face on the con rod cap.

K9K



139310

- Fit the tie rod of the tool on the con rod body.
- Push the con rod upwards to release the con rod from the crankpin.
- Turn the crankshaft **90°** clockwise (timing end).



139315

**WARNING**

Failure to observe the following procedure may damage the piston base cooling jets.

Pull the con rod - piston assembly using the tie rod of the tool, taking care not to allow the piston to touch the piston base cooling jets.

- Remove the upper con rod bearing shell.

**Note:**

If reusing the con rod bearing shells, mark the position of the upper con rod bearing shell in relation to the con rod body.

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - products) to clean the bearing mating face on the con rod body.

**REFITTING****I - REFITTING OPERATION FOR THE CON ROD BEARING SHELLS ON CYLINDER NO.2**

- parts always to be replaced: con rod cap bolts**

K9K

□


## Note:

Always replace con rod bearing shells with a width of **20 mm** by con rod bearing shells with a width of **18 mm**.


If the set of con rod bearing shells only includes con rod bearing shells which are **18mm** wide, only use the head of the tool with the marking "**K9K SUP**".

Fit the head of the tool with the marking "**K9K INF**" on the threaded sleeve of the tool.

- Position the lower con rod bearing shell on the tool.



133814



133815

133815

□


## Note:

The contact surface between the bearing shell and the con rod must be dry and free of grease.

Fit the lower con rod bearing shell on the con rod cap using the tool.

- Position the lower con rod bearing shell so that the ends do not protrude beyond the con rod cap.
- Lubricate the surface of the con rod bearing shell (crankshaft end) using new engine oil.

K9K



139318

- Remove the tool head with the marking "K9K INF" and fit the head with the marking "K9K SUP".
- Position the upper con rod bearing shell on the tool.
- Fit the upper con rod bearing shell on the con rod body using the tool.
- Position the upper con rod bearing shell so that the ends do not protrude beyond the con rod body.
- Lubricate the surface of the con rod bearing shell (crankshaft end) using new engine oil.
- Push the con rod - piston assembly back up into place.
- Turn the crankshaft **90°** anticlockwise.
- Lubricate the crankpin with new engine oil.
- Pull the con rod - piston assembly to position the con rod on the crankshaft.
- 

**Note:**

Before refitting the con rod cap, ensure that there are no impurities (filings, cloth lint, etc.) on the con rod body or cap surfaces.

**Refit:**

- the con rod cap according to the mark made during removal,
- the new con rod bolts.

- Torque and angle tighten the **con rod cap bolts (20 N.m + 45° ± 6°)**.

**II - REMOVAL - REFITTING OPERATIONS FOR THE CON ROD BEARING SHELLS ON CYLINDERS NO.3, 1 AND 4**

- Perform the same removal - refitting operations as for the con rod bearing shells on cylinder no. 2.

**Note:**

For removing and refitting the con rod bearing shells on cylinders no. 1 and no. 4, position the pistons at Bottom Dead Centre before performing the same removal and refitting operations as for the con rod bearing shells on cylinder no. 2.

**III - FINAL OPERATION**

- parts always to be replaced: engine oil sump seal**

**parts always to be replaced: Oil filter**

**parts always to be replaced: Drain plug seal on engine oil sump**

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

**WARNING**


To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use a wooden spatula or an **ABRASIVE PAD** to clean the joint face of the cylinder block and engine oil sump.
- Refit the oil pump.
- Fit without tightening the oil pump bolts, while keeping a clearance of **3 mm to 5 mm**.
- Fit the engine oil sump seal.


**WARNING**

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).

K9K




20166



20167

- Apply **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) :
  - four beads with a diameter of **5 mm** at (A) ,
  - two drops with a diameter of **5 mm** at (B) .
- Fit the engine oil sump while supporting it using a **component jack**.



140918


- Tilt the engine oil sump forwards in order to access the oil pump bolts.
- Torque tighten the **oil pump bolts (25 N.m)** using the **torque wrench PROSTEEL**, part number **77 11 226 888** starting with the **13 mm** bolt.

**Note:**

Check that the engine oil sump seal is definitely in place before tightening the engine oil sump bolts.

- Refit the engine oil sump bolts.
- Torque tighten in order the engine oil sump bolts (see **10A, Engine and cylinder block assembly, Lower cover: Removal - Refitting**, page 10A-9) .
- Refit the catalytic converter upstream stay (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) .
- Connect the connector to the oil level sensor.
- Refit the relay bearing of the front right-hand wheel driveshaft (see **Front right-hand driveshaft: Removal - Refitting**) .
- Refit the front axle subframe (see **Front axle subframe: Removal - Refitting**) (31A, Front axle components).
- Remove the **safety strap(s)** from the radiator.
- Refit the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page 19D-8) .

K9K



123824

- Disconnect the crankshaft position sensor (4) to prevent the engine from starting.
- Refit the oil filter (see 10A, **Engine and cylinder block assembly, Oil filter: Removal - Refitting**, page 10A-34)
- Fill up the engine oil (see 10A, **Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) .
- Start the engine using the starter until the engine oil warning light goes out.
- Connect the crankshaft position sensor.
- Refit the engine undertray.
- Clear the present faults using the **Diagnostic tool**.

## Engine oil: Draining - Refilling

K4M or K9K

### Equipment required

oil recovery tray
oil change wrench
torque wrench
oil change end piece with an 8 mm square drive

### Tightening torques

drain plug	20 N.m
------------	--------

## DRAINING

### I - AVERAGE CAPACITY OF ENGINE OIL

K4M

- 4.7 litres** (without oil filter replacement).
- 4.8 litres** (with oil filter replacement).

K9K

- 4.0 litres** (without oil filter replacement).
- 4.1 litres** (with oil filter replacement).

### II - RECOMMENDATIONS FOR REPAIR

#### WARNING

Always check the oil level using the dipstick.

Do not exceed the maximum level on the dipstick (could destroy the engine).

Correct the engine oil level if necessary before delivering the vehicle to the customer.

#### Note:


When filling up the engine oil, always leave at least **10 minutes** for the oil to drain down before checking with a dipstick.

### III - PARTS AND CONSUMABLES FOR REPAIR

- parts always to be replaced: Drain plug seal on engine oil sump.
- Consumable:
  - Engine oil (see **Engine oil: Specifications**).

### IV - OIL SERVICE


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).



144629


- Remove:
  - the engine oil filler cap (1),
  - the dipstick.
- Place the **oil recovery tray** under the engine.

K4M or K9K



144757

- Remove the drain plug (2) using the oil change wrench.
- Let the engine oil flow out completely.
- Remove the drain plug seal.

**Rubber-lipped seal**

113765

- Refit a new seal to the drain plug (no direction of fitting).
- Refit the drain plug.
- Torque tighten the **drain plug (20 N.m)** using a **torque wrench** fitted with a **oil change end piece with an 8 mm square drive**.
- Clean any oil run-off from the engine oil sump using a cloth.
- Remove the **oil recovery tray**.

**V - FILLING**

- Fill the engine with oil, respecting the recommended quantity.
- Wait at least **10 minutes**.
- Check the oil level using the dipstick.
- Top up the engine oil level if necessary.
- Refit:
  - the engine oil filler cap,
  - the dipstick.

## Oil filter: Removal - Refitting

K9K

## Special tooling required

**Mot. 1329** Oil filter removing tool (76 mm diameter)

**WARNING**


Always check the oil level using the dipstick.

Do not exceed the maximum level on the dipstick (could destroy the engine).

Correct the engine oil level if necessary before delivering the vehicle to the customer.

## Note:

When topping up the engine oil, always leave at least 10 minutes for the oil to drain down before checking with a dipstick.

**REMOVAL****OPERATION FOR REMOVAL OF PART CONCERNED**

24739

- Position the **(Mot. 1329)** (1) with an extension piece and a ratchet on the oil filter.
- Remove the oil filter.

**REFITTING****I - REFITTING PREPARATION OPERATION**

- parts always to be replaced: Oil filter.**
- Lubricate the new oil filter seal with new engine oil.

**II - REFITTING OPERATION FOR PART CONCERNED**

- Tighten the oil filter by hand until the oil filter seal makes contact with the oil filter support.
- Tighten the oil filter 3/4 of a turn manually or using the tool **(Mot. 1329)**.

**III - FINAL OPERATION**

- Wipe any oil run-off with a cloth.
- Check the oil level with the dipstick.
- Top up the oil level (if necessary).

K4M

### Special tooling required

**Mot. 1329** Oil filter removing tool (76 mm diameter)

### Equipment required

oil recovery tray

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### WARNING

Always check the oil level using the dipstick.

Do not exceed the maximum level on the dipstick (could destroy the engine).

Correct the engine oil level if necessary before delivering the vehicle to the customer.

Note:

When filling up the engine oil, always leave at least **10 minutes** for the oil to drain down before checking with a dipstick.


When removing the oil filter, check that the oil filter seal is not still stuck to the cylinder block or the oil filter support.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the engine undertray bolts,
  - the engine undertray.
- Place the **oil recovery tray** under the engine.
- Remove the injector rail protector.

### II - REMOVAL OPERATION



116556

- Remove the oil filter using the **(Mot. 1329) (1)**.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Oil filter.**
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease the cylinder block joint face.
- Lubricate the oil filter seal with new engine oil.

### II - REFITTING OPERATION

- Fit a new oil filter.
- Tighten the oil filter until it makes contact with the engine.
- Manually tighten the oil filter by 3/4 of a turn.

### III - FINAL OPERATION

- Refit the injector rail protector.
- Remove the **oil recovery tray**.
- Wipe any oil run-off with a cloth.
- Top up with engine oil recommended by the manufacturer (see **Engine oil: Specifications**).
- Start the engine and wait until the oil pressure warning light goes out on the instrument panel.
- Check for leaks from the oil filter.
- Refit the engine undertray.
- Wait at least **10 minutes**.
- Check the oil level using the dipstick.

K4M

- Top up the engine oil level to the dipstick if necessary (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**)

Dacia Duster Explorers UK

# ENGINE AND CYLINDER BLOCK ASSEMBLY


## Oil-coolant heat exchanger: Removal - Refitting

# 10A

K9K, and 796

### Tightening torques

oil heat exchanger bolt	39 N.m
oil filter support bolt	28 N.m



106794

- (1) Oil filter holder mounting bolt
- (2) Oil filter
- (3) Oil filter holder
- (4) Coolant - oil heat exchanger mounting bolts
- (5) Coolant - oil heat exchanger
- (6) Oil pressure sensor

### REMOVAL

#### REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the engine cover,

- the engine undertray,
- the closure panel component under the diesel filter.


- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

# ENGINE AND CYLINDER BLOCK ASSEMBLY

## Oil-coolant heat exchanger: Removal - Refitting


# 10A

K9K, and 796




24821

- ❑ Disconnect the air outlet duct (7) on the intercooler.




113894

- ❑ Disconnect the oil pressure sensor connector (9) .
- ❑ Place a container under the engine on the oil filter side.
- ❑ Remove the bolt (10) from the oil filter support.
- ❑ Remove the oil filter support.



24811


- ❑ Move aside the air outlet duct.
- ❑ Remove the air outlet duct support (8) from the fan assembly mounting.



133518

- ❑ Remove the seal (11) from the oil filter support.

K9K, and 796




113895

- Remove:
  - the bolt (12) from the oil-coolant heat exchanger,
  - the oil-water heat exchanger.
- Using a clean cloth, clean up any oil and coolant runs on the cylinder block and on the oil filter support.

### REFITTING

#### I - REFITTING PREPARATION OPERATION


- parts always to be replaced: coolant-engine oil heat exchanger seal on the cylinder block.**
- Always replace:
  - the seals of the oil filter support bolt,
  - the oil filter support seal.



107306

- Remove the oil-water heat exchanger seals (13) .
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the housing of each seal in the oil-water heat exchanger if it is to be reused,
  - the oil-coolant heat exchanger seal face if it is to be reused,
  - the mating face of each seal on the coolant pump inlet pipe,
  - the joint face on the cylinder block,
  - the housing of each oil filter support seal,
  - the housing of each seal in the oil filter support.

K9K, and 796




107306

- Refit new seals (14) and (15) on the oil-water heat exchanger.
- Apply soapy water to the two seals (15) in contact with the coolant pump inlet pipe.

### II - REFITTING OPERATION FOR PART CONCERNED


- Refit the oil-water heat exchanger.
- Torque tighten the **oil heat exchanger bolt (39 N.m)**.

### III - FINAL OPERATION



133518

133518



107857

- Refit:
  - a new seal in the housing of the oil filter support,
  - the oil filter support, positioning the lug (16) in the hole (17) of the oil-water heat exchanger.
- Refit the oil filter holder bolt.
- Torque tighten the **oil filter support bolt (28 N.m)**.
- Connect the oil pressure sensor connector.
- Refit the air outlet duct support on the fan assembly mounting.

# ENGINE AND CYLINDER BLOCK ASSEMBLY

## Oil-coolant heat exchanger: Removal - Refitting

# 10A

K9K, and 796

- Connect the air outlet duct to the intercooler.
- Fill the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Refit:
  - the closure panel component under the diesel filter,
  - the engine undertray,
  - the engine cover.
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

Dacia Duster Explorers UK

K9K

### Tightening torques


oil pressure sensor	33 N.m
---------------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the engine undertray.

### II - OPERATION FOR REMOVAL OF PART CONCERNED



113894

- Disconnect the oil pressure sensor connector.
- Remove the oil pressure sensor (2) using the.

## REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED

- Refit the oil pressure sensor.
- Torque tighten the **oil pressure sensor (33 N.m)**.
- Connect the oil pressure sensor connector.

### II - FINAL OPERATION

- Refit the engine undertray.

K4M

### Tightening torques


oil pressure sensor	35 N.m
---------------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the engine undertray bolts,
  - the engine undertray.

### II - REMOVAL OPERATION



116639

- Disconnect the oil pressure sensor connector (1) .
- Remove the oil pressure sensor.

## REFITTING

### I - REFITTING OPERATION

- Degrease the mating face of the oil pressure sensor on the cylinder block using **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).
- Refit the oil pressure sensor.
- Torque tighten the **oil pressure sensor (35 N.m)**.

### II - FINAL OPERATION

- Connect the oil pressure sensor connector.
- Refit the engine undertray.

## Oil pump: Removal - Refitting

K9K

Tightening torques 


oil pump bolts	25 N.m
----------------	--------

## REMOVAL

## I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Drain the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) .
- Remove the sump (see **10A, Engine and cylinder block assembly, Lower cover: Removal - Refitting**, page 10A-9) .

## II - OPERATION FOR REMOVAL OF PART CONCERNED



108646

- Remove:
  - the oil pump bolts (1) ,
  - the oil pump.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Check for oil pump centering rings on the cylinder block.

## II - REFITTING OPERATION FOR PART CONCERNED

- Refit the oil pump.
- Torque tighten the **oil pump bolts (25 N.m)**.

## III - FINAL OPERATION

- Refit the sump (see **10A, Engine and cylinder block assembly, Lower cover: Removal - Refitting**, page 10A-9) .
- Top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) .

## Oil pump: Removal - Refitting

K4M

Tightening torques 


oil pump bolts	25 N.m
----------------	--------

## REMOVAL

## I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Drain the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) .
- Remove the sump (see **10A, Engine and cylinder block assembly, Lower cover: Removal - Refitting**, page 10A-9) .

## II - REMOVAL OPERATION



108646

- Remove:
  - the oil pump bolts (1) ,
  - the oil pump.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Check for centering rings on the oil pump.

## II - REFITTING OPERATION

- Refit the oil pump.
- Torque tighten the **oil pump bolts (25 N.m)**.

## III - FINAL OPERATION

- Refit the sump (see **10A, Engine and cylinder block assembly, Lower cover: Removal - Refitting**, page 10A-9) .
- Top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) .

## Oil pressure: Check

K4M or K9K

### Oil pressure tables:

Engine	Minimum oil pressure (bar)		Maximum oil pressure (bar)
	Idling speed	3000 rpm	3000 rpm
D4D, D4F	1.5	3.9	5.3
K7J, K7M	1.3	3.7	5.0

Engine	Minimum oil pressure (bar)		Maximum oil pressure (bar)
	Idling speed	4000 rpm	4000 rpm
K4M	0.5	3.1	4.4
K9K	0.8	3.4	5.2

### End pieces to be used:

Engine	End pieces
D4D, D4F	C + F
K4M, K7J, K7M, K9K	E + C + F

### I - REMOVAL PREPARATION OPERATION

#### WARNING

Always check the oil level using the dipstick.

Do not exceed the maximum level on the dipstick (could destroy the engine).


Correct the engine oil level if necessary before delivering the vehicle to the customer.

#### Note:

When topping up the engine oil, always leave at least **10 minutes** before checking the level with a dipstick.

### II - CHECK

- Remove the oil pressure sensor (see **10A, Engine and cylinder block assembly, Oil pressure sensor: Removal - Refitting**, page 10A-42).



87363

- In place of the oil pressure sensor, fit the with suitable adapters using their a **22 mm** long socket.
- Start the vehicle.
- Monitor the engine oil pressure as the oil temperature rises (approximately **80°C** or the first time the engine cooling fan is activated); it should not be less than the pressure at idle speed.
- If the oil pressure is lower than the pressure at idle speed, check that:
  - the oil filter is not clogged,
  - dirt or swarf is not present in the engine oil,
  - the oil pump is in good condition and being correctly driven.
- Check the oil pressure in comparison with the values given in the table above.
- Switch off the engine.
- Remove the with the end pieces.
- Refit the oil pressure sensor (see **10A, Engine and cylinder block assembly, Oil pressure sensor: Removal - Refitting**, page 10A-42).
- Wipe any oil run-off with a cloth.
- Wait at least **10 minutes**.
- Check the oil level using the dipstick.

## Oil pressure: Check

K4M or K9K

- Top up the engine oil level if necessary (see **Engine oil: Specifications**) .
- Start the vehicle and check that there are no oil leaks at the oil pressure sensor.

Dacia Duster Explorers UK

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

Tightening torques 	
multifunction support bolts on the cylinder block	<b>44 N.m</b>
lower bolt of the multifunction support on the sump	<b>25 N.m</b>


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch side liner,
  - the injector rail protector,
  - the engine undertray bolts,
  - the engine undertray.
- Remove the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Disconnect fuel supply pipe on the injector rail.
- Remove:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page **11A-2**),
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page **16A-1**).
- Remove (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the bolt from the power-assisted steering high pressure pipe on the cylinder block,
  - the bolts from the power-assisted steering pump on the multifunction support (without opening the circuit).
- Attach the power-assisted steering pump to the front end panel.
- Disconnect the connector from the air conditioning compressor.

- Remove the air conditioning compressor bolts (without opening the circuit) (see **Compressor: Removal - Refitting**) (62A, Air conditioning).
- Attach the air conditioning compressor to the sub-frame.

### II - REMOVAL OPERATION




- Remove:
  - the multifunction support bolts (1),
  - the multifunction support.

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

## REFITTING

## I - REFITTING OPERATION



- Refit the multifunction support.
- Position bolts (1) to (6) without tightening them.
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m**.
- Loosen bolts (1) and (2) of the multifunction support by one half-turn.
- Pretighten the multifunction support bolt (6) on the sump **5 N.m**.
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m**.
- Pretighten in order (3) , (4) , (5) , (6) the multifunction support bolts on the cylinder block (**5 N.m**).
- Torque tighten in order (1) , (2) , (3) , (4) , (5) the **multifunction support bolts on the cylinder block (44 N.m)**.
- Torque tighten the **lower bolt of the multifunction support on the sump (25 N.m) (6)** .

## II - FINAL OPERATION

- Refit the air conditioning compressor (see **Compressor: Removal - Refitting**) (62A, Air conditioning).
- Connect the air conditioning compressor connector.

- Refit (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the power-assisted steering pump,
  - the bolt of the power-assisted steering high pressure pipe on the cylinder block.
- Refit:
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .
- Connect the fuel supply pipe on the injector rail.
- Refit the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Refit:
  - the engine undertray,
  - the injector rail protector.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

K4M, and STANDARD HEATING RECIRCULATION

Tightening torques 	
multifunction support bolts on the cylinder block	44 N.m
multifunction support bolt on the sump	25 N.m

### REMOVAL


#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch side liner,
  - the engine undertray bolts,
  - the engine undertray.
- Remove the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Remove:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) .

#### POWER ASSISTED STEERING

- Remove (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the power-assisted steering pump bolts,
  - the high pressure pipe bolt on the cylinder block.
- Attach the power-assisted steering pump to the front end panel.

#### II - REMOVAL OPERATION




102265

- Remove:
  - the multifunction support bolts (2) ,
  - the multifunction support.

K4M, and STANDARD HEATING RECIRCULATION

## REFITTING

## I - REFITTING OPERATION



- Refit the multifunction support.
- Position bolts (1) to (7) without tightening them.
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m.**
- Loosen bolts (1) and (2) a half-turn.
- Pretighten the multifunction support bolt (7) on the sump **5 N.m.**
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m.**
- Pretighten the multifunction support bolts (3) , (4) , (5) , (6) on the cylinder block **5 N.m.**
- Torque tighten in order (1), (2), (3), (4), (5), (6) the **multifunction support bolts on the cylinder block (44 N.m).**
- Torque tighten the **multifunction support bolt on the sump (25 N.m) (7) .**

## II - FINAL OPERATION

## POWER ASSISTED STEERING

- Refit (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the power-assisted steering pump,
  - the power-assisted steering pump bolts,

- the high pressure pipe bolt on the cylinder block.

 Refit:

- the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) ,
- the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .

- Refit the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).

- Refit the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

K9K

### Tightening torques

multifunction support bolts on the cylinder block	<b>44 N.m</b>
multifunction support bolt on the sump	<b>25 N.m</b>

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch side liner,
  - the engine undertray bolts,
  - the engine undertray,
  - the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page **11A-2**),
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page **16A-1**).


### POWER ASSISTED STEERING, and STANDARD HEATING RECIRCULATION

- Remove the bolts from the power-assisted steering pump on the multifunction support (without opening the circuit) (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering).
- Attach the power-assisted steering pump to the front end panel.

### AIR CONDITIONING

- Disconnect the air conditioning compressor connector.
- Remove the air conditioning compressor bolts (without opening the circuit) (see **Compressor: Removal - Refitting**) (62A, Air conditioning).
- Attach the air conditioning compressor to the lower front cross member.
- Unpick the wiring harness on the multifunction support.

### II - REMOVAL OPERATION




- Remove:
  - the multifunction support bolts (1),
  - the multifunction support.

K9K

## REFITTING

### REFITTING OPERATION



19704

- Refit the multifunction support.
- Position bolts (1) to (7) without tightening them.
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m**.
- Loosen bolts (1) and (2) a half-turn.
- Pretighten the multifunction support bolt (7) on the sump **5 N.m**.
- Pretighten the multifunction support bolts (1) and (2) on the cylinder block **5 N.m**.
- Pretighten the multifunction support bolts (3) , (4) , (5) , (6) on the cylinder block **5 N.m**.
- Torque tighten in order (1) , (2) , (3) , (4) , (5) , (6) the **multifunction support bolts on the cylinder block (44 N.m)**.
- Torque tighten the **multifunction support bolt on the sump (25 N.m) (7)** .
- Proceed in the reverse order to removal.

K4M

### Special tooling required

<b>Mot. 1448</b>	Remote operation pliers for hose clips.
<b>Mot. 1390</b>	Support for removal - refitting of engine - gearbox assembly

### Equipment required

refrigerant charging station

### Tightening torques

nut on the rubber pad support of the left-hand suspended engine mounting	<b>62 N.m</b>
exhaust flange bolts	<b>21 N.m</b>
front axle subframe tie-rod upper bolts	<b>21 N.m</b>
anti-roll bar tie rod upper bolts	<b>37 N.m</b>
earth strap bolt on the gearbox	<b>21 N.m</b>
power-assisted steering low pressure pipe bolt on the front axle sub-frame	<b>21 N.m</b>
power-assisted steering pipe bolts on the gearbox support	<b>21 N.m</b>
power-assisted steering pipe bolts on the gearbox	<b>21 N.m</b>
power-assisted steering pipe bolt on the cylinder block	<b>21 N.m</b>

### IMPORTANT

Wear cut-resistant gloves during the operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION



#### IMPORTANT

To prevent the vehicle from falling, lash it to the vehicle lift using a strap.

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).


### AIR CONDITIONING

- Drain the refrigerant circuit using the tool **refrigerant charging station** (see **Refrigerant circuit: Draining - Filling**) (62A, Air conditioning).

- Remove:


- the air inlet sleeve,
- the battery (see **Battery: Removal - Refitting**) (80A, Battery),
- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
- the injector rail protector,
- the battery tray,
- the injection computer (see **17B, Petrol injection, Petrol injection computer: Removal - Refitting**, page 17B-7) .

K4M




116654

- Disconnect the accelerator cable on the throttle valve at (1) .
- Remove the accelerator cable from the inlet distributor at (2) .



145508

- Remove the engine wiring bolt (3) on the battery mounting.
- Unclip the battery wiring at (4) .
- Remove the earth strap bolt (5) on the battery mounting.




145507

- Remove the fuse and relay box cover.
- Remove the side protector (6) of the fuse and relay box.
- Disconnect the engine harness - front wiring connector (7) .
- Unclip the engine harness fuse holders and relays (8) from their mountings on the fuse and relay box in the engine compartment.
- Position the engine harness, fuses and relays on the engine.
- Remove:
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the engine undertray bolts,
  - the engine undertray,
  - the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection),
  - the front wheel arch liners (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Drain:
  - the engine oil if necessary (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32) ,
  - the gearbox oil (see **Manual gearbox oils: Draining - Filling**) (21A, Manual gearbox),

K4M

- the cooling system (see 19A, Cooling, Cooling system: Draining - Refilling, page 19A-6) .




Disconnect:

- the fuel supply pipe (9) on the injector rail,
- the petrol vapour rebreather pipe (10) .

**WARNING**

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.


- Fit blanking plugs on the fuel supply pipe.
- Unclip the pipes at (11) .



- Disconnect the connector (12) from the fuel vapour recirculation solenoid valve.
- Disconnect (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the power-assisted steering low pressure hose on the power-assisted steering pump using the (**Mot. 1448**) and drain the circuit,
  - the power-assisted steering high pressure pipe on the power-assisted steering pump,
  - the connector from the power-assisted steering pressure switch.

K4M


### STANDARD HEATING RECIRCULATION



145498

- Remove:
  - the power-assisted steering low pressure pipe (13) on the oil reservoir using the **(Mot. 1448)**,
  - the power assisted steering oil reservoir (14) ,
  - the bolt of the power-assisted steering high pressure pipe on the cylinder block.
- Unclip the power-assisted steering pipes on the fan assembly mounting at (15) .
- Disconnect the fan assembly connector (16) .


### AIR CONDITIONING




145497

- Remove:
  - the power-assisted steering low pressure pipe (17) on the oil reservoir using the **(Mot. 1448)**,
  - the power assisted steering oil reservoir (18) ,
  - the bolt of the power-assisted steering high pressure pipe on the cylinder block.
- Unclip the power-assisted steering pipes on the fan assembly mounting at (19) .
- Disconnect the connectors (20) from the fan assembly.
- Unclip the fan assembly wiring at (21) .

K4M



- ❑ Remove the power-assisted steering low pressure pipe bolt (22) on the front axle subframe.



- ❑ Remove:
  - the power-assisted steering high pressure pipe bolt (23) on the gearbox,
  - the power-assisted steering high pressure pipe bolt (24) on the gearbox support,
  - the earth strap bolt (25) on the gearbox.


### AIR CONDITIONING

- ❑ Remove (see **Compressor: Removal - Refitting**) (62A, Air conditioning):
  - the pipe retaining bracket bolt on the compressor,
  - the pipe union bolts on the compressor.

#### Note:


Plugs must be fitted on the hoses to prevent moisture from entering the system.

- ❑ Disconnect the compressor pipes.
- ❑ Fit blanking plugs in the pipe openings.
- ❑ Disconnect the air conditioning pressostat connector.




- ❑ Move aside the cooling hose clips (26) on the coolant pump inlet pipe using the **(Mot. 1448)**.
- ❑ Disconnect:
  - the cooling hoses on the coolant pump inlet pipe,
  - the vacuum pipe on the inlet distributor chamber.

K4M



116637


- Move aside the clips (27) of the coolant hoses on the water chamber using the (Mot. 1448).
- Disconnect the cooling hoses from the water chamber.
- Unclip the downstream oxygen sensor wiring on the steering box heat shield.
- Disconnect the downstream oxygen sensor connector.



145789

- Remove the cooling pipe support bolt (28) on the sump.


- Remove (see ) (36A, Steering assembly):
  - the heat shield bolts on the steering box,
  - the steering box heat shield,
  - the steering box bolts on the front axle subframe.
- Attach the steering rack to the body.




144756

- Remove:
  - the front axle subframe tie-rod upper bolts (29) ,
  - the anti-roll bar tie rod upper bolts (30) ,
  - the front right-hand wheel driveshaft (see **Front right-hand driveshaft: Removal - Refitting**) (29A, Driveshaft),
  - the front left-hand wheel driveshaft (see **Front left-hand driveshaft: Removal - Refitting**) (29A, Transmission).
- Pass the power-assisted steering low pressure pipe over the gearbox cover.


K4M



118882



24810



109149


- Unclip:
  - the gear control cables on the gearbox at (31) using a screwdriver,
  - the gear control cables from the sleeve stops by pressing at (A) .
- Move the gear control cables away from the gearbox.

**WARNING**

Do not pull the clip. If it is incorrectly handled in any way, the pipe will need to be replaced.

- Disconnect the clutch control pipe on the clutch slave cylinder by pressing the clip (32) .
- Recover the brake fluid in a container.
- Fit blanking plugs on the pipe openings.
- Remove the lower engine tie-bar (see 19D, **Engine mounting, Lower engine tie-bar: Removal - Refitting**, page 19D-8) .

K4M




- Remove:
  - the bolts (33) from the exhaust flange,
  - the exhaust bracket ring.
- Move aside the exhaust pipe.

Note:

Pull the exhaust pipe backwards.


- Remove the front axle subframe (see **Front axle subframe: Removal - Refitting**) (31A, Front axle components).

### II - REMOVAL OPERATION




- Mark the positions of the suspended engine mountings on the body.
- Support the engine - gearbox assembly on the engine marks (34) using the (Mot. 1390).
- Remove the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page **19D-4**).

K4M



107929

- Remove the nut (35) on the rubber pad support of the left-hand suspended engine mounting.
- Strike the gearbox stud with a copper hammer to separate the engine - gearbox assembly from the body.



123542

- Lift the vehicle to remove the engine - gearbox assembly.

Note:

Ensure that no component obstructs the movement of the body around the engine - gearbox assembly.

- Remove the engine - gearbox assembly.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- For standard engine replacements (see **Engine: Standard replacement**) (Technical Note 6006A, 10A, Engine and peripherals).
- parts always to be replaced: ring between exhaust manifold and catalytic converter**

### II - REFITTING OPERATION

- Fit the engine - gearbox assembly.
- Refit the nut on the rubber pad support of the left-hand suspended engine mounting.
- Torque tighten the **nut on the rubber pad support of the left-hand suspended engine mounting (62 N.m)**.
- Refit the right-hand suspended engine mounting (see 19D, **Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) .

K4M

- Remove the **(Mot. 1390)** from the engine - gearbox assembly.

### III - FINAL OPERATION

- Proceed in the reverse order to removal.
- Torque tighten:
  - the **exhaust flange bolts (21 N.m)**,
  - the **front axle subframe tie-rod upper bolts (21 N.m)**,
  - the **anti-roll bar tie rod upper bolts (37 N.m)**,
  - the **earth strap bolt on the gearbox (21 N.m)**,
  - the **power-assisted steering low pressure pipe bolt on the front axle subframe (21 N.m)**,
  - the **power-assisted steering pipe bolts on the gearbox support (21 N.m)**,
  - the **power-assisted steering pipe bolts on the gearbox (21 N.m)**,
  - the **power-assisted steering pipe bolt on the cylinder block (21 N.m)**.
- Perform the following operations:
  - top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page **10A-32**),
  - fill up the gearbox oil (see **Manual gearbox oils: Draining - Filling**) (21A, Manual gearbox),
  - fill and bleed the cooling circuit (see **19A, Cooling, Cooling system: Draining - Refilling**, page **19A-6**),
  - bleed the clutch circuit (see **Clutch circuit: Bleed**) (37A, Mechanical component controls).

- Check that there are no leaks.

### AIR CONDITIONING

- Fill the refrigerant circuit using the tool **refrigerant charging station** (see **Refrigerant circuit: Draining - Filling**) (62A, Air conditioning).
- Fill up the power-assisted steering circuit.
- First, bleed the power-assisted steering circuit by turning the steering wheel fully from left to right with the engine off.
- Bleed the power-assisted steering circuit by turning the steering wheel fully from lock to lock with the engine running.
- Top up the oil in the power-assisted steering oil reservoir.

# ENGINE AND CYLINDER BLOCK ASSEMBLY

## Engine - gearbox assembly: Removal - Refitting

# 10A

K9K, and 796

Special tooling required	
<b>Mot. 1448</b>	Remote operation pliers for hose clips.
<b>Mot. 1390</b>	Support for removal - refitting of engine - gearbox assembly

Equipment required
refrigerant charging station

Tightening torques 	
nut on the rubber pad support of the left-hand suspended engine mounting	<b>62 N.m</b>
exhaust flange bolts	<b>21 N.m</b>
front axle subframe tie-rod upper bolts	<b>21 N.m</b>
anti-roll bar tie rod upper bolts	<b>37 N.m</b>
earth strap bolt on the gearbox	<b>21 N.m</b>
power-assisted steering low pressure pipe bolt on the front axle subframe	<b>21 N.m</b>
power-assisted steering pipe bolts on the gearbox support	<b>21 N.m</b>
power-assisted steering pipe bolts on the gearbox	<b>21 N.m</b>
power-assisted steering pipe bolt on the cylinder block	<b>21 N.m</b>

### IMPORTANT

Wear cut-resistant gloves during the operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION



#### IMPORTANT

To prevent the vehicle from falling, lash it to the vehicle lift using a strap.

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).


### AIR CONDITIONING

- Drain the refrigerant circuit using the tool **refrigerant charging station** (see **Refrigerant circuit: Draining - Filling**) (62A, Air conditioning).

- Remove:


- the engine cover,
- the air inlet sleeve,
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
- the battery (see **Battery: Removal - Refitting**) (80A, Battery),
- the battery tray,
- the injection computer (see **17B, Petrol injection, Petrol injection computer: Removal - Refitting**, page 17B-7).

K9K, and 796



145506

- Remove the engine wiring bolt (1) on the battery mounting.
- Unclip the battery wiring at (2).
- Remove the earth strap bolt (3) on the battery mounting.
- Disconnect the connector (4) from the pre-postheating unit.
- Disconnect the non-return valve (5) at the vacuum pump.




145507


- Remove the fuse and relay box cover.
- Remove the side protector (6) of the fuse and relay box.
- Disconnect the engine harness - front wiring connector (7).
- Unclip the engine harness fuse holders and relays (8) from their mountings on the fuse and relay box in the engine compartment.
- Position the engine harness, fuses and relays on the engine.
- Remove:
  - the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the engine undertray bolts,
  - the engine undertray,
  - the front bumper (see **Front bumper assembly: Exploded view**) and (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection),
  - the front wheel arch liners (see **Exterior body front trim assembly: Exploded view**) (55A, Exterior protection).
- Drain:
  - the engine oil if necessary (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling**, page 10A-32),
  - the gearbox oil (see **Manual gearbox oils: Draining - Filling**) (21A, Manual gearbox),

K9K, and 796

- the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .



- Disconnect the connector (9) from the water detection sensor on the diesel filter.
- Unclip the water detection connector on the diesel filter mounting at (10) .




- Disconnect:
  - the fuel supply pipe (11) ,
  - the fuel return pipe (12) .

### WARNING


To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

- Fit blanking plugs on the fuel supply pipe.
- Unclip the pipes at (13) .
- Disconnect the intercooler ducts (see 12B, **Turbocharging, Intercooler: Removal - Refitting**, page 12B-8) .

K9K, and 796



122813




145504

- Unclip:
  - the turbocharger control solenoid valve wiring at (14) ,
  - the turbocharger control solenoid valve (15) from its support.
- Disconnect:
  - the air duct (16) on the EGR assembly,
  - the air duct between the turbocharger and the intercooler at (17) .
- Remove:

- the air duct nut (18) on the gearbox,
- the intercooler air ducts.

- Disconnect (see **Power-assisted steering pump: Removal - Refitting**) (36B, Power-assisted steering):
  - the power-assisted steering low pressure hose on the power-assisted steering pump using the (**Mot. 1448**) and drain the circuit,
  - the power-assisted steering high pressure pipe on the power-assisted steering pump,
  - the connector from the power-assisted steering pressure switch.

### STANDARD HEATING RECIRCULATION




145498


- Remove:
  - the power-assisted steering low pressure pipe (19) on the oil reservoir using the (**Mot. 1448**),
  - the power assisted steering oil reservoir (20) ,
  - the bolt of the power-assisted steering high pressure pipe on the cylinder block.
- Unclip the power-assisted steering pipes on the fan assembly mounting at (21) .
- Disconnect the fan assembly connector (22) .

K9K, and 796

### AIR CONDITIONING




- Remove the power-assisted steering high pressure pipe bolt on the cylinder block.
- Disconnect the connectors (23) from the fan assembly.
- Unclip the fan assembly wiring at (24) .



145505


- Remove the earth strap bolt (25) on the body.
- Disconnect the pump assembly connectors (26) .
- Unclip the pump assembly wiring at (27) .



24762

- Remove the power-assisted steering low pressure pipe bolt (28) on the front axle subframe.

K9K, and 796



145559

Remove:

- the power-assisted steering high pressure pipe bolt (29) on the gearbox,
- the power-assisted steering high pressure pipe bolt (30) on the gearbox support,
- the earth strap bolt (31) on the gearbox.


### AIR CONDITIONING

- Remove the bolts from the pipe unions on the compressor.
- Disconnect the compressor pipes.

**Note:**


Plugs must be fitted on the hoses to prevent moisture from entering the system.

- Fit blanking plugs in the pipe openings.
- Disconnect the air conditioning pressostat connector.
- Remove the expansion bottle nuts.
- Move aside the expansion bottle.



145500

- Move aside the cooling hose clip (32) on the water chamber using the (Mot. 1448).
- Disconnect the cooling hose on the water chamber.




145501

- Move aside the cooling hose clips (33) on the heating radiator using the (Mot. 1448).
- Disconnect the cooling hoses on the heating radiator.
- Remove the cooling hoses from their mountings.
- Remove (see ) (36A, Steering assembly):
  - the steering box heat shield bolts,

K9K, and 796

- the steering box heat shield,
- the steering box bolts on the front axle subframe.

□ Attach the steering rack to the body.



144756


□ Remove:

- the front axle subframe tie-rod upper bolts (34) ,
- the anti-roll bar tie rod upper bolts (35) .


□ Remove:

- the front right-hand wheel driveshaft (see **Front right-hand driveshaft: Removal - Refitting**) (29A, Driveshaft),
- the front left-hand wheel driveshaft (see **Front left-hand driveshaft: Removal - Refitting**) (29A, Transmission).

□ Pass the power-assisted steering low pressure pipe over the gearbox cover.



24817



109149


109149

□ Unclip:

- the gear control cables on the gearbox at (36) using a screwdriver,
- the gear control cables from the sleeve stops by pressing at (A) .

□ Move the gear control cables away from the gearbox.

K9K, and 796




24810



### WARNING

Do not pull the clip. If it is incorrectly handled in any way, the pipe will need to be replaced.

- Disconnect the clutch control pipe on the clutch slave cylinder by pressing the clip (37) .
- Recover the brake fluid in a container.
- Fit blanking plugs in the pipe openings.
- Remove the lower engine tie-bar (see **19D, Engine mounting, Lower engine tie-bar: Removal - Refitting**, page 19D-8) .



135949

- Remove:
  - the bolts (38) from the exhaust flange,
  - the exhaust bracket ring.
- Move aside the exhaust pipe.


### Note:

Pull the exhaust pipe backwards.


- Remove the front axle subframe (see **Front axle subframe: Removal - Refitting**) (31A, Front axle components).

K9K, and 796

### II - REMOVAL OPERATION



112813




112814

□

Note:

Ensure that the **(Mot. 1390)** is correctly positioned on the multifunction support at **(39)**.


- Position the **(Mot. 1390)** under the engine - gearbox assembly.
- Remove the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting, page 19D-4**).



107929

- Remove the nut **(40)** on the rubber pad support of the left-hand suspended engine mounting.
- Strike the gearbox stud with a copper hammer to separate the engine - gearbox assembly from the body.

K9K, and 796



123542

- Lift the vehicle to remove the engine - gearbox assembly.

#### Note:

Ensure that no component obstructs the movement of the body around the engine - gearbox assembly.

- Remove the engine - gearbox assembly.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- For standard engine replacements (see **Engine: Standard replacement**) (Technical Note 6006A, 10A, Engine and peripherals).
- parts always to be replaced: ring between exhaust manifold and catalytic converter**

### II - REFITTING OPERATION

- Fit the engine - gearbox assembly.
- Refit the nut on the rubber pad support of the left-hand suspended engine mounting.
- Torque tighten the **nut on the rubber pad support of the left-hand suspended engine mounting (62 N.m)**.
- Refit the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting, page 19D-4**).

- Remove the **(Mot. 1390)** from the engine - gearbox assembly.

### III - FINAL OPERATION

- Proceed in the reverse order to removal.
- Torque tighten:
  - the **exhaust flange bolts (21 N.m)**,
  - the **front axle subframe tie-rod upper bolts (21 N.m)**,
  - the **anti-roll bar tie rod upper bolts (37 N.m)**,
  - the **earth strap bolt on the gearbox (21 N.m)**,
  - the **power-assisted steering low pressure pipe bolt on the front axle subframe (21 N.m)**,
  - the **power-assisted steering pipe bolts on the gearbox support (21 N.m)**,
  - the **power-assisted steering pipe bolts on the gearbox (21 N.m)**,
  - the **power-assisted steering pipe bolt on the cylinder block (21 N.m)**.
- Perform the following operations:
  - top up the engine oil (see **10A, Engine and cylinder block assembly, Engine oil: Draining - Refilling, page 10A-32**),
  - fill up the gearbox oil (see **Manual gearbox oils: Draining - Filling**) (21A, Manual gearbox),
  - fill and bleed the cooling circuit (see **19A, Cooling, Cooling system: Draining - Refilling, page 19A-6**),
  - bleed the clutch circuit (see **Clutch circuit: Bleed**) (37A, Mechanical component controls).

### AIR CONDITIONING

- Fill the refrigerant circuit using the tool **refrigerant charging station** (see **Refrigerant circuit: Draining - Filling**) (62A, Air conditioning).

- Fill up the power-assisted steering circuit.
- First, bleed the power-assisted steering circuit by turning the steering wheel fully from left to right with the engine off.
- Bleed the power-assisted steering circuit by turning the steering wheel fully from lock to lock with the engine running.
- Top up the oil in the power-assisted steering oil reservoir.

# ENGINE AND CYLINDER BLOCK ASSEMBLY

## Engine - gearbox assembly: Removal - Refitting

# 10A

K9K, and 796

- Check that there are no leaks.

Dacia Duster Explorers UK

## Flywheel: Removal - Refitting

K4M

### Tightening torques


flywheel bolts	25 N.m + 50° ± 6°
----------------	-------------------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove:
  - the gearbox (see **Manual gearbox: Removal - Refitting**),
  - the clutch pressure plate (see **Pressure plate - Disc: Removal - Refitting**).

### II - REMOVAL OPERATION



107913

- Lock the engine using the (1).
- Remove:
  - the flywheel bolts,
  - the flywheel,
  - the.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Check the condition of the flywheel.
- On the crankshaft, clean the flywheel bolt threading.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the flywheel bearing face if reusing,
  - the crankshaft bearing face.
- parts always to be replaced: Flywheel bolts.**
- Coat the new flywheel bolts using **FRENETANCHE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).



23325


### WARNING

Do not remove the bolts (2) from the flywheel drive plate.

### II - REFITTING OPERATION

- Refit the flywheel.

K4M



107913

- Screw in the new flywheel bolts without tightening them.
- Lock the engine using the.
- Torque tighten in order the **flywheel bolts (25 N.m + 50° ± 6°)**.
- Remove the tool.

### III - FINAL OPERATION

- Refit:
  - the clutch pressure plate (see **Pressure plate - Disc: Removal - Refitting**) ,
  - the gearbox (see **Manual gearbox: Removal - Refitting**) .

## Flywheel: Removal - Refitting

K9K

### Tightening torques


flywheel bolts	55 N.m
----------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove:
  - the manual gearbox (see **Manual gearbox: Removal - Refitting**) ,
  - the clutch pressure plate (see **Pressure plate - Disc: Removal - Refitting**) .

### II - OPERATION FOR REMOVAL OF PART CONCERNED



109158

- Lock the flywheel with the(1).
- Remove the flywheel bolts.
- Remove:
  - the flywheel,
  - the.

## REFITTING

### I - REFITTING PREPARATION OPERATION


- Check the condition of the flywheel.
- parts always to be replaced: Flywheel bolts.**

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:

- the crankshaft bearing face on the flywheel if re-used,
- the flywheel pressure face on the crankshaft,
- the flywheel threading.

### II - REFITTING OPERATION FOR PART CONCERNED

- Refit the flywheel.
- Coat the new flywheel bolts with **FRENETCH** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).



23326

- Lock the flywheel using tool.
- Tighten to torque and in order the **flywheel bolts (55 N.m)**.

### III - FINAL OPERATION

- Refit:
  - the clutch pressure plate (see **Pressure plate - Disc: Removal - Refitting**) ,
  - the manual gearbox (see **Manual gearbox: Removal - Refitting**) .

# TOP AND FRONT OF ENGINE

## Pressure at end of compression: Check

# 11A

K4M

### Equipment required


petrol compression gauge

Diagnostic tool

## CHECK

### I - PREPARATION OPERATION FOR CHECK

- Remove:
  - the coils (see **17A, Ignition, Coils: Removal - Refitting**, page **17A-1**),
  - the spark plugs (see **Plugs: Removal - Refitting**).



132338

- Connect a **petrol compression gauge (1)**.
- Put the vehicle under starting conditions:
  - gear lever in neutral position for manual gearbox,
  - gear lever in position P (park) for an automatic gearbox.
- Disconnect the injector connectors.

### II - TEST OPERATION

- Activate the starter until the needle of the petrol compression gauge stabilises.
- Measure the compression of the engine, cylinder by cylinder.

- Fully depress the accelerator pedal in order to open the throttle valve during the compression measurements.

#### Note:

It is necessary to wait for at least **10 seconds** before starting the engine each time (the starter will not run due to its thermal protection).

### III - FINAL OPERATION

- Disconnect the **petrol compression gauge**.
- Refit:
  - the spark plugs (see **Plugs: Removal - Refitting**),
  - the coils (see **17A, Ignition, Coils: Removal - Refitting**, page **17A-1**).
- Connect the injector connectors.
- Using the **Diagnostic tool**, check that there are no faults stored in the computer.
- Start the vehicle.

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K9K, and STANDARD HEATING RECIRCULATION

### Equipment required

offset spanner

### Tightening torques

new accessories belt	40 N.m
tensioning roller bolt	

### WARNING

Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.

### WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front wheel arch side liner,
  - the front right-hand wheel arch liner partially (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the plastic shield underneath the diesel filter.


### II - OPERATION FOR REMOVAL OF PART CONCERNED

#### Auto tensioner



118158

- Turn the accessories belt tensioning roller clockwise at (2) using a **16 mm offset spanner**.
- Remove the accessories belt.



135490

- Remove:
  - the accessories belt tensioning roller bolt (3),
  - the accessories belt tension wheel.

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K9K, and STANDARD HEATING RECIRCULATION

### REFITTING

#### I - REFITTING PREPARATION OPERATION

##### WARNING

Only use brushes with plastic or non-corrosive metal (brass) bristles.

- Use a brush to remove any deposits from the crankshaft accessories pulley V-grooves.
- parts always to be replaced: Accessories belt**
- parts always to be replaced: Accessories belt tensioning roller**
- parts always to be replaced: Accessories tensioning roller bolt**

#### II - REFITTING OPERATION FOR PART CONCERNED

- Refit a new accessories belt tensioning roller.

##### Auto tensioner

- Torque tighten the **new accessories belt tensioning roller bolt (40 N.m)**.
- Refit a new accessories belt.
- Rotate the crankshaft clockwise through two revolutions (timing end).

#### III - FINAL OPERATION

- Refit:

- the front right-hand wheel arch liner (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
- the front wheel arch side liner,
- the plastic shield underneath the diesel filter,
- the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K9K, and AIR CONDITIONING

### Tightening torques

tensioning roller bolt	40 N.m
------------------------	--------

### WARNING

Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.

### WARNING


In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch side liner,
  - the front right-hand wheel arch liner partially (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the plastic shield underneath the diesel filter.

### II - REMOVAL OPERATION



101878

- Rotate the accessories belt auto tensioner clockwise using a **16 mm** offset wrench.
- Remove:
  - the accessories belt,
  - the accessories belt tension wheel.

## REFITTING

### I - REPAIR PREPARATION OPERATION

- parts always to be replaced: Accessories belt.**
- parts always to be replaced: Accessories belt tensioning roller**
- parts always to be replaced: Accessories tensioning roller bolt**

### WARNING

Only use brushes with plastic or non-corrosive metal (brass) bristles.

- To remove all deposits, use a brush to clean the grooves of:
  - the crankshaft pulley,
  - the air conditioning compressor pulley,
  - the alternator pulley,
- Refit a new tensioning roller fitted with a new bolt.
- Tighten to torque the **tensioning roller bolt (40 N.m)**.


# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K9K, and AIR CONDITIONING

### II - REFITTING OPERATION FOR PART CONCERNED



101878

- Rotate the tensioning roller clockwise using a **16 mm** offset wrench.
- Refit a new accessories belt.
- Turn the crankshaft two revolutions clockwise (timing end) to position the accessories belt correctly.

### III - FINAL OPERATION

- Refit:
  - the front right-hand wheel arch liner (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the front right-hand wheel arch side liner,
  - the plastic shield underneath the diesel filter,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

### Tightening torques

the automatic tensioning roller mounting bolts	<b>21 N.m</b>
the fixed roller mounting bolt	<b>21 N.m</b>

### IMPORTANT

Wear cut-resistant gloves during the operation.


### WARNING

Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).



- Remove the front right-hand wheel arch side liner (3)

### II - REMOVAL OPERATION



- Turn the accessories belt auto tensioner anti-clockwise using a spanner (4) (16 mm), to relax the belt.
- Lock the auto tensioner using a 6 mm Allen key (5).
- Remove:
  - the accessories belt,
  - the auto tensioner bolts,
  - the auto tensioner,
  - the fixed roller bolt,
  - the fixed roller.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: **Accessories belt**
- parts always to be replaced: Accessories belt tensioning roller**
- parts always to be replaced: Accessories fixed roller**
- Use a brush to remove any deposits from the crankshaft pulley V-grooves.

### II - REFITTING OPERATION

- Refit:
  - a new fixed roller,
  - a new automatic tensioner.

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

- Torque tighten:
  - **the automatic tensioning roller mounting bolts (21 N.m),**
  - **the fixed roller mounting bolt (21 N.m).**
- Turn the accessories belt auto tensioner clockwise using a **16 mm** spanner.
- Lock the auto tensioner using a **6 mm** Allen key.
- Refit a new accessories belt.
- Unlock the auto tensioner.
- Turn the crankshaft two revolutions clockwise to position the accessories belt correctly.

### III - FINAL OPERATION

- Proceed in the reverse order to removal.

Dacia Duster Explorers UK

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

K4M, and STANDARD HEATING RECIRCULATION

### Tightening torques

auto tensioner bolts	40 N.m
----------------------	--------

### IMPORTANT

Wear cut-resistant gloves during the operation.


### WARNING

Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).



144752

- Remove the front right-hand wheel arch side liner (3).

### II - REMOVAL OPERATION



118158

118158

- Pivot the accessories belt auto tensioner clockwise.
- Remove:
  - the accessories belt,
  - the tensioning roller bolt (4),
  - the tensioning roller.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Accessories belt
- parts always to be replaced: Accessories belt tensioning roller
- Use a brush to remove any deposits from the crankshaft pulley V-grooves.

### II - REFITTING OPERATION

- Refit a new tensioning roller.
- Torque tighten the **auto tensioner bolts (40 N.m)**.
- Pivot the accessories belt auto tensioner clockwise.
- Refit a new accessories belt.
- Turn the crankshaft two revolutions clockwise to position the accessories belt correctly.

### III - FINAL OPERATION

- Refit the front right-hand wheel arch side liner.

# TOP AND FRONT OF ENGINE

## Accessories belt: Removal - Refitting

# 11A

---

K4M, and STANDARD HEATING RECIRCULATION

---

- Refit the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

Dacia Duster Explorers UK

# TOP AND FRONT OF ENGINE

## Crankshaft accessories pulley: Removal - Refitting

# 11A

K9K

### Special tooling required

**Mot. 1489** TDC locating pin.

### Tightening torques

accessories pulley bolt **120 N.m + 95° ±15°**

TDC pin plug **25 N.m**

### IMPORTANT

Wear cut-resistant gloves during the operation.

### WARNING


Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch side liner,
  - the front right-hand wheel arch partially (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the plastic shield underneath the diesel filter,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page **11A-2**).

### II - REMOVAL OPERATION



135413



109938

- Remove:
  - the crankshaft accessories pulley bolt (2), locking the flywheel using a large screwdriver (1),
  - the crankshaft accessories pulley (3).

# TOP AND FRONT OF ENGINE

## Crankshaft accessories pulley: Removal - Refitting

# 11A

K9K

### REFITTING


#### I - REFITTING PREPARATION OPERATION

- ❑ parts always to be replaced: Crankshaft accessories pulley bolts.


#### WARNING

Only use brushes with plastic or non-corrosive metal (brass) bristles.


- ❑ If reusing the crankshaft accessories pulley, clean the crankshaft accessories pulley V-grooves with a brush to eliminate any deposits.



- ❑ Refit the old crankshaft accessories pulley bolt (4) with a spacer (5) .
- ❑ Turn the crankshaft clockwise (timing end) using the old bolt of the crankshaft accessories pulley, until the collet (6) of the crankshaft timing pin is almost vertical and facing upwards.



- ❑ Remove the TDC setting pin plug (7) .




- ❑ Screw the TDC setting pin (**Mot. 1489**) (8) into the cylinder block.
- ❑ Remove the old bolt from the crankshaft accessories pulley fitted with its spacer.

#### II - REFITTING OPERATION

- ❑ Refit the accessories crankshaft pulley with a new bolt.

K9K



14489

- Turn the crankshaft clockwise (timing end) smoothly using the bolt of the crankshaft accessories pulley, until the crankshaft presses against the tool (**Mot. 1489**) (9) .
- Torque and angle tighten (with the crankshaft in contact with the TDC setting pin) the **accessories pulley bolt (120 N.m + 95° ±15°)**.
- Remove the TDC setting rod (**Mot. 1489**).

### III - FINAL OPERATION

- Apply a drop of **silicone adhesive sealant** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the thread of the TDC setting pin plug.
- Torque tighten the **TDC pin plug (25 N.m)**.
- Refit:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page **11A-2**) ,
  - the front right-hand wheel arch side liner,
  - the front right-hand wheel arch (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the plastic shield underneath the diesel filter,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

K4M

### Tightening torques

new crankshaft accessories pulley bolt	40 N.m + 145° ± 15°
TDC pin plug	25 N.m


### IMPORTANT

Wear cut-resistant gloves during the operation.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the air inlet duct,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2),
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2).



14491


- Pierce the centre of the plugs (1) at the camshaft ends with a screwdriver.
- Remove:
  - the plugs from the camshaft ends with a screwdriver,
  - the TDC setting pin plug (2).



14491-1


- Position the camshaft grooves (3) almost horizontally and offset towards the bottom turning the crankshaft in the operating direction (clockwise at timing end).
- Screw in the TDC setting pin (4).

K4M



14489


- Turn the crankshaft in its operating direction (clockwise at timing end), until the crankshaft presses against the TDC setting pin.



14490

- The camshaft grooves (5) must be horizontal and offset downwards.
- Remove the TDC setting pin.
- Lock the flywheel using a screwdriver.

### II - REMOVAL OPERATION



14487

- Remove the crankshaft accessories pulley bolt (6).

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Crankshaft accessories pulley bolts
- 

#### WARNING


Be sure to degrease:

- the end of the crankshaft,
- the bearing face of the crankshaft accessories pulley.

This is to prevent timing slippage.


## Crankshaft accessories pulley: Removal - Refitting

K4M




145073

- Position the setting tool.
- Secure the ends of the camshafts using an M6 bolt (7) .



14489-2

- Screw in the TDC setting pin (8) .
- Check that the crankshaft is pressing against the TDC tool.
- The crankshaft groove must be upwards.



130493

- If the crankshaft is not pressing against the TDC tool, bring the crankshaft back by turning the fly-wheel using a screwdriver (9) .

## II - REFITTING OPERATION

- Refit the crankshaft accessories pulley.
- Torque and angle tighten the **new crankshaft accessories pulley bolt (40 N.m + 145° ± 15°)**.

## III - FINAL OPERATION

- Remove:
  - the TDC tool,
  - the setting tool.
- Refit:
  - a new inlet camshaft plug using the,
  - a new exhaust camshaft plug using the.
- Place a drop of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) on the threading of the TDC pin plug.
- Refit the TDC setting pin plug.
- Torque tighten the **TDC pin plug (25 N.m)**.
- Refit:
  - the accessories belt (see 11A, **Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),

# TOP AND FRONT OF ENGINE

## Crankshaft accessories pulley: Removal - Refitting

# 11A

K4M

- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page **12A-2**),
  - the air inlet duct.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

Tightening torques 	
timing fixed roller bolt	50 N.m
new crankshaft accessories pulley bolt	40 N.m + 145° ± 15°
timing tension wheel nut	27 N.m
lower timing cover bolts	12 N.m
nut of each camshaft sprocket	30 N.m + 84° ± 4°
TDC pin plug	20 N.m
upper timing cover bolts	46 N.m
upper timing cover nuts	46 N.m
flywheel end lifting eye bolts	10 N.m


### IMPORTANT

Wear cut-resistant gloves during the operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the air inlet duct,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the crankshaft accessories pulley (see **11A, Top and front of engine, Crankshaft accessories pulley: Removal - Refitting**, page 11A-10) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) .



14487

### Remove:

- the upper timing cover bolts (1) ,
- the upper timing cover,
- the lower timing cover bolts (2) ,
- the lower timing cover.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

### II - REMOVAL OPERATION



- Loosen the nut (3) of the timing tensioning roller.

Note:

Do not drop the crankshaft timing sprocket when removing the timing belt.

- Remove:
  - the timing fixed roller bolt (4) using the tool (1) ,
  - the timing fixed roller,
  - the timing belt,
  - the timing tensioning roller nut,
  - the timing tensioning roller,
  - the crankshaft timing sprocket.

### REFITTING - PROCEDURE 1

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Timing belt,
- parts always to be replaced: Timing belt tensioning roller,
- parts always to be replaced: Crankshaft accessories pulley bolts,
- parts always to be replaced: Inlet camshaft cap,
- parts always to be replaced: Timing fixed roller,
- parts always to be replaced: Exhaust camshaft cap.

### II - REFITTING OPERATION FOR PART CONCERNED

- The first procedure applies to replacing any timing face component which has a crankshaft timing sprocket without a collet and which does not require one or more of the camshaft sprockets to be loosened.

#### 1 - Adjusting the timing

□

#### WARNING


Be sure to degrease:

- the end of the crankshaft (timing end),
- the timing sprocket pressure faces and bore of the crankshaft,
- the crankshaft accessories pulley bearing faces,
- the camshaft ends (timing end),
- the camshaft sprocket bores and bearing faces.

This is to avoid timing slippage.

This slippage leads to engine damage.

- Set the camshaft grooves horizontally and below the centre line by turning the camshafts with their necessary.




- Fit:
  - the (5) onto the ends of the camshafts,
  - a lifting eye bolt (6) to secure the.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K4M




- ❑ Position the RENAULT badge (7) engraved on the stem of each camshaft sprocket vertically and pointing upwards.


### 2 - Refitting



- ❑ Refit a new timing tensioning roller by positioning the lug of the timing tensioning roller in the groove (8) .
- ❑ Screw on the timing tensioning roller nut without tightening it.



- ❑ Refit:
  - the crankshaft timing sprocket (9) ,
  - a new timing belt,
  - a new timing fixed roller (10) .




- ❑ Torque tighten the **timing fixed roller bolt (50 N.m)** using the tool.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M



103263


- Position the adjustable index (11) opposite the mark (12) , by turning the eccentric (13) clockwise using a 6 mm Allen key.
- Torque tighten the **timing tensioning roller nut (7 N.m)**.
- Refit the toolon the cylinder block.

Note:

There are two types of lower timing cover:

- without a timing flap,
- with a timing flap.

### a - Lower timing cover with a timing flap



130497

- Refit the lower timing cover (14) .
- Tighten to torque the **lower timing cover bolts (12 N.m)**.

### b - continuation of the refitting procedure regardless of the type of lower timing cover


- Refit a new crankshaft accessories pulley.

# TOP AND FRONT OF ENGINE


## Timing belt: Removal - Refitting

# 11A

K4M




130493



14489

- Use a screwdriver (15) to check that the flywheel does not turn (clockwise at the timing end), otherwise bring the crankshaft back into contact with the tool (16) using the screwdriver; the crankshaft groove should be at the top.
- Torque and angle tighten a **new crankshaft accessories pulley bolt (40 N.m + 145° ± 15°)** (crankshaft in contact with the tool).

### c - Lower timing cover with a timing flap



109052

- Remove the timing flap from the lower timing cover.

### d - continuation of the refitting procedure regardless of the type of lower timing cover

- Remove:
  - the bolt of the tool,
  - the setting tool,
  - the from the cylinder block.

### 3 - Checking the tension


- Rotate the crankshaft twice clockwise at the timing end and before aligning the marks made previously by the operator (on the camshaft dephaser), screw the tool into the cylinder block.
- Move the crankshaft slowly and smoothly until it comes into contact with the tool.
- Remove the tool from the cylinder block.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M




103263

- Check that the adjustable index (17) is opposite the notch (18), if this is not the case:
  - loosen the timing tensioning roller nut by up to one turn while holding the eccentric with a **6 mm** Allen key,
  - gradually move the adjustable index marker (17) opposite the mark (18) turning the eccentric cam (19) clockwise.
- Torque tighten the **timing tension wheel nut (27 N.m)**.

#### 4 - Checking the timing

- Ensure that the index and the notch on the timing tensioning roller are in the correct position before checking the timing.
- Screw tool into the cylinder block.
- Move the crankshaft slowly and smoothly until it comes into contact with the tool.



14490

- Position (without forcing) the camshaft setting tool (the camshaft end grooves must be horizontal and offset towards the bottom).

#### Note:

The timing adjustment and tensioning operation must be repeated if the camshaft setting tool does not engage.

- Remove:
  - the setting tool,
  - the from the cylinder block.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

### a - Lower timing cover with a timing flap



- ❑ Refit the lower timing cover flap, checking that the locating pin (20) fits properly in the notch (21).

### b - Lower timing cover without a timing flap

- ❑ Refit the lower timing cover.
- ❑ Tighten to torque the **lower timing cover bolts (12 N.m)**.


## REFITTING -PROCEDURE 2

### I - REFITTING PREPARATION OPERATION

- ❑ parts always to be replaced: Timing belt,
- ❑ parts always to be replaced: Timing belt tensioning roller,
- ❑ parts always to be replaced: Timing fixed roller,
- ❑ parts always to be replaced: Crankshaft accessories pulley,
- ❑ parts always to be replaced: camshaft timing sprocket nut,
- ❑ parts always to be replaced: Crankshaft accessories pulley bolts,
- ❑ parts always to be replaced: Inlet camshaft cap,
- ❑ parts always to be replaced: Exhaust camshaft cap.

### II - REFITTING OPERATION

- ❑ The second procedure is used when replacing any timing face component which has a crankshaft timing sprocket with or without a collet, that requires one or more of the camshaft sprockets to be loosened.



- ❑ Fit the tool on the camshaft sprockets using the tool.
- ❑ Loosen the nuts (22) of each camshaft sprocket.
- ❑ Remove:
  - the tool from the cylinder block,
  - every camshaft sprocket nut,
  - the camshaft sprockets.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

### 1 - Adjusting the timing

□

Note:

If the stud loosens with the nut (see 11A, **Top and front of engine, Camshaft: Removal - Refitting**, page 11A-49) (11A, Top and front of engine).


#### WARNING

Always degrease:


- the end of the crankshaft (timing end),
- the timing sprocket pressure faces and bore of the crankshaft,
- the crankshaft accessories pulley bearing faces,
- the camshaft ends (timing end),
- the camshaft sprocket bores and bearing faces.

This is to avoid timing slippage.

This slippage leads to engine damage.



14490



145072


- Position the camshaft grooves horizontally and below the centre line, by turning the camshafts with their necessary.

# TOP AND FRONT OF ENGINE


## Timing belt: Removal - Refitting

# 11A

K4M



145073




130493

### Fit:

- the (23) onto the ends of the camshafts,
- an M6 bolt (24) to hold the.

### Refit:

- the crankshaft timing sprocket,
- the camshaft sprockets,
- every camshaft sprocket nut.



14489

14489


- Fit the tool on the cylinder block.
- Use a screwdriver (25) to check that the flywheel does not turn (clockwise at the timing end), otherwise bring the crankshaft back into contact with the tool (26) using the screwdriver; the crankshaft groove should be at the top.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A


K4M



14487-3


- ❑ Position the RENAULT badge (27) etched on the stem of each camshaft sprocket vertically and pointing upwards.

### 2 - Refitting



108879

- ❑ Refit a new timing tensioning roller by positioning the lug of the timing tensioning roller in the groove (28).
- ❑ Screw on the timing tensioning roller nut without tightening it.



135896

- ❑ Refit a new timing belt starting with the sprocket of each camshaft (without moving the sprocket of each camshaft).
- ❑ Fit the tool (29) on the camshaft sprockets (use the bolt and nut of the upper timing cover to fit the tool).

#### Note:

Take care to properly tighten the timing belt between the two camshaft sprockets.

#### Note:


If the engine is equipped with a crankshaft timing sprocket with a collet, take care to properly tighten the timing belt between the exhaust camshaft sprocket and the crankshaft timing sprocket.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A


K4M



14487-2

- Refit a new timing fixed roller.
- Torque tighten the **timing fixed roller bolt (50 N.m)** using the tool.

### 3 - Timing belt tension



103263

- Position the adjustable index (30) opposite the mark (31), by turning the eccentric (32) clockwise using an Allen key.


- Torque tighten the **timing tensioning roller nut (7 N.m)**.

Note:

There are two types of lower timing cover:

- without a timing flap,
- with a timing flap.

### a - Lower timing cover with a timing flap



130497

- Refit the lower timing cover (33).
- Tighten to torque the **lower timing cover bolts (12 N.m)**.

### b - continuation of the refitting procedure regardless of the type of lower timing cover

- Refit a new crankshaft accessories pulley.
- Torque and angle tighten:
  - the **new bolt of the crankshaft accessories pulley (40 N.m + 145° ± 15°)**,
  - the **nut of each camshaft sprocket (30 N.m + 84° ± 4°)**.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

### c - Lower timing cover with a timing flap



109052


- ❑ Remove the timing flap from the lower timing cover.

### d - continuation of the refitting procedure regardless of the type of lower timing cover

- ❑ Remove:
  - the bolt of the tool,
  - the,
  - the tool from the cylinder block,
  - the.


### 4 - Checking the tension

- ❑ Rotate the crankshaft twice clockwise at the timing end and before aligning the marks made previously by the operator (on the camshaft dephaser), screw the tool into the cylinder block.
- ❑ Move the crankshaft slowly and smoothly until it comes into contact with the tool.
- ❑ Remove the tool from the cylinder block.



109051

109051



103263

103263

- ❑ Check that the adjustable index (34) is opposite the notch (35), if this is not the case:
  - loosen the timing tensioning roller nut by up to one turn while holding the eccentric with an Allen key,
  - gradually move the adjustable index marker (34) opposite the mark (35) turning the eccentric cam (36) clockwise.
- ❑ Torque tighten the timing tensioning roller nut (27 N.m).

# TOP AND FRONT OF ENGINE


## Timing belt: Removal - Refitting

# 11A

K4M

### 5 - Checking the timing

- Ensure that the index and the notch on the timing tensioning roller are in the correct position before checking the timing.
- Screw tool into the cylinder block.
- Move the crankshaft slowly and smoothly until it comes into contact with the tool.



14490


- Position (without forcing) the (the camshaft end grooves must be horizontal and offset downwards).

#### Note:

If the cannot be engaged, readjust the timing and the tension.

- Remove:
  - the setting tool,
  - the from the cylinder block.

### a - Lower timing cover with a timing flap



109052

- Refit the lower timing cover flap, checking that the locating pin (37) fits properly in the notch (38) .

### b - Lower timing cover without a timing flap

- Refit the lower timing cover.
- Tighten to torque the **lower timing cover bolts (12 N.m)**.

### III - FINAL OPERATION

- Apply a drop of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the thread of the TDC pin plug.
- Tighten to torque the **TDC pin plug (20 N.m)**.
- Refit the upper timing cover.
- Torque tighten:
  - the **upper timing cover bolts (46 N.m)**,
  - the **upper timing cover nuts (46 N.m)**.
- Refit:
  - a new inlet camshaft plug using the,
  - a new exhaust camshaft plug using the,
  - the engine lifting eye at the flywheel end.
- Torque tighten the **flywheel end lifting eye bolts (10 N.m)**.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K4M

Refit:

- the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page **19D-4**),
- the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page **11A-2**),
- the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page **12A-2**),
- the air inlet duct.

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K9K, and 796

### Special tooling required

<b>Mot. 1453</b>	Engine anchorage support with multiple adjustments and retaining straps.
<b>Mot. 1489</b>	TDC locating pin.
<b>Mot. 1430</b>	Set of 5 crankshaft and camshaft pulley timing pins.

### Tightening torques

timing belt tensioning roller bolt	<b>27 N.m</b>
accessories pulley M14 bolt	<b>120 N.m + 95° ± 15°</b>
timing belt tensioning roller bolt	<b>27 N.m</b>
TDC pin plug	<b>25 N.m</b>
right-hand suspended engine mounting bolts	<b>25 N.m</b>

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Engine: Precautions for the repair**).

### IMPORTANT

Wear protective gloves during every operation.

### WARNING

Never run the engine in the opposite direction to that of normal operation.


### WARNING

Do not run the engine without the accessories belt to avoid damaging the crankshaft accessories pulley.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).



145071  
145071



24754  
24764


- Fit the engine support tool (**Mot. 1453**) with the retaining belt, taking the timing end lifting eye as an anchoring point.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K9K, and 796




145429

- Mark the position of the suspended engine mounting in relation to the body.
- Remove:
  - the right-hand suspended engine mounting (see 19D, **Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the camshaft position sensor (1) (see 13B, **Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,
  - the accessories belt (see 11A, **Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .



136656



136654


- Remove:
  - the bolt (3) from the upper timing cover,
  - the upper timing cover by unclipping the three tabs (2) .

# TOP AND FRONT OF ENGINE


## Timing belt: Removal - Refitting

# 11A

K9K, and 796




136660



136662


- Unclip the three tabs (4) .
- Remove the lower timing cover.



136658

- Remove:
  - the bolts (5) from the right-hand suspended engine mounting support on the cylinder head,
  - the right-hand pendulum suspension support.

### II - REMOVAL OPERATION



19650

19650


- Remove the TDC pin plug (6) using a 14 female torx socket.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K9K, and 796



19702


- Turn the crankshaft to position the camshaft pulley hole (7) almost opposite the cylinder head hole (8) .



14489

14489


- Turn the crankshaft clockwise (timing end) smoothly until the crankshaft is against the **(Mot. 1489)**.



19650-1

19650-1

- Screw tool **(Mot. 1489)** (9) into the cylinder block.



19655


- Insert the **(Mot. 1430)** (10) in the holes of the camshaft pulley and cylinder head.
- Remove:
  - the **(Mot. 1430)**,
  - the **(Mot. 1489)**.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A


K9K, and 796



109938

Remove:

- the bolt (11) from the crankshaft accessories pulley, locking the flywheel using a large screwdriver,
- the crankshaft accessories pulley.



109937

Undo the timing belt tensioning roller bolt (12) .

- Loosen the timing belt tensioning roller by turning the eccentric cam using a **6 mm** Allen key.

Remove:

- the timing belt taking care not to let the crankshaft timing sprocket fall out.

- the timing belt tensioning roller.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

#### WARNING

The belt must be replaced with a new one if it has been removed.

#### WARNING

When replacing the belt, always replace the tension wheels and idler pulleys.

#### WARNING

Always degrease:

- the end of the crankshaft (timing end),
- the timing sprocket pressure faces and bore of the crankshaft,
- the contact surfaces of the crankshaft accessories pulley.

This is to avoid timing slippage.

This slippage leads to engine damage.

#### II - PARTS AND CONSUMABLES FOR THE REPAIR

- parts always to be replaced: Crankshaft accessories pulley bolts,
- parts always to be replaced: Timing belt tensioning roller,
- parts always to be replaced: Timing belt.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A


K9K, and 796

### III - REFITTING OPERATION



19656-2

- ❑ Refit:
  - the crankshaft timing sprocket,
  - a new timing belt tensioning roller.
- ❑ Put the tensioning roller lug (13) in the cylinder head groove (14) .
- ❑ Engage the (Mot. 1430) in the camshaft pulley hole and the cylinder head hole at (15) , turning the camshaft using an 18 mm offset wrench if necessary.
- ❑ Check that high-pressure pump pulley marking (16) is opposite the bolt head (17) .



14489


- ❑ Refit the (Mot. 1489).
- ❑ Place the crankshaft against the (Mot. 1489) (the crankshaft groove (18) must be upwards).

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K9K, and 796




19657

- ❑ Fit the new timing belt, starting with the crankshaft sprocket, aligning the marks on the belt with those on the camshaft and high pressure pump pulleys.

### Note:

There must be **19 timing belt tooth grooves** between the marks of the camshaft and high pressure pump pulleys and **51 timing belt tooth grooves** between the marks of the crankshaft timing sprocket and the high pressure pump pulley.



19658


- ❑ Position the timing belt tensioning roller adjustable index opposite the lug (19) by turning the eccentric cam anti-clockwise using a **6 mm** Allen key.
- ❑ Torque tighten the **timing belt tensioning roller bolt (27 N.m)**.
- ❑ Refit the accessories crankshaft pulley with a new bolt.
- ❑ Torque and angle tighten (crankshaft against the (Mot. 1489)) the **accessories pulley M14 bolt (120 N.m + 95° ± 15°)**.
- ❑ Remove:
  - the (Mot. 1430),
  - the (Mot. 1489).

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K9K, and 796



19702

- Rotate the crankshaft clockwise through two revolutions (timing end).
- Before the camshaft pulley hole (20) is opposite the cylinder head hole (21), screw the (Mot. 1489) into the cylinder block.
- Bring the crankshaft slowly and smoothly into contact with the tool (Mot. 1489).



19655

- Set the camshaft pulley using the (Mot. 1430).

Note:

There should be **19 belt tooth grooves** between the marks on the camshaft pulley (22) and the high pressure pump pulley (23).

- Remove:
  - the (Mot. 1489),
  - the (Mot. 1430).

Note:

After rotating the crankshaft through two revolutions, the tensioning roller adjustable index may be in one of two positions.

The rotation of the tension wheel eccentric depends on the position.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K9K, and 796

### 1 - First position



111083



111081

- Loosen the tensioning roller bolt by no more than one turn, holding it with a **6 mm Allen key**.
- Gradually align the adjustable index marker (**24**) in the middle of the timing window (**25**), turning the key anti-clockwise.


# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting


# 11A

K9K, and 796

### 2 - Second position



111082




111081

- Loosen the tensioning roller bolt by one turn, holding it with a **6 mm** Allen key.
- Gradually align the adjustable index marker (26) in the middle of the timing window (27), turning the key clockwise.
- Torque tighten the **timing belt tensioning roller bolt (27 N.m)**.
- Rotate the crankshaft clockwise through two revolutions (timing end).
- Before the camshaft pulley hole is opposite the cylinder head hole, screw the **(Mot. 1489)** into the cylinder block.

der block.

- Bring the crankshaft slowly and smoothly into contact with the tool **(Mot. 1489)**.



19655

- Set the camshaft pulley using the **(Mot. 1430)**.
- If the tool **(Mot. 1430)** does not engage, repeat the timing belt refitting operation.
- Remove:
  - the **(Mot. 1489)**,
  - the **(Mot. 1430)**.

### IV - FINAL OPERATION


- Place a drop of **SILICONE ADHESIVE SEALANT** (see **Vehicle: Parts and consumables for the repair**) on the threading of the TDC pin plug.
- Torque tighten the **TDC pin plug (25 N.m)**.
- Refit the right-hand suspended engine mounting support on the cylinder head.
- Torque tighten the **right-hand suspended engine mounting bolts (25 N.m)**.

# TOP AND FRONT OF ENGINE

## Timing belt: Removal - Refitting

# 11A

K9K, and 796



19659

- Refit the lower timing cover, positioning the tab (28) in the opening (29) on the inner cover.
- Clip on the lower timing cover.
- Refit:
  - the upper timing cover,
  - the upper timing cover bolt.
- Clip on the upper timing cover.
- Refit:
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) , observing the marks made during removal.
- Remove the engine support tool (**Mot. 1453**).
- Refit the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K4M

Tightening torques 	
rocker cover bolts 22, 23, 20 and 13	8 N.m
rocker cover bolts 1 to 12, 14 to 19, 21 to 24	15 N.m
rocker cover bolts 22, 23, 20 and 13	15 N.m
flywheel end lifting eye bolts on the rocker cover	11 N.m

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11) ,
  - the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page 12A-12) ,
  - the timing end camshaft seals (see **11A, Top and front of engine, Camshaft seal, timing end: Removal - Refitting**, page 11A-56) ,
  - the ignition coils (see **17A, Ignition, Coils: Removal - Refitting**, page 17A-1) ,
  - the oil decanter (see **11A, Top and front of engine, Oil decanter: Removal - Refitting**, page 11A-68) ,
  - the flywheel end lifting eye on the rocker cover.


# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K4M

### II - REMOVAL OPERATION



14497

14497

- Remove the rocker cover bolts.
- Remove the rocker cover vertically by tapping the lugs (1) with a copper hammer.
- Remove the rocker cover.

# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K4M

### REFITTING

#### I - REFITTING PREPARATION OPERATION



##### IMPORTANT

Wear cut-resistant gloves during the operation.

##### IMPORTANT

Wear goggles with side protectors for this operation.

##### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

##### WARNING

Do not allow this product to drip onto the paintwork.

Clean the cylinder head carefully to prevent foreign bodies from entering the oil supply and return galleries.

Failure to follow this advice could lead to the blocking of the various oil inlet galleries, which would quickly result in engine damage.

##### Note:

The gasket faces on the rocker cover must be clean, dry and free from grease (avoid finger marks).

- Clean the gasket face of the rocker cover and cylinder head with **SUPER CLEANING AGENT FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to dissolve any pieces of seal that are still attached.
- Apply the product to the section to be cleaned.
- Wait approximately fifteen minutes, then remove any residue with a wooden spatula.
- Lubricate the cylinder head camshaft bearings with engine oil.




##### WARNING

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.)

##### Note:

Do not put oil on the gasket face of the cylinder head cover.



14517

14517

- Using a stipple roller, apply **RESIN ADHESIVE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the gasket face until it is well coated.




# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K4M

### II - REFITTING OPERATION



14497

- Refit the rocker cover.
- Tighten to torque and in order:
  - **rocker cover bolts 22, 23, 20 and 13 (8 N.m)**,
  - **rocker cover bolts 1 to 12, 14 to 19, 21 to 24 (15 N.m)**.
- Loosen bolts 22, 23, 20 and 13, in order.
- Torque tighten in order **rocker cover bolts 22, 23, 20 and 13 (15 N.m)**.

### III - FINAL OPERATION

- Refit the flywheel end lifting eye.
- Torque tighten the **flywheel end lifting eye bolts on the rocker cover (11 N.m)**.
- Refit:
  - the oil decanter (see **11A, Top and front of engine, Oil decanter: Removal - Refitting, page 11A-68**) ,
  - the ignition coils (see **17A, Ignition, Coils: Removal - Refitting, page 17A-1**) ,

- the camshaft seals (see **11A, Top and front of engine, Camshaft seal, timing end: Removal - Refitting, page 11A-56**) ,
  - the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting, page 12A-12**) ,
  - the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting, page 12A-11**) ,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6**) ,
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting, page 11A-17**) ,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting, page 12A-2**) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2**) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K9K


### Tightening torques

rocker cover bolts	12 N.m
--------------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .



- Remove the oil vapour rebreathing hose (1) .

### II - REMOVAL OPERATION


- Remove:
  - the rocker cover bolts,
  - the rocker cover,
  - the rocker cover seal.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Clean the cylinder head joint face using **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease:
  - the cylinder head joint face,
  - the housing of the rocker cover seal, if reusing.
- parts always to be replaced: rocker cover seal.**


### II - REFITTING OPERATION



### WARNING

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).

- Deposit four beads (1) of **SILICONE ADHESIVE SEALANT** that are **2 mm** in diameter and **10 mm** long.
- Refit:
  - the rocker cover,
  - the rocker cover bolts.



- Torque tighten in order the **rocker cover bolts (12 N.m)**.

# TOP AND FRONT OF ENGINE

## Rocker cover: Removal - Refitting

# 11A

K9K

### III - FINAL OPERATION

- Connect the oil vapour rebreathing pipe.
- Refit the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page **12A-6**).

Dacia Duster Explorers UK

# TOP AND FRONT OF ENGINE

## Camshaft: Removal - Refitting

# 11A

K4M

### Equipment required

roller-type stud removal tool

### Tightening torques

the camshaft dowel	8 N.m
--------------------	-------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11) ,
  - the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page 12A-12) ,
  - the ignition coils (see **17A, Ignition, Coils: Removal - Refitting**, page 17A-1) ,
  - the rocker cover (see **11A, Top and front of engine, Rocker cover: Removal - Refitting**, page 11A-42) ,
  - the timing end camshaft seals (see **11A, Top and front of engine, Camshaft seal, timing end: Removal - Refitting**, page 11A-56) .


# TOP AND FRONT OF ENGINE

## Camshaft: Removal - Refitting

# 11A

K4M


### II - REMOVAL OPERATION



#### □ Remove:

- the inlet camshaft (1) ,
- the exhaust camshaft (2) .

K4M



- Remove:
  - the valve rockers (3) ;
  - the hydraulic tappets (4) .

Note:

To prevent any risk of unpriming the hydraulic tappets make sure that they are vertical.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Refit the camshafts while positioning them correctly (see ) (Technical Note 6023A, 10A, Engine and peripherals).

Note:

It is essential to reprime the hydraulic tappets as these may become drained if removed for a long time.

- To check if re-priming is necessary, press the top of the tappet with your thumb. If the tappet piston depresses, immerse the tappets in a container full of diesel then reprime them.

### Replacing a camshaft dowel


- 

Note:

It is essential to replace the camshaft dowel if it comes loose at the same time as the nut.

#### a - Removal

- Place the camshaft in a vice with **aluminium jaws**.



- Remove the dowel using a **roller-type stud removal tool (5)** .

#### b - Cleaning the camshaft

- 

Note:


Clean the thread hole of the camshaft carefully to prevent foreign bodies from entering the latter.

Failure to follow this advice could lead to the blocking of the oil inlet holes, which would quickly result in engine damage.

#### c - Refitting

- Place the camshaft in a vice with **aluminium jaws**.

K4M



- Refit the new camshaft dowel (precoated section (7) on the camshaft side).
- Torque tighten the camshaft dowel (8 N.m) using a roller-type stud removal tool (6) .

### II - REFITTING OPERATION

- Refit:
  - the hydraulic tappets,
  - the valve rockers,
  - the inlet camshaft, by lubricating the inlet camshaft bearings,
  - the exhaust camshaft, by lubricating the exhaust camshaft bearings.

### III - FINAL OPERATION

- Refit:
  - the rocker cover (see 11A, Top and front of engine, Rocker cover: Removal - Refitting, page 11A-42) ,
  - the camshaft seals (see 11A, Top and front of engine, Camshaft seal, timing end: Removal - Refitting, page 11A-56) ,
  - the ignition coils (see 17A, Ignition, Coils: Removal - Refitting, page 17A-1) ,
  - the inlet distributor (see 12A, Fuel mixture, Inlet distributor: Removal - Refitting, page 12A-12) ,
  - the throttle valve (see 12A, Fuel mixture, Throttle valve: Removal - Refitting, page 12A-11) ,

- the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6) ,
- the timing belt (see 11A, Top and front of engine, Timing belt: Removal - Refitting, page 11A-17) ,
- the air resonator (see 12A, Fuel mixture, Air resonator: Removal - Refitting, page 12A-2) ,
- the right-hand suspended engine mounting (see 19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting, page 19D-4) ,
- the accessories belt (see 11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2) ,
- the front right-hand wheel (see Wheel: Removal - Refitting) (35A, Wheels and tyres).

- Connect the battery (see Battery: Removal - Refitting) (80A, Battery).

# TOP AND FRONT OF ENGINE

## Camshaft: Removal - Refitting

# 11A

K9K


### Tightening torques

bolts of the camshaft bearings	10 N.m
--------------------------------	--------

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the air filter box (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch liner partially (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the engine undertray bolts,
  - the engine undertray,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,
  - the crankshaft accessories pulley (see **11A, Top and front of engine, Crankshaft accessories pulley: Removal - Refitting**, page 11A-10) ,
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the vacuum pump (see **Vacuum pump: Removal - Refitting**) (37A, Mechanical component controls),
  - the rocker cover (see **11A, Top and front of engine, Rocker cover: Removal - Refitting**, page 11A-42) .



118982

- Increase the hole (1) of the (2) using an **8.5 mm** drill bit.



118983

- Undo the camshaft pulley hub bolts (3) .
- Fit then the cylinder head to lock the camshaft pulley wheel.
- Tighten the camshaft pulley hub bolts (3) .
- Remove:
  - the nut (4) from the camshaft pulley,
  - the,
  - the camshaft pulley.


# TOP AND FRONT OF ENGINE

## Camshaft: Removal - Refitting


# 11A

K9K

### II - OPERATION FOR REMOVAL OF PART CONCERNED



113563



113565

- Mark the position of the camshaft bearings.
- Remove:
  - the camshaft bearing bolts (5) ,
  - the camshaft bearings,
  - the camshaft,
  - the timing end camshaft seal.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Camshaft seal on timing end.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).


#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean the bearing faces of the camshaft bearings.

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:

- the bearing faces of the camshaft bearings on the cylinder head,
- the bearing faces of the camshaft bearings on the camshaft bearings.



20064-1

- 

#### WARNING

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).

# TOP AND FRONT OF ENGINE

## Camshaft: Removal - Refitting


# 11A

K9K

- ❑ Apply four beads (6) of **RESIN ADHESIVE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) 7 mm in diameter on the cylinder head.

### II - REFITTING OPERATION FOR PART CONCERNED

- ❑ Fit the camshaft in place by placing the camshaft groove on the timing end vertically and facing upwards.
- ❑ Refit the camshaft bearings, observing their original positions (bearing **No. 1** at the flywheel end).



113563

- ❑ Refit the camshaft bearing bolts (1) , (3) , (4) and (2) in order.
- ❑ Tighten the camshaft bearing bolts (1) , (3) , (4) and (2) in order.
- ❑ Refit the camshaft bearing bolts in order.
- ❑ Tighten to torque and in order the **bolts of the camshaft bearings (10 N.m)**.
- ❑ Check and adjust (if necessary) the valve clearance (see **Valves: Adjustment**) .

### III - FINAL OPERATION

- ❑ Refit:
  - the camshaft seal (see **11A, Top and front of engine, Camshaft seal, timing end: Removal - Refitting**, page 11A-56) ,
  - the rocker cover (see **11A, Top and front of engine, Rocker cover: Removal - Refitting**, page 11A-42) ,
  - the vacuum pump (see **Vacuum pump: Removal - Refitting**) (37A, Mechanical component controls),
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,

- the crankshaft accessories pulley (see **11A, Top and front of engine, Crankshaft accessories pulley: Removal - Refitting**, page 11A-10) ,
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the engine undertray,
  - the front right-hand wheel arch liner (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the air filter box (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .
- ❑ Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K4M


### Tightening torques

inlet camshaft hub nut	30 N.m + 84° ± 4°
exhaust camshaft hub nut	30 N.m + 84° ± 4°

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6),
  - the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11),
  - the air inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page 12A-12),
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2),
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17).



135235

- Fit the locking tool (1) on the camshaft pulleys.
- Remove:
  - the inlet camshaft pulley nut (2),
  - the exhaust camshaft pulley nut (3),
  - the,
  - the inlet camshaft pulley,
  - the exhaust camshaft pulley.


# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K4M

### II - REMOVAL OPERATION




105257

□

Note:


The inlet and exhaust camshaft seals are removed using the.

- Always remove the end piece (4) of the tool.
- Loosen bolts (5) and (6) fully from the.




135237

- Position the claws of the tool on the camshaft.



135237

- Push the tool until contact is made between the ends of the claws (7) and the camshaft seal.



145806


- Separate the claws by turning the nut (8) clockwise using an open-jawed spanner.

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K4M



135232

- Remove the camshaft seal by turning the bolt (9) clockwise.
- Repeat the previous operations for the other camshaft seal.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Camshaft seal on timing end
- parts always to be replaced: Exhaust camshaft pulley nut
- Always replace the inlet camshaft pulley nut.

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:


- the seal mating face of each camshaft,
- the camshaft seal housings.

#### Note:

It is strictly forbidden to lubricate the outer diameter of the ring before fitting.

#### II - REFITTING OPERATION

##### Fitting the camshaft seal.



18487

18687

- 

#### Note:


Always hold the camshaft seal with the protector (10) when handling, as this type of seal is very fragile. It is strictly forbidden to touch seal; (11) this is to prevent any oil leaks once the oil seal is fitted to the engine.

# TOP AND FRONT OF ENGINE


## Camshaft seal, timing end: Removal - Refitting

# 11A

K4M




105531  
105531




135231

- Fit the protector fitted with a new seal (13) on the inlet and exhaust camshaft, taking care not to touch the seal.
- Screw on the stud (12) of the toolon the inlet and exhaust camshafts.



135229

- Fit the cover (14) and the collar nut (15) of the.



135229

- Screw on the collar nut until the cover touches the cylinder head.
- Remove:
  - the nut,
  - the cover,
  - the threaded rod (16) .

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K4M

### III - FINAL OPERATION

- Refit:
  - the inlet camshaft pulley with a new nut,
  - the exhaust camshaft pulley with a new nut.
- Fit the locking tool on the camshaft pulleys.
- Torque tighten:
  - the **inlet camshaft hub nut (30 N.m + 84° ± 4°)**,
  - the **exhaust camshaft hub nut (30 N.m + 84° ± 4°)**.
- Remove the locking tool.
- Refit:
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page 12A-12) ,
  - the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11) ,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K9K

### Special tooling required

**Mot. 1430** Set of 5 crankshaft and camshaft pulley timing pins.

### Tightening torques


camshaft stud	12 N.m
camshaft pulley nut	30 N.m + 86° ± 6°.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove the front engine cover.
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the front right-hand wheel arch liner (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the engine undertray bolts,
  - the engine undertray,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4),
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2),
  - the crankshaft accessories pulley (see **11A, Top and front of engine, Crankshaft accessories pulley: Removal - Refitting**, page 11A-10),
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17),
  - the **(Mot. 1430)**.


### II - REMOVAL OPERATION



118982

118982

- Increase the hole (1) of the (2) using an **8.5 mm** drill bit.



118983

118983

- Undo the camshaft pulley hub bolts (3).
- Fit theon the cylinder head to lock the camshaft pulley wheel.
- Tighten the camshaft pulley hub bolts (3).
- Remove:
  - the nut (4) from the camshaft pulley,
  - the,


# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting


# 11A

K9K

- the camshaft pulley.




123970



105270

- Position the claws of the tool on the camshaft.




105257

□

Note:

The camshaft seal is removed using the.

- Remove the camshaft seal (5) making sure that the end piece (6) of the tool is always removed.
- Loosen bolts (7) and (8) fully from the.



105271


- Push the tool until contact is made between the ends (9) of the claws and the camshaft seal.

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting


# 11A

K9K



105272

- ❑ Separate the claws by turning the bolt (10) clockwise using an open-jawed spanner.



105273

- ❑ Remove the camshaft seal by turning the bolt (11) clockwise.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- ❑ Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the camshaft seal housing in the cylinder head,
  - the camshaft seal mating face on the camshaft.

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- ❑ **parts always to be replaced: Camshaft seal on timing end.**
- ❑ **parts always to be replaced: camshaft timing sprocket nut.**
- ❑ **parts always to be replaced: camshaft timing sprocket stud (if loosened).**


# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting


# 11A

K9K

### II - REFITTING OPERATION FOR PART CONCERNED



105531



21687-1


- Screw the stud (12) of the onto the camshaft.
- Fit a new camshaft seal on the camshaft.

#### Note:

For camshaft seals delivered fitted to a protective sleeve:

- do not remove the camshaft seal from its protective sleeve,
- fit the sleeve fitted with the camshaft seal to the camshaft,
- push the protective sleeve towards the cylinder head until the camshaft seal reaches its limit on the cylinder head,
- fit the seal on the camshaft by following the recommendations below.

### 1 - First fitting of the camshaft seal



21687-2


- Fit the cover (13) and the collar nut (14) of the.

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A


K9K



21687-3


- ❑ Screw on the collar nut until the cover touches the cylinder head.

### 2 - Second fitting of the camshaft seal



123076

- ❑ Depending on the case, the Parts Department delivers seals (15) equipped with a spacer (16) amongst other things.



123075

- ❑

Note:


The spacer (17) is used to fit the seal (18) and is used in addition to the tool (19).

# TOP AND FRONT OF ENGINE

## Camshaft seal, timing end: Removal - Refitting

# 11A

K9K




123073

- Position the bell (20) fitted with the spacer on the camshaft seal side and then position the collared nut (21) of the tool.

### Note:

The spacer fits on the bell of the tool so that the internal edge of the spacer is on the side of the camshaft seal.




123074

- Screw on the collar nut until the spacer fitted on the cover touches the cylinder head.

### 3 - Continued for both methods

- Remove:
  - the collar nut from the,
  - the cover from the,
  - the stud of the,
  - the protective sleeve and the spacer, if fitted then throw them away.
- Torque tighten the **camshaft stud (12 N.m)**
- Refit:
  - the camshaft pulley,
  - a new camshaft pulley nut.




116756

116756

- Undo the camshaft pulley hub bolts (22) .
- Fit then the cylinder head to lock the camshaft pulley wheel.
- Tighten:
  - the camshaft pulley hub bolts,
  - to torque and angle the **camshaft pulley nut (30 N.m + 86° ± 6°)**
- Remove the tool.

K9K

III - FINAL OPERATION



107269

- Set the camshaft pulley hub using the tool (**Mot. 1430**).

Note:

If the pin (**Mot. 1430**) does not engage, turn the camshaft pulley hub using an **18 mm** offset wrench to facilitate the setting of the camshaft pulley hub.

- Refit:
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) .
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,
  - the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the engine undertray,
  - the front right-hand wheel arch liner (see **Front wheel arch liner: Removal - Refitting**) (55A, Exterior protection),
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Refit the engine cover.

# TOP AND FRONT OF ENGINE

## Oil decanter: Removal - Refitting

# 11A

K4M

### Tightening torques

new oil separator bolts	15 N.m
-------------------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

Remove:

- the air resonator (see 12A, Fuel mixture, Air resonator: Removal - Refitting, page 12A-2) ,


- the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6) ,

- the throttle valve (see 12A, Fuel mixture, Throttle valve: Removal - Refitting, page 12A-11) ,

- the inlet distributor (see 12A, Fuel mixture, Inlet distributor: Removal - Refitting, page 12A-12) ,

- the ignition coils (see 17A, Ignition, Coils: Removal - Refitting, page 17A-1) .

### II - REMOVAL OPERATION



14497-4

Remove:

- the oil decanter bolts,
- the oil decanter.

# TOP AND FRONT OF ENGINE

## Oil decanter: Removal - Refitting

# 11A

K4M

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: oil decanter bolt

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

#### WARNING

When cleaning parts, it is essential that the parts do not impact on each other, otherwise their mating faces may be damaged and therefore their adjustments may be altered, which could damage the engine.


- Use **SUPER CLEANING AGENT FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean:
  - the oil separator joint face if it is to be re-used,
  - the rocker cover joint face.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease:
  - the oil separator joint face if it is to be re-used,
  - the rocker cover joint face.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

#### WARNING

Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).



14516

- Apply **RESIN ADHESIVE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) using a stipple roller on the joint face of the oil separator until the joint face is completely coated.

#### II - REFITTING OPERATION

- Refit the oil separator.

K4M



14497-4

- Torque tighten in order the **new oil separator bolts (15 N.m)**.

### III - FINAL OPERATION

- Refit:

- the ignition coils (see **17A, Ignition, Coils: Removal - Refitting**, page 17A-1) ,
- the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page 12A-12) ,
- the throttle valve (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11) ,
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .


# FUEL MIXTURE

## Air inlet: Description

# 12A

K4M

Diagram of the air inlet circuit



- |     |                      |
|-----|----------------------|
| (1) | Air inlet trunking   |
| (2) | Air resonator        |
| (3) | Air filter unit      |
| (4) | Air filter           |
| (5) | Throttle valve       |
| (6) | Inlet manifold       |
| (7) | Injector holder shim |
| (8) | Air inlet            |

# FUEL MIXTURE


## Air resonator: Removal - Refitting

# 12A

K4M

### REMOVAL

#### REMOVAL OPERATION FOR PART CONCERNED



116562

#### Remove:

- the elastic mounting (1) from the air resonator unit,
- the air resonator unit (2) .

### REFITTING

#### REFITTING OPERATION FOR PART CONCERNED

#### Refit:

- the air resonator unit,
- the air resonator elastic mounting.

# FUEL MIXTURE

## Air filter: Removal - Refitting

# 12A


K4M

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Remove the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page **12A-2**).
- Disconnect the brake servo vacuum pipe (**1**) from the inlet distributor.

#### II - REMOVAL OPERATION



116552

#### WARNING

Do not damage the vacuum outlet on the inlet distributor. If it is damaged, the inlet distributor will need to be replaced.

Remove:

- the two bolts (**2**) from the air filter cover,
- the air filter cover (**3**),
- the air filter.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Clean the air filter housing.

#### II - REFITTING OPERATION FOR PART CONCERNED

Refit:

- the air filter,
- the air filter cover,
- the two air filter cover bolts.

#### III - FINAL OPERATION

- Reconnect the brake servo vacuum pipe to the inlet distributor.
- Refit the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page **12A-2**).

# FUEL MIXTURE

## Air filter: Removal - Refitting

# 12A

K9K


### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- ❑ Remove the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6) .


#### II - OPERATION FOR REMOVAL OF PART CONCERNED

##### 1 - First fitting of air filter unit




- ❑ Remove the 4 bolts (1) from the air filter unit.
- ❑ Pivot the hinged cover (2) of the air filter unit in relation to the air filter unit tank.
- ❑ Move aside the air filter unit cover (2) .

##### 2 - Second fitting of air filter unit



- ❑ Remove the 9 bolts (3) from the air filter unit.
- ❑ Move aside the air filter unit cover (4) .



- ❑ Remove the air filter (5) from the air filter unit cover.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- ❑ Clean the air filter unit.

# FUEL MIXTURE

## Air filter: Removal - Refitting

# 12A

K9K

### II - REFITTING OPERATION FOR PART CONCERNED

- Refit the air filter in the air filter unit cover.

#### **WARNING**

If the air filter is fitted incorrectly in the air filter unit, unfiltered air may enter the engine and cause the engine to malfunction.

- Fit the air filter unit cover.

### III - FINAL OPERATION

- Refit the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .

Dacia Duster Explorers UK

# FUEL MIXTURE

## Air filter unit: Removal - Refitting


# 12A

K9K

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Remove the engine cover.



- Disconnect:
  - the air intake sleeve (1) on the air filter unit.
  - the air pressure sensor connector (2) from the air filter unit.
- Disconnect the connector from the air flowmeter (4) .
- Disconnect the air inlet duct (5) from the air filter unit.
- Move aside the air filter unit wiring harness.

#### II - OPERATION FOR REMOVAL OF PART CONCERNED

- Lift up the front section of the air filter unit.
- Slide the air filter unit to the left.
- Remove:
  - the bolt of the turbocharger pressure sensor,
  - the turbocharger pressure sensor on the air filter unit.
- Remove the air filter unit.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Check that there are mounting studs for the air filter unit on the EGR mounting and on the brackets.

Note:

Replace the studs if necessary.

#### II - REFITTING OPERATION FOR PART CONCERNED

- Fit the air filter unit sideways against the EGR valve mounting.
- Slide the air filter unit to the right.
- Refit:
  - the turbocharger pressure sensor on the air filter unit.
  - the bolt of the turbocharger pressure sensor,
- Refit the air filter unit by lowering it vertically from the injection end.

#### III - FINAL OPERATION

- Connect the air inlet duct to the air filter unit.
- Connect the air flowmeter connector.
- Connect:
  - the turbocharging pressure sensor connector,
  - the air intake sleeve on the air filter unit.
- Refit the engine cover.

K4M


### Tightening torques

air filter unit bolts	9 N.m
-----------------------	-------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .



116651

- Disconnect:
  - the idle speed regulation stepping motor connector (1) ,
  - the connector (2) from the throttle position potentiometer,
  - the petrol vapour recirculation pipe (3) .

### II - OPERATION FOR REMOVAL OF PART CONCERNED



116552

- Disconnect the vacuum pipe (4) from the brake servo on the inlet distributor
- Remove:
  - the two bolts (5) from the air filter cover,
  - the filter element.
- 

### WARNING


Do not damage the vacuum outlet on the inlet distributor. If it is damaged, the inlet distributor will have to be replaced.

# FUEL MIXTURE

## Air filter unit: Removal - Refitting


# 12A

K4M




116571

- Unclip:
  - the coolant pipes at (6) ,
  - the breather (7) .




116564

- Remove the coolant pipes mounting bracket (8) .
- Unpick the electrical wiring (9) from the oxygen sensor.



101488

- Remove the two bolts (10) from the air filter unit.



15757

- Remove the air filter unit.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Replace:
  - the throttle valve seal each time it is removed using grease to make fitting easier,

# FUEL MIXTURE

## Air filter unit: Removal - Refitting

# 12A

K4M

- the plastic rivets and clips every time they are removed.

### II - REFITTING OPERATION

- Refit:
  - the air filter unit,
  - the two air filter unit bolts.
- Torque tighten the **air filter unit bolts (9 N.m)**.
- Attach the electrical wiring to the oxygen sensor.
- Refit the coolant pipes mounting bracket.
- Reclip:
  - the breather,
  - the coolant pipes.
- Refit:
  - the filter element,
  - the two air filter cover bolts.
- Reconnect:
  - the brake servo vacuum pipe on the inlet distributor,
  - the petrol vapour recirculation pipe,
  - the throttle position potentiometer connector,
  - the idle speed regulation stepping motor connector.

### III - FINAL OPERATION

- Refit the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# FUEL MIXTURE

## Air flowmeter: Removal - Refitting


# 12A

K9K, and 796

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION


- Remove the engine cover.



24831

- Disconnect the air flowmeter connector (1).
- Undo the clip (2) from the air flowmeter outlet duct.
- Remove the air flowmeter outlet air duct.
- Remove the air flowmeter outlet air duct.

#### II - REMOVAL OPERATION FOR PART CONCERNED



24834

- Remove:
  - the air flowmeter (3) bolts on the air filter box,
  - the air flowmeter,

- the air flowmeter seal.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Always replace the air flowmeter seal on the air filter unit.

#### II - REFITTING OPERATION FOR PART CONCERNED

- Refit:
  - a new air flowmeter seal on the air filter box,
  - the air flowmeter,
  - the air flowmeter bolts.

#### III - FINAL OPERATION

- Refit:
  - the air flowmeter outlet air duct,
  - the air flowmeter outlet air duct clip.
- Connect the air flowmeter connector.
- Refit the engine cover.

K4M


### Tightening torques

throttle valve bolts	13 N.m
----------------------	--------

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



- Disconnect the accelerator cable at (1).

### II - OPERATION FOR REMOVAL OF PART CONCERNED



- Remove:
  - the throttle valve bolts (2),
  - the throttle valve.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Throttle valve seal.

### II - REFITTING OPERATION

- Refit:
  - the throttle valve equipped with a new seal,
  - the throttle valve bolts.
- Torque tighten the **throttle valve bolts (13 N.m)**.

### III - FINAL OPERATION

- Reattach the accelerator cable.
- Refit the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).


K4M

### Tightening torques

intake distributor mounting bolts	9 N.m
-----------------------------------	-------

## REMOVAL


### I - REMOVAL PREPARATION OPERATION



116654

- Disconnect the accelerator cable on the throttle valve at (1) .
- Remove the accelerator cable (2) from the inlet distributor.
- Disconnect:
  - the air temperature sensor connector (3) ,
  - the air inlet pressure sensor connector (4) ,
  - the connectors (5) from the coils.
- Unclip the wiring (6) on the inlet distributor.
- Move the wiring aside.
- Remove the throttle valve (see 12A, **Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11)

### II - OPERATION FOR REMOVAL OF PART CONCERNED



116653

- Remove:
  - the inlet distributor bolts (7) ,
  - the inlet distributor.
- When replacing the inlet distributor, remove:
  - the air temperature sensor,
  - the inlet air pressure sensor.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: inlet distributor seal.

## Inlet distributor: Removal - Refitting

K4M

□

### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:

- the housing of each inlet distributor seal if reused,
- the joint face of the injector holder shim.

□ Fit new seals to the inlet distributor.


□ When replacing the inlet distributor, refit:

- the air temperature sensor,
- the inlet distributor pressure sensor.

### II - REFITTING OPERATION FOR PART CONCERNED

□ Refit:

- the inlet distributor,
- the inlet distributor mounting bolts.



116653

□ Torque tighten in order the **intake distributor mounting bolts (9 N.m)**.

### III - FINAL OPERATION

□ Refit the throttle valve equipped with a new seal (see **12A, Fuel mixture, Throttle valve: Removal - Refitting**, page 12A-11) .

□ Clip the wiring onto the inlet distributor.

□ Connect:

- the coil connectors,
- the air inlet pressure sensor connector,
- the air temperature sensor connector.

□ Position the accelerator cable on the inlet distributor and on the throttle valve.


K4M

Tightening torques 	
injector holder shim bolts (7) and (8)	25 N.m
injector holder shim bolts 9 to 16	21 N.m
upper timing cover bolt	41 N.m
suspended mounting bolt	62N.m


### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page **12A-12**),
  - the injector rail (see **17B, Petrol injection, Injector rail - Injectors: Removal - Refitting**, page **17B-10**),
  - the multifunction support (see **10A, Engine and cylinder block assembly, Multifunction support: Removal - Refitting**, page **10A-48**).



110567



101792

- Remove:
  - the bolt (1) of the suspended mounting on the injector holder shim,
  - the bolt (2) mounting the upper timing cover on the injector holder shim.

#### II - REMOVAL OPERATION

- Remove:
  - the bolts (3) from the injector holder shim,
  - the injector holder shim.

## Injector holder shim: Removal - Refitting

K4M


### REFITTING

#### I - REFITTING PREPARATION OPERATION

- The injector holder shim seal must always be replaced.

#### II - REFITTING OPERATION

- Fit:
  - the injector holder shim,
  - all the injector holder shim bolts.



101792

- Place the injector holder shim against:
  - the upper timing cover by manually tightening the bolt (4) ,
  - the suspended engine mounting by manually tightening the bolt (5) .
- Position the injector holder shim against the shims (6) on the rocker cover.
- Tighten to torque and in order:
  - the **injector holder shim bolts (7) and (8) (25 N.m)**,
  - the **injector holder shim bolts 9 to 16 (21 N.m)**.

#### III - FINAL OPERATION

- Torque tighten:
  - the **upper timing cover bolt (41 N.m)**,
  - the **suspended mounting bolt (62N.m)**.
- Refit:
  - the multifunction support (see **10A, Engine and cylinder block assembly, Multifunction support: Removal - Refitting**, page **10A-48**) ,

- the injector rail (see **17B, Petrol injection, Injector rail - Injectors: Removal - Refitting**, page **17B-10**) ,
- the inlet distributor (see **12A, Fuel mixture, Inlet distributor: Removal - Refitting**, page **12A-12**) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

K9K

### Tightening torques


exhaust manifold stud	9 N.m
exhaust manifold nuts	26 N.m

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6),
  - the engine undertray,
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10),
  - the exhaust gas recirculation assembly (see **14A, Antipollution, Exhaust gas recirculation assembly: Removal - Refitting**, page 14A-9),
  - the turbocharger (see **12B, Turbocharging, Turbocharger: Removal - Refitting**, page 12B-1).

### II - REMOVAL OPERATION



113561

- Remove:
  - the exhaust manifold nuts,
  - the exhaust manifold.
- Mark the position of the exhaust manifold gasket.
- Remove the exhaust manifold gasket.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: exhaust manifold seal.
- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean the joint face:
  - the cylinder head,
  - of the exhaust manifold, if it is to be reused.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) and **CLEAN CLOTHS** to clean and degrease the joint faces:
  - the cylinder head,
  - of the exhaust manifold, if it is to be reused.


#### Note:

If a stud is loosened during this operation, coat the stud with **HIGH RESISTANCE THREAD LOCK** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

- Torque tighten the **exhaust manifold stud (9 N.m)**.

### II - REFITTING OPERATION

- Refit:
  - a new exhaust manifold gasket in the position marked during removal,
  - the exhaust manifold.



114532

- Torque tighten in order the **exhaust manifold nuts (26 N.m)**.

## Exhaust manifold: Removal - Refitting

K9K

## III - FINAL OPERATION

 Refit:

- the turbocharger (see **12B, Turbocharging, Turbocharger: Removal - Refitting**, page 12B-1) ,
- the exhaust gas recirculation assembly (see **14A, Antipollution, Exhaust gas recirculation assembly: Removal - Refitting**, page 14A-9) ,
- the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) ,
- the engine undertray,
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK


K4M

Tightening torques 	
exhaust manifold studs	8 N.m
exhaust manifold mounting nuts	23 N.m
bolts (6) mounting the stay on the cylinder block	21 N.m
nut (7) mounting the stay on the exhaust manifold	21 N.m
exhaust manifold upper heat shield mounting bolts	12 N.m
upstream oxygen sensor	45 N.m
exhaust bracket mounting bolts	21 N.m

### REMOVAL


#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2),
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



116557


- Remove the nuts (1) from the exhaust flange.
- Push the exhaust pipe towards the rear of the vehicle.



116635

- Disconnect the upstream oxygen sensor connector (2).
- Remove:
  - the upstream oxygen sensor using the,
  - the upper heat shield (3) from the exhaust manifold.


K4M



116640


- Remove the stay (4) between the exhaust manifold and the cylinder block.

### II - REMOVAL OPERATION



101797

- Remove:
  - the exhaust manifold nuts,
  - the exhaust manifold.



116642

- Using the workbench, remove:
  - the bolts (5) from the exhaust manifold lower heat shield,
  - the lower heat shield from the exhaust manifold.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: exhaust manifold seal.
- parts always to be replaced: ring between exhaust manifold and catalytic converter.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the exhaust manifold joint face if it is to be re-used,
  - the cylinder head joint face.

#### Note:


If a stud loosens during removal, coat it with **HIGH RESISTANCE THREADLOCK** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

- Tighten to torque the **exhaust manifold studs (8 N.m)**.

## Exhaust manifold: Removal - Refitting

K4M

### II - REFITTING OPERATION FOR PART CONCERNED




15101

15101

- Refit the exhaust manifold.
- Tighten to torque and in order the **exhaust manifold mounting nuts (23 N.m)**.

K4M

### III - FINAL OPERATION



116640

- Refit the stay between the exhaust manifold and the cylinder block.
- Tighten to torque and in order:
  - the bolts (6) mounting the stay on the cylinder block (21 N.m),
  - the nut (7) mounting the stay on the exhaust manifold (21 N.m).
- Refit the exhaust manifold upper heat shield.
- Torque tighten the exhaust manifold upper heat shield mounting bolts (12 N.m).
- Refit the upstream oxygen sensor using the.
- Torque tighten the upstream oxygen sensor (45 N.m).
- Connect the upstream oxygen sensor connector.
- Refit the exhaust bracket mounting bolts.
- Torque tighten the exhaust bracket mounting bolts (21 N.m).
- Refit:
  - the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6) ,
  - the air resonator (see 12A, Fuel mixture, Air resonator: Removal - Refitting, page 12A-2) .
- Connect the battery (see Battery: Removal - Refitting) (MR 388, 80A, Battery).

# TURBOCHARGING

## Turbocharger: Removal - Refitting

# 12B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

new turbocharger studs on the exhaust manifold **9 N.m**

new turbocharger stud on the turbocharger **9 N.m**

turbocharger nuts **28 N.m**


### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



24814

- Disconnect:
  - the oil vapour rebreathing pipe (1) ,
  - the duct between the turbocharger and the inter-cooler at (2) .
- Remove:
  - the exhaust gas recirculation solenoid valve (see **14A, Antipollution, Exhaust gas recirculation solenoid valve: Removal - Refitting**, page 14A-4) ,
  - the air duct between the turbocharger and the air filter unit,
  - the engine undertray,
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) .


# TURBOCHARGING

## Turbocharger: Removal - Refitting

# 12B

K9K

### II - REMOVAL OPERATION



112327

- Remove (see 12B, Turbocharging, Turbocharger oil pipe: Removal - Refitting, page 12B-4) :
  - the turbocharger oil return pipe (3) ,
  - the turbocharger oil supply pipe.
- Remove:
  - the nuts (4) from the turbocharger on the exhaust manifold,
  - the turbocharger,
  - the turbocharger seal.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Turbocharger nut.
- parts always to be replaced: seal between exhaust manifold and turbocharger.

- parts always to be replaced: exhaust manifold stud on the turbocharger (if loosened).

#### WARNING

Ensure that no foreign bodies enter the turbine or compressor during the refitting operation.

Check that the turbocharger oil return pipe is not partially or completely blocked by scale. Check that there are no leaks. If there are, replace the part.

#### WARNING

Following a turbocharger fault, check that the intercooler and air circuit assembly are not full of oil. If they are, remove them and clean them with a cleaning tray or station and dry them with a compressed air gun.

- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean:
  - the exhaust manifold joint face,
  - the turbocharger gasket face if reused.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the exhaust manifold joint face,
  - the turbocharger joint face if it is to be reused,
  - the housing of the turbocharger air outlet pipe seal,
  - the joint face of the exhaust gas cooler mounting on the gearbox end.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Torque tighten:
  - the **new turbocharger studs on the exhaust manifold (9 N.m)**,
  - the **new turbocharger stud on the turbocharger (9 N.m)**.

#### II - REFITTING OPERATION

- Refit:
  - a new turbocharger seal on the exhaust manifold,
  - the turbocharger.

# TURBOCHARGING

## Turbocharger: Removal - Refitting

# 12B

K9K

- Use an open wrench to fit the new turbocharger nuts without tightening them (the turbocharger must be in contact with the manifold and the wrench should no longer turn without effort).
- Torque tighten the **turbocharger nuts (28 N.m)**.

### III - FINAL OPERATION

- Refit (see **12B, Turbocharging, Turbocharger oil pipe: Removal - Refitting**, page 12B-4) :
  - the turbocharger oil return pipe,
  - the turbocharger oil supply pipe.
- Refit:
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10)
  - the engine undertray,
  - the air duct between the turbocharger and the air filter unit,
  - the exhaust gas recirculation solenoid valve (see **14A, Antipollution, Exhaust gas recirculation solenoid valve: Removal - Refitting**, page 14A-4)
- Connect:
  - the duct between the turbocharger and the inter-cooler onto the turbocharger,
  - the oil vapour rebreathing pipe .
- Refit:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the engine cover.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

### Check

- Disconnect the flow actuator connector (engine starting inhibition).
- Run the starter motor until the oil pressure warning light goes out (wait for a few seconds).
- Switch off the ignition.
- Reconnect the fuel flow actuator connector.
- Make sure that there are no oil leaks.
- Connect the **Diagnostic tool** and clear the stored faults.

## Turbocharger oil pipe: Removal - Refitting

K9K

### Equipment required

self-contained starter

Diagnostic tool

### Tightening torques

new turbocharger oil supply pipe hollow bolt to the turbocharger	<b>Torx bolt 18 N.m or Hexagonal bolt 14 N.m</b>
--	--

turbocharger oil supply pipe nut on the cylinder head	<b>shouldered nut 35 N.m or non-shouldered nut 23 N.m</b>
---	---

turbocharger oil return pipe bolts	<b>12 N.m</b>
------------------------------------	---------------

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

Wear cut-resistant gloves during the operation.

### WARNING

Ensure that no foreign bodies enter the turbine or compressor during the refitting operation.

Check that the turbocharger oil return pipe is not partially or completely blocked by scale. Check that there are no leaks. If there are, replace the part.

### WARNING

Metal objects may enter the oil and air circuits as a result of a broken turbocharger.

Failure to observe the following instructions will lead to the turbocharger breaking again.

### Note:


This procedure deals with removing and refitting the turbocharger oil return pipe and the turbocharger oil supply pipe.

## REMOVING THE TURBOCHARGER OIL SUPPLY PIPE

### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .
- Remove:
  - the engine undertray,
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) .

### II - REMOVAL OPERATION



113848

- Loosen the nut (6) for the turbocharger oil supply pipe on the cylinder head, using the tool.

## Turbocharger oil pipe: Removal - Refitting


K9K

- Remove:
  - the turbocharger oil supply pipe hollow bolt from the turbocharger,
  - the turbocharger oil supply pipe.
- Wipe away any oil run-off.

## REFITTING THE TURBOCHARGER OIL SUPPLY PIPE

## I - REFITTING PREPARATION OPERATION

- parts always to be replaced: turbocharger oil supply pipe
- parts always to be replaced: turbocharger oil pipe seal
- parts always to be replaced: Turbocharger oil supply pipe bolt



114285

## Note:

These two turbocharger oil supply pipes may be used on the same engine. The tightening torque of the end pieces (7) on the cylinder head is different, depending on the following:

- if the end piece is **shouldered (8)** ; in this case, there is no need to apply **HIGH RESISTANCE THREADLOCK** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the thread of the end piece,
- if the end piece is **not shouldered (9)** ; in this case, it is essential to apply **HIGH RESISTANCE THREADLOCK** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the thread of the end piece.

## II - REFITTING OPERATION

- Refit a new turbocharger oil supply pipe.
- Fit the turbocharger oil supply pipe nut on the cylinder head, without tightening it.
- Refit a new hollow bolt for the turbocharger oil supply pipe on the turbocharger.
- Torque tighten:
  - a new turbocharger oil supply pipe hollow bolt to the turbocharger (Torx bolt 18 N.m or Hexagonal bolt 14 N.m),

## Turbocharger oil pipe: Removal - Refitting

K9K

- the turbocharger oil supply pipe nut on the cylinder head (shouldered nut 35 N.m or non-shouldered nut 23 N.m) using toolor tool.

### III - FINAL OPERATION


- Refit:
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) ,
  - the engine undertray.
- Refit:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the engine cover.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Disconnect the high pressure pump flow actuator connector and the connector for each diesel fuel injector in order to prevent the engine from starting.
- Connect a **self-contained starter**.
- Run the starter until the oil pressure warning light goes out on the instrument panel (wait for a few seconds).
- Switch off the ignition.
- Disconnect the **self-contained starter**.
- Connect the high pressure pump flow actuator connector and the connector for each diesel fuel injector.
- Start the engine.
- Let the engine idle then depress the accelerator several times with no load.
- Switch off the ignition.
- Check:
  - that the turbocharger is operating correctly,
  - that there are no oil leaks from the turbocharger.
- Use the **Diagnostic tool** to check for an absence of stored faults; deal with these and clear them as necessary.

### REMOVING THE TURBOCHARGER OIL RETURN PIPE

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).


- Remove:
  - the engine undertray bolts,
  - the engine undertray,
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) .

### REMOVAL OPERATION



135844

- Remove the turbocharger oil return pipe bolts (10) .



112327

- Rotate the turbocharger oil return pipe (12) to facilitate its removal.

## Turbocharger oil pipe: Removal - Refitting

K9K

- Extract the turbocharger oil return pipe from the cylinder block.
- Remove the turbocharger oil return pipe seals.

**REFITTING THE TURBOCHARGER OIL RETURN PIPE****I - REFITTING PREPARATION OPERATION**

- parts always to be replaced: turbocharger oil pipe seal.**
- Use **SURFACE CLEANER** (see **Vehicle: Towing and lifting**) (04B, Consumables - Products) to clean and degrease:
  - the seal housing on the turbocharger oil return pipe if it is to be reused,
  - the turbocharger oil return pipe joint face if it is to be reused,
  - the turbocharger oil return pipe joint face on the turbocharger,
  - the turbocharger oil return pipe housing in the cylinder block.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Lubricate the turbocharger oil return pipe O-ring with clean engine oil.

**II - REFITTING OPERATION**

- Proceed in the reverse order to removal.
- Torque tighten the **turbocharger oil return pipe bolts (12 N.m)**.

# TURBOCHARGING

## Intercooler: Removal - Refitting


# 12B

K9K



### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection).



- Remove:
  - the air deflector mounting pins (1) ,
  - the air deflector.



- Press the clips of the fan assembly centring pins (2) using a screwdriver and pull them in the direction of the arrow (3) .
- Remove the fan assembly centring pins (2) .

#### II - REMOVAL OPERATION

Note:


Do not damage the cooling unit vanes (radiator, condenser, etc.) during handling.

# TURBOCHARGING

## Intercooler: Removal - Refitting


# 12B

K9K



145428

- Push the « radiator - fan » assembly in the direction of the arrow (4) in order to remove the intercooler.
- Remove the clips (5) of the intercooler ducts.
- Disconnect the intercooler ducts.



119000

- Remove the intercooler (7) in the direction of the arrows (8) then (9) .


### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Check that the intercooler is not full of oil. If this is the case, clean it with a cleaning agent and then let it dry.

#### II - REFITTING OPERATION

- Proceed in the reverse order to removal.



119003

- Press the end piece of the intercooler mounting at (6) , in the direction of the arrow, to unclip it.


# FUEL SUPPLY

## Fuel circuit: Operating diagram

# 13A

K4M

Operating diagram of the fuel supply circuit ( « pump - sender - fuel filter » assembly)



19310

19310

The fuel supply circuit does not have a return.

The fuel pressure does not vary with engine load.

The circuit comprises:

- a rail (1) without a return pipe and without a supply pressure regulator,
- a single pipe (2) coming from the tank,
- a « pump-sender-fuel filter » assembly fitted with the pressure regulator (3), the pump (4) and the fuel filter (5) (all located in the tank),
- a fuel vapour recirculation tank (6).


# FUEL SUPPLY

## Fuel circuit: Operating diagram

# 13A

K4M

Operating diagram of the fuel supply circuit (external filter)



106938

The fuel supply circuit does not have a return.

The fuel pressure does not vary with engine load.

The circuit comprises:

- a rail (7) without a return pipe union and without a supply pressure regulator,
- a single pipe (8) coming from the tank,
- a « pump-fuel sender » supply assembly fitted with the pressure regulator (9) , the pump (10) and the fuel filter (11) ,
- a fuel vapour recirculation tank (12) .

## Manual priming pump: Removal - Refitting

K9K

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- (see **Diesel injection: Precautions for the repair**) ,
- (see **Vehicle: Precautions for the repair**) (01D, Mechanical introduction).

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

### IMPORTANT

Wear goggles with side protectors for this operation.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### WARNING

To prevent impurities from entering the circuit, place protective plugs on all fuel circuit components exposed to the open air.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

### Note:


The priming pump is incorporated in the fuel supply pipe.

To remove the priming pump, remove the fuel supply pipe assembly.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).




- Remove:
  - the fuel supply pipe protector nuts (1) ,
  - the fuel supply pipe protector (2) .


## Manual priming pump: Removal - Refitting

K9K

### II - OPERATION FOR REMOVAL OF PART CONCERNED



- Disconnect the fuel supply pipe at the fuel tank end at (3) .
- Insert the blanking plugs.
- Unclip the fuel supply pipe under the body at (4) .



- Disconnect the connection (5) from the fuel supply pipe on the fuel filter.
- Unclip the fuel supply pipe at (6) .
- Remove the fuel supply pipe through the engine compartment.

### REFITTING

#### I - REFITTING OPERATION FOR PART CONCERNED

- Proceed in the reverse order to removal.
- Ensure that the fuel supply pipe unions are clicked into position properly.

### II - FINAL OPERATION

- Prime the fuel circuit using the priming pump.

#### WARNING

Check that there are no leaks:

- run the engine at idle speed for **2 minutes**,
- accelerate several times at no load,
- switch off the ignition,
- check that there is no fuel escaping.

# FUEL SUPPLY

## Diesel filter: Removal - Refitting

# 13A

K9K

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- (see **Diesel injection: Precautions for the repair**),
- (see **Vehicle: Precautions for the repair**) (01D, Mechanical introduction).

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.


### Note:

Make sure you have a new diesel filter before opening the fuel circuit.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).



24740

- Remove:
  - the plastic screen under the diesel filter,
  - the front right-hand wheel arch liner bolts (1).
- Move the front right-hand wheel arch liner slightly to one side.

# FUEL SUPPLY


## Diesel filter: Removal - Refitting

# 13A

K9K

### II - REMOVAL OPERATION

#### MAHLE type filter



- Remove:
  - the diesel filter protection plate nuts (2) ,
  - the diesel filter protection plate,
  - the diesel filter from its mounting, noting its original position.
- Disconnect the water detection sensor connector (4)
- Place a container under the diesel filter.
- Open the bleed screw (3) and let the diesel run out.

#### WARNING


Keep the pipe unions away from contaminated areas.

#### Note:

Mark the position of the fuel pipe unions in relation to the diesel filter before removing the diesel filter.

- Disconnect the pipe unions on the diesel filter.
- Let the diesel fuel flow out from the various pipes into the container.
- Fit plugs into the openings.
- Remove the water detection sensor, turning it anti-clockwise.

#### DELPHI type filter




- Disconnect the water detection sensor connector (5)
- Remove:
  - the diesel filter protection plate nuts (6) ,
  - the diesel filter protection plate,
  - the diesel filter from its mounting, noting its original position.
- Place a container under the diesel filter.

# FUEL SUPPLY

## Diesel filter: Removal - Refitting

# 13A

K9K



- Disconnect:
  - the fuel inlet pipe union (7) ,
  - the fuel outlet pipe union (8) ,
  - the fuel return pipe union (9) .
- Let the diesel fuel flow out from the various pipes into the container.
- Remove the water detection sensor (10) , turning it anti-clockwise.
- Fit plugs into the openings.

## REFITTING

### I - REFITTING OPERATION

- Refit the water detection sensor, turning it clockwise.
- Connect:
  - the pipe unions on the diesel filter,
  - the water detection sensor connector.
- Refit:
  - the new diesel filter in its original position,
  - the diesel filter protection plate,
  - the diesel filter protection plate nuts.

### II - DRAINING THE WATER INSIDE THE DIESEL FILTER

#### Note:

- Certain vehicles have a sensor for detecting water in the diesel fuel, located in the diesel filter. If water is detected, the injection fault warning light comes on.

- Periodically drain any water contained in the diesel filter.
- For filters without a water presence sensor:
  - open the drain plug,
  - let the water flow out,
  - close the plug.
- For filters with a water presence sensor:
  - disconnect the water presence sensor connector,
  - unclip the water presence sensor connector,
  - loosen the water presence sensor by one turn,
  - let the water flow out,
  - tighten the water presence sensor,
  - connect the water presence sensor connector.

### III - FINAL OPERATION

- Refit:
  - the front right-hand wheel arch liner,
  - the plastic screen under the diesel filter.


# FUEL SUPPLY

## Diesel filter: Removal - Refitting

# 13A

K9K

### Priming the supply circuit



- Prime the fuel system with the manual priming pump (11) (automatic degassing).

# FUEL SUPPLY

## Fuel pressure: Check

# 13A

K4M

### Special tooling required

**Mot. 1311-08** Union for taking fuel pressure measurements.

### Tightening torques

fuel pipe protector nuts	<b>7 N.m</b>
fuel pipe protector bolt	<b>7 N.m</b>

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects near the working area,
- beware of fuel splashes when disconnecting the union,
- protect sensitive areas from fuel outflow.

### IMPORTANT

Wear goggles with side protectors for this operation.

### IMPORTANT


Wear leaktight gloves (nitrile type) for this operation.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.


### CHECK

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Switch off the ignition.




#### Remove:

- the nuts (1) and the bolt (2) from the fuel pipe protector,
- the fuel pipe protector.



- Disconnect the fuel supply pipe union (3).

K4M



109173

- Connect:
  - the « T » union (**Mot. 1311-08**) (6) to the fuel tank outlet pipe,
  - the pipe (5) fitted with a pressure gauge contained in the test kit to the « T » union (6) ,
  - the fuel supply pipe (7) to the « T » union (6) .
- Start the vehicle to run the fuel pump.
- Determine the pressure:
  - the pressure must be constant (approximately **3.5 bar ± 0.2 bar**),
  - It may take a few seconds to obtain a correct pressure reading.
- Disconnect:
  - the pipe fitted with the pressure gauge contained in the test kit from the « T » union,
  - the « T » union (**Mot. 1311-08**) from the fuel tank outlet pipe.
- Connect the fuel supply pipe union to the fuel tank outlet pipe.
- Refit the fuel supply pipe protector.
- Torque tighten:
  - the **fuel pipe protector nuts (7 N.m)**,
  - the **fuel pipe protector bolt (7 N.m)**.

# FUEL SUPPLY

## Fuel flow: Check

# 13A

K4M

### Special tooling required

**Mot. 1311-08** Union for taking fuel pressure measurements.

### Tightening torques

fuel pipe protector nuts **7 N.m**

fuel pipe protector bolt **7 N.m**

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects near the working area,
- beware of fuel splashes when disconnecting the union,
- protect sensitive areas from fuel outflow.

### IMPORTANT

Wear goggles with side protectors for this operation.

### IMPORTANT


Wear leaktight gloves (nitrile type) for this operation.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

### CHECK


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Switch off the ignition.



145185

### Remove:

- the nuts (1) and the bolt (2) from the fuel pipe protector,
- the fuel pipe protector.



108650


- Disconnect the fuel supply pipe union (3).

# FUEL SUPPLY

## Fuel flow: Check

# 13A


K4M



109173


Connect:

- the « T » union (**Mot. 1311-08**) (6) to the fuel tank outlet pipe,
- the pipe (5) contained in the test kit onto the « T » union (6) ,
- the fuel supply pipe (7) to the « T » union (6) .



109174


- Insert the pipe (11) into a graduated measuring cylinder (**2000 ml**).
- Remove the Protection and Switching Unit cover.



116568

- Disconnect the connector (12) from the passenger compartment engine harness.

K4M



109172

- Connect the connector terminal (13) to the + **BATTERY** to operate the fuel pump.
- Note the time taken for the measuring cylinder to fill up.


Note:

The minimum flow rate from the fuel pump is **60 l/h**.

- Remove the terminal (13) of the + **BATTERY** connector.
- Refit the Protection and Switching Unit cover.
- Disconnect:
  - the pipe fitted with the pressure gauge contained in the test kit from the « T » union,
  - the « T » union (**Mot. 1311-08**) from the fuel tank outlet pipe.
- Connect the fuel supply pipe union to the tank outlet pipe.
- Refit the fuel supply pipe protector.
- Torque tighten:
  - the **fuel pipe protector nuts (7 N.m)**,
  - the **fuel pipe protector bolt (7 N.m)**.

## Diesel injection: List and location of components

K9K, and 796




123977

No.	Description
1	High pressure pump
2	Injection computer
3	Injector rail pressure sensor
4	Spherical injector rail
5	Diesel temperature sensor
6	Diesel fuel flow actuator
7	Accelerometer
8	Injector
9	Venturi
10	Exhaust gas recirculation solenoid valve
11	Turbocharging air pressure sensor
12	Air flowmeter with integrated temperature sensor


No.	Description
13	Turbocharger
14	Cylinder reference sensor
15	Coolant temperature sensor
16	TDC sensor
17	Pre-postheating unit
18	Turbocharger control solenoid valve (only for K9K 796 engine)
19	Accelerator pedal potentiometer

## Diesel injection: List and location of components


K9K, and 796




High-pressure pump (1) .



Injector rail pressure sensor (3) ,  
Spherical injector rail (4) ,  
Diesel temperature sensor (5) ,  
Diesel fuel flow actuator (6) ,  
Accelerometer (7) ,  
Injectors (8) ,  
Venturi (9) .




Injection computer (2) .



Exhaust gas recirculation solenoid valve (10) ,  
Turbocharger (11) .


## Diesel injection: List and location of components

K9K, and 796



24831

Air flowmeter with integrated temperature sensor (12) ,  
Turbocharging air pressure sensor (13) .




20796

Coolant temperature sensor (15) .



24749

Cylinder marking sensor (14) .




24817

Top Dead Centre sensor (16) .


## Diesel injection: List and location of components

K9K, and 796



24729

Pre-postheating unit (17) .



24750

Accelerator pedal potentiometer (19) .

## Diesel injection computer: Removal - Refitting

K9K

### Equipment required

Diagnostic tool

### Tightening torques

injection computer nuts	8 N.m
injection computer protector bolts	8 N.m

### Note:

When programming, reprogramming or replacing the computer, it is necessary to program the new computer with the C2I parameters (injector flow correction) and the engine adaptives using the **Diagnostic tool**.


There are two ways to do this (see **Fault finding - Replacement of components**) (13B, Diesel injection):

- an automatic method which can be used if it is possible to read the information contained in the old computer,
- a manual method which is to be used if it is not possible to read the information contained in the old computer.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Remove the battery (see **Battery: Removal - Refitting**) (80A, Battery).



24734

- Unclip the positive terminal wiring (2) .
- Remove:
  - the bolts (3) from the injection computer protector,
  - the injection computer protector (4) .

### II - REMOVAL OPERATION



146253

- Remove the injection computer nuts (6) .
- Disconnect the three connectors (5) from the injection computer.
- Remove the injection computer.

## Diesel injection computer: Removal - Refitting

K9K

## REFITTING

## I - REFITTING OPERATION


- Fit the injection computer on its mounting studs.
- Torque tighten the **injection computer nuts (8 N.m)**.
- Connect the injection computer connectors.

## II - FINAL OPERATION

- Refit the injection computer protector.
- Tighten to torque the **injection computer protector bolts (8 N.m)**.
- Clip on the positive terminal wiring.
- Refit the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Respect the programming settings for the C2I (individual injector correction) parameters and the engine adaptives (see **Fault finding - Replacement of components**) (13B, Diesel injection).
- Switch on the ignition and read the fault codes using the **Diagnostic tool**.
- If necessary, repair the faults indicated.
- Clear the faults.
- Check that the vehicle is working properly.

## Camshaft position sensor: Removal - Refitting

K9K

**REMOVAL****OPERATION FOR REMOVAL OF PART CONCERNED**

24749

- Disconnect the connector (1) from the camshaft position sensor.
- Remove:
  - the bolt (2) from the camshaft position sensor,
  - the camshaft position sensor.

**REFITTING****I - REFITTING OPERATION FOR PART CONCERNED**

- Refit:
  - the camshaft position sensor,
  - the camshaft position sensor bolt.

**II - FINAL OPERATION**

- Reconnect the camshaft position sensor connector.

## Crankshaft position sensor: Removal - Refitting

K9K, and 796


Tightening torques 	
crankshaft position and speed sensor bolt	8 N.m

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the engine undertray bolts,
  - the engine undertray.

#### II - REMOVAL OPERATION



24817

- Disconnect the crankshaft position sensor connector (1) from underneath the vehicle.
- From underneath the vehicle, remove:
  - the crankshaft position sensor bolt (2) ,
  - the crankshaft position sensor.

### REFITTING

#### I - REFITTING OPERATION

- Refit the crankshaft position sensor.

- Torque tighten the **crankshaft position and speed sensor bolt (8 N.m)**.
- Connect the crankshaft position sensor connector.

#### II - FINAL OPERATION

- Refit the engine undertray.

# DIESEL INJECTION

## High pressure pump: Removal - Refitting

# 13B

K9K, and 796

### Equipment required

Diagnostic tool

### Tightening torques

the high pressure pump bolts **23 N.m**

high pressure pump pulley nut **70 N.m**

dipstick guide and filler neck nuts on the high pressure rail **21 N.m**

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, use the **Diagnostic tool** to check:

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.


### Note:

Never run the engine in the opposite direction to that of normal operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733


- Remove the dipstick guide and filler neck nuts (1).
- Put the dipstick guide to one side (2).

# DIESEL INJECTION


## High pressure pump: Removal - Refitting

# 13B


K9K, and 796



109466



102360




24752

- Disconnect:
  - the heater plugs (3) ,
  - the injectors (4) ,
  - the connectors from the high pressure pump (5) .
- Clean the diesel supply and return pipes (see **Diesel injection: Precautions for the repair**) .
- Disconnect the diesel supply and return pipes (6) .
- Fit blanking plugs into the openings.

Disconnect:

- the fuel return pipe (7) connecting the injectors to the high-pressure pump,
- the injector rail pressure sensor (8) ,
- the accelerometer (9) ,
- the camshaft position sensor (10) .



24733


- Unclamp the engine wiring (11) and move it to one side.
- Remove the channel (12) located on the injector rail.

# DIESEL INJECTION

## High pressure pump: Removal - Refitting


# 13B

K9K, and 796



102083

- Remove the high pressure pipe (13) between the injector rail and the high pressure pump (see 13B, **Diesel injection, High pressure pipe between pump and rail: Removal - Refitting**, page 13B-19) .
- Put blanking plugs in all the openings of the injection circuit.
- Remove:
  - the right-hand suspended engine mounting (see 19D, **Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,
  - the camshaft position sensor (see 13B, **Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) .
- Remove (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) :
  - the upper timing cover,
  - the lower timing cover,
  - the cylinder head suspended mounting.
- Position the engine at top dead centre (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) .




23168

- Fit the high pressure pump pulley retaining tool (14) .
- If necessary, turn the engine slowly to adjust the position of the locking tool on the pump pulley teeth.
- Remove the high pressure pump pulley nut (15) , holding the pulley with a 32 mm open-jawed spanner.

## High pressure pump: Removal - Refitting

K9K, and 796




23169

- Position the (16) fitted with the.

### WARNING

Ensure that the tool pushrod is correctly oriented and is pressing against the high pressure pump shaft.

## II - REMOVAL OPERATION



102085

- Remove:
  - the high pressure pump bolts (17) ,
  - the bracket (18) from the engine cover.
- Screw the pushrod of the tool until the high pressure pump becomes detached.
- Remove:
  - the high pressure pump,
  - the.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Check for an index pin on the high pressure pump shaft.

### II - REFITTING OPERATION

- Refit the high pressure pump on the cylinder head by inserting it into the high pressure pump pulley.


#### Note:

Check that the high pressure pump shaft is correctly orientated in relation to the high pressure pump pulley.

- Refit the engine cover bracket.
- Fit the high pressure pump bolts without tightening them.

## High pressure pump: Removal - Refitting

K9K, and 796



134076

- Torque tighten in order **the high pressure pump bolts (23 N.m)**.
- Torque tighten the **high pressure pump pulley nut (70 N.m)** while holding the high pressure pump pulley using a **32 mm** spanner.

**Note:**

Check that the timing belt is correctly positioned and in good condition.

- Remove them from the cylinder head.

### III - FINAL OPERATION

- Remove the blanking plugs.
- Refit the high pressure pipe between the injector rail and the high pressure pump (see **13B, Diesel injection, High pressure pipe between pump and rail: Removal - Refitting**, page 13B-19) .
- Refit (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) :
  - the suspended mounting on the cylinder head,
  - the lower timing cover,
  - the upper timing cover.
- Refit:
  - the camshaft position sensor (see **13B, Diesel injection, Camshaft position sensor: Removal - Refitting**, page 13B-7) ,

- the right-hand suspended engine mounting (see **19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting**, page 19D-4) ,

- the neck located on the injector rail.

- Secure the engine wiring on the neck.

- Connect:

- the camshaft position sensor,
- the accelerometer,
- the injector rail pressure sensor,
- the fuel return pipe connecting the injectors to the high-pressure pump,
- the supply and return pipes on the high pressure pump,
- the connectors to the high pressure pump,
- the injectors,
- the heater plugs.

- Refit the dipstick guide.

- Torque tighten the **dipstick guide and filler neck nuts on the high pressure rail (21 N.m)**.

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

- Start the engine.

- Check that there are no fuel leaks.

- Refit the engine cover.

# DIESEL INJECTION

## Flow actuator: Removal - Refitting

# 13B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

flow actuator bolts **6 N.m**

dipstick guide and filler neck nuts on the high pressure rail **21 N.m**

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.


### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733

- Remove the dipstick guide and filler neck nuts (1).
- Put the dipstick guide to one side (2).



24752


- Disconnect:
  - the heater plugs (3),
  - the injectors (4),
  - the connectors from the high pressure pump (5),
  - the diesel supply and return pipes (6).

# DIESEL INJECTION

## Flow actuator: Removal - Refitting

# 13B

K9K



102315

- Disconnect:
  - the injector rail pressure sensor,
  - the accelerometer .
- Unclamp the engine wiring and put it to one side.
- Remove:
  - the neck located on the injector rail,
  - the high pressure pipe (7) between the injector rail and injector no. 4 (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) .
- Plug the openings.

### II - REMOVAL OPERATION

- Loosen the fuel flow actuator bolts (8) .

#### WARNING

Do not use the electrical connector as a lever arm.

- Withdraw the fuel flow actuator (by hand using small successive turns).

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Only unpack the new component when you are ready to fit it.

#### WARNING

Do not remove the blanking plugs from each component until the last moment.

#### WARNING

Do not damage the seal when refitting.

#### Note:

Do not lubricate the seals with grease or old diesel fuel. Use the applicator provided in the kit for the new part.

#### II - REFITTING OPERATION

- Position the flow actuator.
- Finger tighten the flow actuator bolts.
- Torque tighten the **flow actuator bolts (6 N.m)**.

#### III - FINAL OPERATION

- Refit the new high pressure pipe between the injector rail and injector no. 4 (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) .
- Connect:
  - the diesel supply and return pipes on the high pressure pump,
  - the electrical connectors on the high-pressure pump,
  - the injectors,
  - the heater plugs.
- Refit the dipstick guide.
- Torque tighten the **dipstick guide and filler neck nuts on the high pressure rail (21 N.m)**.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Start the engine.
- Check that there are no fuel leaks.
- Refit the engine cover.

# DIESEL INJECTION

## Venturi: Removal - Refitting

# 13B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

Venturi bolt **6 N.m**

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.


Note:

Ensure that you have a new Venturi before opening up the fuel circuit.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733


- Remove the dipstick guide and filler neck nuts (1).
- Put the dipstick guide to one side (2).



24752

- Disconnect the diesel supply and return pipes (3).

K9K



102316

- Disconnect the return pipe (4) connecting the injector to the high pressure pump.

### II - REMOVAL OPERATION

- Remove:
  - the bolt (5) of the Venturi (6),
  - the Venturi.
- Plug the openings.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- 

#### WARNING

Do not remove the blanking plugs from each component until the last moment.

- Lubricate the O-ring with lubricant from the applicator supplied with the new part.

#### II - REFITTING OPERATION

- parts always to be replaced: Venturi.

#### Note:

Do not damage the seal when refitting.

- Fit the Venturi.
- Torque tighten the **Venturi bolt (6 N.m)**.

#### III - FINAL OPERATION

- Connect the return pipe connecting the injector to the high-pressure pump.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Start the engine.
- Check that there are no fuel leaks.
- Refit the engine cover.

# DIESEL INJECTION

## High pressure pipe: Check

# 13B

K9K

### Equipment required

Diagnostic tool

□

#### WARNING

Check that there are no diesel leaks after each operation.

Note:


the **Diagnostic tool** can be used for testing the high pressure circuit with the engine running. This command can be used to run fault finding on a leak due to an incorrectly fitted or tightened union. This command only works if the engine coolant temperature is over **60°C**. The fault finding procedure does not reveal small leaks caused by insufficient tightening.

Note:

Respect the repair precautions (see **Diesel injection: Precautions for the repair**).

### CHECK

- Remove the front engine cover.



24732

- Prime the fuel circuit using the manual priming pump (1) until the transparent pipes are filled with fuel (automatic degassing).
- Check that there are no fuel leaks.
- Connect the **Diagnostic tool** to the vehicle.
- Deal with present faults,

Note:

Certain faults will prevent this test from being carried out: deal with them first.

Note:

The engine automatically runs a cycle of four accelerations and decelerations to lower the rail pressure.

#### WARNING

Do not leave anything on the side of the engine housing during the test phase (significant vibration).

- Run command **AC 626 - high pressure circuit sealing test**.
- Check that there are no fuel leaks.
- Deal with the causes of any possible leaks.
- Use the **Diagnostic tool** to check for stored faults; deal with these and clear them as necessary.
- Disconnect the **Diagnostic tool**.

K9K

### Equipment required

Diagnostic tool

### Tightening torques

nut of the high pressure pipe between the pump and the injector rail on the high pressure pump **28 N.m**

nut of the high pressure pipe between the pump and the rail on the injector rail **28 N.m**

dipstick guide and filler neck nuts on the high pressure rail **21 N.m**

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.


### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733

- Remove the dipstick guide and filler neck bolts (1).
- Put the dipstick to one side.




109466

- Disconnect the following connectors (2) :
  - the heater plugs,

K9K

- the injectors.



24752

- Disconnect:
  - the high pressure pump connectors (3) .
  - the injector rail pressure sensor.
- Clean the diesel supply and return pipes (see **Diesel injection: Precautions for the repair**) .
- Disconnect the diesel supply and return pipes (4) .
- Disconnect the return pipe connecting the injectors to the high pressure pump.
- Fit the correct blanking plugs.
- Move the wiring to one side with the neck on the side.
- Clean the high pressure pipe unions between the rail and the injectors (see **Diesel injection: Precautions for the repair**) .


### II - REMOVAL OPERATION

- Clean the unions of the high pressure pipe between the high pressure pump and the injector rail (see **Diesel injection: Precautions for the repair**) .
- Undo:
  - the high pressure pipe nut at the high pressure pump end,
  - the high pressure pipe nut at the injector rail end.
- Fit blanking plugs into the openings.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: High pressure pipe between the pump and rail.



20960

#### WARNING

Before fitting a new high pressure pipe, lightly lubricate the nut threads with oil from the applicator provided with the new part.

Be careful not to allow oil into the high pressure pipe.

Do not lubricate high pressure pipes supplied without an applicator, as these high pressure pipes are self-lubricating.

#### WARNING

Do not remove the blanking plugs from each component until the last moment.

#### II - REFITTING OPERATION

- Remove the blanking plugs.
- Insert the high pressure pipe olive in the high pressure pump high pressure outlet taper.
- Insert the high pressure pipe olive into the injector rail inlet taper.
- Finger tighten the high-pressure pipe nuts, starting with the one at the injector rail side.

K9K

- Slightly pretighten the high pressure pipe nuts.
- Torque tighten:
  - the **nut of the high pressure pipe between the pump and the injector rail on the high pressure pump (28 N.m)**,
  - the **nut of the high pressure pipe between the pump and the rail on the injector rail (28 N.m)**.

### III - FINAL OPERATION

- Refit the neck on the injector rail.
- Connect:
  - the injection rail pressure sensor,
  - the diesel return pipe connecting the injectors to the high pressure pump,
  - the diesel fuel supply and return pipes,
  - the high pressure pump electrical connectors.
- Connect the connectors of:
  - the injectors,
  - the heater plugs.
- Insert the dipstick.
- Refit the dipstick guide.
- Torque tighten the **dipstick guide and filler neck nuts on the high pressure rail (21 N.m)**.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Prime the diesel circuit using the priming pump.
- Check the high pressure circuit (see **13B, Diesel injection, High pressure pipe: Check**, page **13B-18**)  
.
- Refit the engine cover.

K9K

### Equipment required

Diagnostic tool

### Tightening torques

injector rail nuts	<b>28 N.m</b>
« pump - rail » high pressure pipe nuts	<b>28 N.m</b>
dipstick guide and filler neck nuts on the high pressure rail	<b>21 N.m</b>

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.


### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



24733

- Remove the nuts (1) from the dipstick guide and neck.
- Put the dipstick to one side.


K9K



109466

- Disconnect the following connectors (2) :

- the heater plugs,
- the injectors.



24752

- Disconnect the high pressure pump connectors (3) .
- Remove the bolts mounting the neck onto the injector rail.
- Move the wiring to one side with the neck on the side.
- Remove the clips connecting the high pressure pipes.
- Clean the high pressure pipe unions between the rail and the injectors (see **Diesel injection: Precautions for the repair**) .

### II - REMOVAL OPERATION


- Undo:
  - the high pressure nut at the injector end,
  - the high pressure pipe nut at the injector rail end.
- Remove the pipe and discard it.
- Fit blanking plugs into the openings.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: High pressure pipe between the rail and injector.**

K9K



20960

### WARNING

Before fitting a new high pressure pipe, lightly lubricate the nut threads with oil from the applicator provided with the new part.

Be careful not to allow oil into the high pressure pipe.

Do not lubricate high pressure pipes supplied without an applicator, as these high pressure pipes are self-lubricating.

### WARNING

Do not remove the blanking plugs from each component until the last moment.

- If replacing the four high pressure pipes:
  - loosen the injector rail nuts by a few turns (the injector rail should be loose).

### II - REFITTING OPERATION

- Remove the blanking plugs.
- Insert the high pressure pipe olive in the injector high pressure inlet taper.
- Position the high pressure pipe olive in the high pressure outlet taper of the injector rail.
- Finger tighten the high pressure pipe nuts, starting with the nut at the injector end.

- Slightly pretighten the high pressure pipe nuts.

#### Note:

The assembly order of the « rail-injector » high pressure pipes is not important.

- Mount a new clip provided with the new high pressure pipe.
- If replacing the four high pressure pipes, torque tighten the **injector rail nuts (28 N.m)**.
- Torque tighten in order the « **pump - rail** » **high pressure pipe nuts (28 N.m)** :
  - injectors end,
  - on the injector rail end.

#### Note:

Tighten each pipe fully before moving on to the next pipe.

### III - FINAL OPERATION

- Refit the neck on the injector rail.
- Connect the connectors of:
  - the injectors,
  - the heater plugs.
- Insert the dipstick.
- Refit the dipstick guide.
- Torque tighten the **dipstick guide and filler neck nuts on the high pressure rail (21 N.m)**.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Prime the diesel circuit using the priming pump.
- Check the high pressure circuit (see **13B, Diesel injection, High pressure pipe: Check**, page **13B-18**) .
- Refit:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page **12A-6**) .
  - the engine cover,

# DIESEL INJECTION

## Injector rail: Removal - Refitting

# 13B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

injector rail nuts	28 N.m
--------------------	--------

nuts of the neck and dipstick guide on the injector rail	21 N.m
--	--------

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before starting any work on the injection circuit, use the **Diagnostic tool** to check:

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.


### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733


- Remove the nuts (1) from the dipstick guide and neck.
- Put the engine oil dipstick guide to one side (2).

# DIESEL INJECTION


## Injector rail: Removal - Refitting

# 13B

K9K




109466




24752

- Disconnect:
  - the heater plugs (3) ,
  - the injectors (4) ,
  - the connectors on the high pressure pump (5) ,
  - the diesel return pipe connecting the injectors to the high pressure injection pump.
- Clean the diesel supply and return pipes (see **Diesel injection: Precautions for the repair**) .
- Disconnect the diesel supply and return pipes (6) .
- Place blanking plugs on the openings.



102360

- Disconnect:
  - the pressure sensor (7) from the injector rail,
  - the accelerometer (8) .



24733

- Unclamp the engine wiring (9) and place it to one side.
- Remove:
  - the neck (10) located on the spherical injector rail,
  - the high pressure pipe between the high pressure pump and the injector rail (see **13B, Diesel injection, High pressure pipe between pump and rail: Removal - Refitting, page 13B-19**) ,

# DIESEL INJECTION


## Injector rail: Removal - Refitting

# 13B

K9K

- the high pressure pipes between the injector rail and the injectors (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) .

### II - OPERATION FOR REMOVAL OF PART CONCERNED



133523

- Remove:
  - the nuts (11) from the injector rail,
  - the injector rail.

### REFITTING

#### I - REFITTING OPERATION FOR PART CONCERNED

#### WARNING

Do not remove the blanking plugs from each component until the last moment.

- Fit the injector rail.
- Finger tighten the nuts.
- Refit:
  - the high pressure pipes between the injector rail and the injectors (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) ,

- the high pressure pipe between the high pressure pump and the injector rail (see **13B, Diesel injection, High pressure pipe between pump and rail: Removal - Refitting**, page 13B-19) .

- Torque tighten the **injector rail nuts (28 N.m)**.

#### II - FINAL OPERATION

- Refit the neck located on the injector rail.
- Secure the engine wiring on the neck.
- Connect:
  - the accelerometer,
  - the injector rail pressure sensor,
  - the diesel return pipe connecting the injectors to the high pressure pump,
  - the diesel supply and return pipes on the high pressure pump,
  - the connectors to the high pressure pump,
  - the injectors,
  - the heater plugs.
- Refit the dipstick guide.
- Torque tighten the **nuts of the neck and dipstick guide on the injector rail (21 N.m)**.
- Start the engine.
- Check that there are no fuel leaks.
- Check the high pressure circuit (see **13B, Diesel injection, High pressure pipe: Check**, page 13B-18) .
- Refit the engine cover.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## Fuel temperature sensor: Removal - Refitting

K9K

### Equipment required

Diagnostic tool

### Tightening torques

fuel temperature sensor	15 N.m
-------------------------	--------

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.


### REMOVAL

Note:

Make sure you have a new diesel temperature sensor before removal.

### I - REMOVAL PREPARATION OPERATION

- Remove the front engine cover.




24752

- Disconnect:

- the heater plugs (1) on cylinders 3 and 4,
- the injectors (2) of cylinders 3 and 4,

### II - REMOVAL OPERATION

- Disconnect the fuel temperature sensor connector (3).



102317

- Clean the fuel temperature sensor.
- Remove the fuel temperature sensor (4).
- Plug the openings.

## Fuel temperature sensor: Removal - Refitting

K9K

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Lubricate the O-ring with lubricant from the applicator supplied with the new part.

## II - REFITTING OPERATION

Note:

Do not damage the O-ring when refitting.

- Remove the blanking plugs.
- Fit the fuel temperature sensor.
- Torque tighten the **fuel temperature sensor (15 N.m)**.
- Connect the connector **(3)** of the fuel temperature sensor.

## III - FINAL OPERATION

- Connect:
  - the injectors **(2)** of cylinders **3** and **4**,
  - the heater plugs **(1)** on cylinders **3** and **4**.
- Start the engine.
- Check that there are no fuel leaks.
- Refit the engine cover.

# DIESEL INJECTION

## Injector leak flow: Check

# 13B

K9K

### Equipment required

Diagnostic tool

### PARTS AND CONSUMABLES FOR THE REPAIR

#### Consumables:


- cleaning cloths (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).
- set of K9K blanking plugs (**DELPHI** injection) (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

#### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### CHECK

- Remove the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



102360

#### Disconnect:

- the diesel return pipes (1) on the injectors,
- the diesel return pipe (2) on the venturi attached to the high pressure pump.

#### Note:

Make preparations for fuel outflow.

- Fit the correct blanking plug on the venturi.

#### Note:


It is essential to fit an appropriate blanking plug to the Venturi to avoid depriming the diesel return circuit.

# DIESEL INJECTION

## Injector leak flow: Check

# 13B

K9K



- Connect four of the transparent pipes (3) of the onto the diesel injector return.
- Insert these pipes in the four graduated measuring cylinders (4) of the.

**Note:**

If necessary, attach the graduated measuring cylinder rail of the to the bonnet.

- Connect the **Diagnostic tool** to the vehicle.
- Follow the instructions given in test 9: Injector sealing test (see **Fault finding - Test**) (13B, Diesel injection).
- Disconnect the transparent pipes from the.
- Remove the transparent pipes from the graduated measuring cylinder of the.
- Empty the diesel fuel out of the graduated measuring cylinders.
- Connect:
  - the diesel return pipes on the injectors,
  - the diesel return pipe to the Venturi attached to the high pressure pump.
- Replace the faulty injector(s) (see **13B, Diesel injection, Diesel injector: Removal - Refitting**, page **13B-32**).
- Check that there are no fuel leaks.
- Use the **Diagnostic tool** to check for the absence of stored faults, deal with them and clear them, as necessary.
- Disconnect the **Diagnostic tool**.
- Refit the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page **12A-6**).

# DIESEL INJECTION

## Diesel injector: Removal - Refitting

# 13B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

diesel injector clamp bolt	28 N.m
injector rail nuts	28 N.m
« rail-injector» high pressure pipe nuts	24 N.m
nuts of the neck and dipstick guide on the injector rail	21 N.m

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

Injectors may be replaced individually.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

### Remove:

- the engine cover,
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).



24733


- Remove the nuts (1) from the dipstick guide and neck.
- Put the engine oil dipstick guide to one side (2).

# DIESEL INJECTION


## Diesel injector: Removal - Refitting

# 13B

K9K




109466



102360

Disconnect:

- the pressure sensor (7) from the injector rail,
- the accelerometer (8) .



24752


Disconnect:

- the heater plugs (3) ,
- the injectors (4) ,
- the connectors (5) on the high pressure pump,
- the diesel return pipe connecting the injectors to the high pressure injection pump.

Clean the diesel supply and return pipes (see **Diesel injection: Precautions for the repair**) .

Disconnect the diesel supply and return pipes (6) .

Plug the openings.



24733

Unclamp the engine wiring (9) and place it to one side.

Remove the neck (10) located on the injector rail.

Remove the « rail-injector » high pressure pipes (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting, page 13B-22**) .

Plug the openings.


# DIESEL INJECTION

## Diesel injector: Removal - Refitting

# 13B

K9K

### II - OPERATION FOR REMOVAL OF PART CONCERNED



109462

- Loosen the injector clamp bolt (11) .

Note:

If reusing a diesel injector, always mark the removed diesel injector in relation to its cylinder.

- Remove the diesel injector (12) .

Note:


If the diesel injector is jammed, remove the injector using the tool and the tool.

- Remove the heat protection washer.

Note:

If the heat protection washer is stuck at the bottom of the well, use the (see **Injector well cleaning tool: Use**) (Technical Note 6040A, 13B, Diesel injection).

### REMOVING THE INJECTORS USING TOOLS (MOT. 921-01) AND (EMB. 880)




120509

120509

- (A) Tool for extracting injector holders (Mot. 921-01).
- (B) Pin extractor (Emb. 880).

- Fit the tool on the extractor
- Apply releasing agent around the diesel injector.



120510

120510

- Fit the slide hammer onto the diesel injector.
- Extract the jammed injector using the slide hammer.

# DIESEL INJECTION

## Diesel injector: Removal - Refitting

# 13B

K9K

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Always replace the heat protection washer of the diesel injector concerned.

#### Cleaning parts

- 

#### WARNING

It is strictly forbidden to clean the injectors with:

- a wire brush,
- an emery cloth,
- an ultrasonic cleaner.

- Always clean the well of the removed injector (see **Injector well cleaning tool: Use**) (Technical Note 6040A, 13B, Diesel injection).

- If reusing the removed injector:

- clean the injector using a **CLOTH FOR INJECTION SYSTEM** soaked in **INJECTOR CLEANER** or **BRAKE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products),
- if necessary, leave the injector nozzle to soak in **INJECTOR CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products),
- wipe the injector with a new **CLOTH FOR INJECTION SYSTEM**, (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) and (see **Diesel injection: Precautions for the repair**) (13B, Diesel injection).

#### II - REFITTING OPERATION FOR PART CONCERNED

- 

#### WARNING

Do not remove the caps from each component until the last moment.

#### Note:

If one or more injectors are replaced, note the alphanumeric code (C2I) and the cylinder on which it is fitted.

- Refit the injector with its clamp.

- Torque tighten the **diesel injector clamp bolt (28 N.m)**.

#### III - FINAL OPERATION

- Fit the high pressure pipes (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) .

- Torque tighten the **injector rail nuts (28 N.m)**.

- Torque tighten in order the « **rail-injector** » **high pressure pipe nuts (24 N.m)** (see **13B, Diesel injection, High pressure pipe between rail and injector: Removal - Refitting**, page 13B-22) .

- Refit the neck located on the injector rail.

- Secure the engine wiring on the neck.

- Connect:

- the accelerometer,
- the high pressure rail pressure sensor,
- the diesel return pipe connecting the injectors to the high pressure pump,
- the diesel supply and return pipes on the high pressure pump,
- the electrical connectors on the high-pressure pump,
- the injectors,
- the heater plugs.

- Refit the dipstick guide.

- Torque tighten the **nuts of the neck and dipstick guide on the injector rail (21 N.m)**.

- Refit:

- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .
- the engine cover,


- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# DIESEL INJECTION

## Diesel injector: Removal - Refitting

# 13B

K9K



19724

- Program the alphanumeric code (C21) (13) for the replaced injector(s) using the **Diagnostic tool** (see **Fault finding - Replacement of components**) (13B, Diesel injection).
- Start the engine.
- Check that there are no fuel leaks.

# DIESEL INJECTION

## Accelerometer: Removal - Refitting

# 13B

K9K

### Equipment required

Diagnostic tool

### Tightening torques

accelerometer	<b>20 N.m</b>
dipstick guide and filler neck nuts on the high pressure rail	<b>21 N.m</b>

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Diesel injection: Precautions for the repair**).

### IMPORTANT

Before carrying out any work on the injection system, check using the **Diagnostic tool** :

- that the injector rail is not under pressure,
- that the fuel temperature is not too high.

It is essential to respect the safety and cleanliness advice whenever work is carried out on this system.

Working on the circuit with the engine running is strictly forbidden.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the front engine cover.



24733

- Remove the nuts (1) from the dipstick guide and neck.
- Put the engine oil dipstick guide to one side (2).



102360

- Remove the « pump-rail » high pressure pipe (3) (see **13B, Diesel injection, High pressure pipe between pump and rail: Removal - Refitting**, page 13B-19).
- Disconnect the accelerometer connector (4).

# DIESEL INJECTION

## Accelerometer: Removal - Refitting

# 13B

K9K

### II - OPERATION FOR REMOVAL OF PART CONCERNED

- Remove the accelerometer using.

### REFITTING

#### I - REFITTING OPERATION FOR PART CONCERNED

- Refit the accelerometer.
- Torque tighten the **accelerometer (20 N.m)** using the.

#### II - FINAL OPERATION

- Connect the accelerometer connector.
- Refit:
  - the « pump-rail » high pressure pipe (see **13B, Diesel injection, High pressure pipe between pump and rail: Removal - Refitting**, page **13B-19**),
  - the dipstick guide.
- Torque tighten the **dipstick guide and filler neck nuts on the high pressure rail (21 N.m)**.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Program the accelerometer if replaced (see **Fault finding - Interpretation of faults**) (13B, Diesel injection).

Note:

When replacing the accelerometer, run command **RZ004** using the **Diagnostic tool** in order to carry out the necessary programming.

- Check the high pressure circuit (see **13B, Diesel injection, High pressure pipe: Check**, page **13B-18**)  
.
- Refit the engine cover.

## Pre-postheating unit: Removal - Refitting

K9K

Tightening torques 


pre-postheating unit bolt	8 N.m
---------------------------	-------

## REMOVAL

## I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## II - REMOVAL OPERATION



24729

- Disconnect the pre-postheating unit connector (1) .
- Remove:
  - the bolt (2) from the pre-postheating unit,
  - the pre/postheating unit (3) .

## REFITTING

## I - REFITTING OPERATION

- Refit the pre-postheating unit.
- Tighten to torque the **pre-postheating unit bolt (8 N.m)**.
- Connect the pre-postheating unit connector.

## II - FINAL OPERATION

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# PREHEATING

## Heater plugs: Removal - Refitting

# 13C

K9K

### Equipment required

compressed air nozzle

hinged wrench for heater plug

### Tightening torques

heater plugs


15 N.m

## REMOVAL


### I - REMOVAL PREPARATION STAGE

- Remove the front engine cover.

### II - REMOVAL OPERATION



109466



15762

- Disconnect the connector from each heater plug.

### IMPORTANT

Wear goggles with side protectors for this operation.

- Clean around the outside of the heater plugs with a **compressed air nozzle** to prevent any impurities from entering the cylinders.

### Note:

If the heater plugs jam, use the heater plug removal tool (see ) (Technical Note 5197A, 06A, Tools).

# PREHEATING

## Heater plugs: Removal - Refitting

13C

K9K

- Unscrew the heater plugs using a **10 mm** long socket connected to a universal joint or a **hinged wrench for heater plug**.
- Use a hose to unscrew the heater plugs completely.
- Remove the heater plugs.

### REFITTING

#### I - REFITTING OPERATION

- Without tightening, fit the heater plugs using the hose.
- Torque tighten the **heater plugs (15 N.m)**.
- Connect the connector for each heater plug.


#### II - FINAL OPERATION

- Refit the engine cover.

Dacia Duster Explorers UK

## Exhaust gas recirculation: List and location of components

K9K



112326

- (1) Exhaust gas recirculation solenoid valve
- (2) Intercooler
- (3) Exhaust gas inlet pipe
- (4) Metal air inlet tube
- (5) Intercooler bracket on the flywheel end
- (6) Intercooler support on the timing end

## Fuel vapour absorber: Removal - Refitting

K4M

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

Wear goggles with side protectors for this operation.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

### WARNING

Keep the pipe unions away from contaminated areas.

### WARNING

To prevent impurities from entering the circuit, place protective plugs on all fuel circuit components exposed to the open air.

Note:

The fuel vapour absorber is located behind the front bumper, on the front right-hand side of the vehicle.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).


- Remove the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Move aside the front section of the front right-hand wheel arch liner.

### II - REMOVAL OPERATION



108415

- Disconnect:
  - the fuel vapour absorber pipes (1) ,
  - the solenoid valve connector.
- Unclip the breather pipe (2) .
- Insert the blanking plugs.



108428

- Remove:
  - the fuel vapour absorber nuts (3) ,
  - the fuel vapour absorber.

## Fuel vapour absorber: Removal - Refitting

K4M

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Remove the blanking plugs.

## II - REFITTING OPERATION

- Refit:
  - the fuel vapour absorber,
  - the fuel vapour absorber nuts.
- Clip on the breather pipe **(2)**
- Connect:
  - the solenoid valve connector,
  - the fuel vapour absorber pipes **(1)**.

## III - FINAL OPERATION

- Fit the front section of the front right-hand wheel arch liner.
- Refit the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).

K9K, and 796

### Tightening torques

exhaust gas recirculation solenoid valve bolts	<b>10 N.m</b>
--	---------------

Note:


The exhaust gas recirculation solenoid valve is fitted into the exhaust gas recirculation unit.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).

### II - REMOVAL OPERATION




114508


- Disconnect the connector (1) from the exhaust gas recirculation solenoid valve.
- Remove:
  - the bolts (2) from the exhaust gas recirculation solenoid valve,
  - the exhaust gas recirculation solenoid valve,
  - the exhaust gas recirculation solenoid valve seal.

## Exhaust gas recirculation solenoid valve: Removal - Refitting

K9K, and 796



133820



107634

□

### Note:

Use the tool to detach the exhaust gas recirculation solenoid valves jammed in their exhaust gas cooler mountings on the gearbox end.

### Remove:

- the bracket bolt (3) from the air filter unit,
- the air filter unit bracket.

Position the lugs (4) of the tool in the bracket holes of the exhaust gas recirculation solenoid valve.

Unlock the exhaust gas recirculation solenoid valve by turning it on its axis using the.

### Refit:

- the air filter unit bracket,
- the bolt on the air filter unit bracket.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: exhaust gas recirculation solenoid valve seal.
- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean:
  - the joint face of the exhaust gas recirculation solenoid valve if it is being reused,
  - the joint face of the exhaust gas cooler mounting on the gearbox end.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the joint face of the exhaust gas recirculation solenoid valve if it is being reused,
  - the joint face of the exhaust gas cooler mounting on the gearbox end.

### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

### II - REFITTING OPERATION

- Position the exhaust gas recirculation solenoid valve with a new seal.

K9K, and 796

- Torque tighten the **exhaust gas recirculation solenoid valve bolts (10 N.m)**.
- Connect the exhaust gas recirculation solenoid valve connector.

### III - FINAL OPERATION

- Refit the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) .

Dacia Duster Explorers UK

## Exhaust gas cooler: Removal - Refitting

K9K, and 796

### Tightening torques

exhaust gas cooler bolts	12 N.m
exhaust gas recirculation rigid pipe bolts	12 N.m

### IMPORTANT


Wear leaktight gloves (Nitrile type) for this operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the engine undertray bolts,
  - the engine undertray.
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10),
  - the exhaust gas recirculation rigid pipe (see **14A, Antipollution, Exhaust gas recirculation rigid pipe: Removal - Refitting**, page 14A-12),
  - the exhaust gas recirculation assembly (see **14A, Antipollution, Exhaust gas recirculation assembly: Removal - Refitting**, page 14A-9).

### II - REMOVAL OPERATION



- Remove the following on the workbench:
  - the exhaust gas cooler bolts (1) from the exhaust gas cooler mounting at the gearbox end,
  - the exhaust gas cooler from the exhaust gas cooler mounting at the gearbox end,
  - the exhaust gas cooler seal at the gearbox end.

## REFITTING

### I - REMOVAL PREPARATION OPERATION

- parts always to be replaced: exhaust gas cooler seal**

#### Note:

Take care not to damage the joint faces of the exhaust gas cooler to prevent any coolant leaks.

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean:
  - the joint faces of the exhaust gas cooler if it is to be reused,

## Exhaust gas cooler: Removal - Refitting

K9K, and 796

- the joint face of the exhaust gas cooler mounting on the gearbox end,
  - the joint face of the exhaust gas cooler mounting on the timing end.
- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
- the joint faces of the exhaust gas cooler if it is to be reused,
  - the joint face of the exhaust gas cooler mounting on the gearbox end,
  - the joint face of the exhaust gas cooler mounting on the timing end.

**II - REFITTING OPERATION**

- On the workbench, refit:
- the exhaust gas cooler fitted with a new seal on the exhaust gas cooler mounting at the gearbox end,
  - fit without tightening the exhaust gas cooler bolts on the exhaust gas cooler mounting at the gearbox end,
  - a new exhaust gas recirculation rigid pipe on the exhaust gas recirculation assembly,
  - fit without tightening the bolts of the exhaust gas recirculation rigid pipe on the exhaust gas recirculation assembly.

**Note:**

The exhaust gas cooler must be able to move in relation to the exhaust gas cooler mounting and the exhaust gas recirculation rigid pipe so that it can be adjusted correctly.

- Fit the exhaust gas recirculation assembly equipped with the exhaust gas recirculation rigid pipe on the cylinder head.
- Tighten:
- the bolts of the exhaust gas recirculation assembly on the cylinder head,
  - the bolts of the exhaust gas recirculation rigid pipe bracket on the cylinder head,
  - the bolts of the exhaust gas cooler on the exhaust gas recirculation mounting,
  - the bolts of the exhaust gas recirculation rigid pipe on the exhaust gas recirculation assembly,
- Remove:
- the exhaust gas recirculation assembly bolts,
  - the bolts of the exhaust gas recirculation rigid pipe bracket,
  - the exhaust gas recirculation assembly fitted with the exhaust gas recirculation rigid pipe.
- On the workbench, torque tighten:
- the **exhaust gas cooler bolts (12 N.m)**,
  - the **exhaust gas recirculation rigid pipe bolts (12 N.m)**.

**III - FINAL OPERATION**

- Proceed in the reverse order to removal.
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

K9K, and 796

### Special tooling required

**Ms. 583** Pipe clamps.

### Tightening torques

bolts of the exhaust gas recirculation assembly **21 N.m**


bolts on the « timing end lifting eye - air inlet metal tube assembly » **10 N.m**

### IMPORTANT

Wear cut-resistant gloves during the operation.

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air filter box (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6),
  - the engine undertray,
  - the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10).



24814

- Remove:
  - the clip (1) on the air pipe between the intercooler and the exhaust gas recirculation assembly,
  - the clip (2) on the air pipe between the intercooler and the turbocharger.
- Disconnect:
  - the air pipe between the intercooler and the exhaust gas recirculation assembly,
  - the air pipe between the intercooler and the turbocharger,
  - the oil vapour rebreathing pipe (3),
  - the non-return valve (4) at the vacuum pump,
  - the exhaust gas recirculation solenoid valve connector (5).

K9K, and 796



118974


- Position the (**Ms. 583**) or the hose clamps on the coolant inlet and outlet hoses of the exhaust gas cooler.

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.

- Remove:
  - the bolts (**6**) on the coolant circulation cover,
  - the coolant circulation cover,
  - the seals of the coolant circulation cover.

## II - REMOVAL OPERATION



145641

- Remove:
  - the bolts (**9**) from the lifting eye at the timing end,
  - the lifting eye on the timing end (**10**),
  - the air inlet metal tube (**11**),
  - the air inlet metal tube seals,
  - the exhaust gas recirculation rigid pipe (see **14A, Antipollution, Exhaust gas recirculation rigid pipe: Removal - Refitting, page 14A-12**),
  - the bolts (**12**) of the exhaust gas assembly mounting,
  - the exhaust gas recirculation assembly.
- Remove the following on the workbench:
  - the air duct sleeve (**7**),
  - the centring ring (**8**) of the air filter unit.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- On the workbench, refit:
  - the air pipe sleeve (**7**),
  - the centring ring of the air filter unit.
- Always replace:
  - the air inlet metal tube seals,
  - the coolant circulation cover seals,
  - the turbocharger air outlet pipe seal.

## Exhaust gas recirculation assembly: Removal - Refitting

K9K, and 796

- Use **GREY ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean the joint faces of the exhaust gas cooler mounting at the gearbox end.

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the housing of the coolant circulation cover seals,
  - the exhaust gas cooler mounting joint faces on the gearbox end,
  - the housing of each air inlet metal tube seal,
  - the housing of the turbocharger air outlet pipe seal,
  - the housing of the air inlet metal tube in the cylinder head,
  - the housing of the air inlet metal tube in the exhaust gas cooler mounting on the gearbox end.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

**II - REFITTING OPERATION**

- Proceed in the reverse order to removal.
- Torque tighten:
  - the **bolts of the exhaust gas recirculation assembly (21 N.m)**,
  - the **bolts on the « timing end lifting eye - air inlet metal tube assembly » (10 N.m)**.
- Fill and bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page **19A-6**).

## Exhaust gas recirculation rigid pipe: Removal - Refitting


K9K, and 796

Tightening torques 	
bolts of the exhaust gas recirculation rigid pipe bracket on the cylinder head	21 N.m
bolts of the exhaust gas recirculation rigid pipe on the exhaust manifold	36 N.m
bolts of the exhaust gas recirculation rigid pipe on the exhaust gas recirculation assembly	12 N.m
lifting eye bolts	10 N.m

### REMOVAL

#### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the engine undertray.
- Remove the catalytic converter (see **19B, Exhaust, Catalytic converter: Removal - Refitting**, page 19B-10) .



- Remove:
  - the bolts (1) from the lifting eye at the timing end,

- the timing end lifting eye (2) ,

#### II - REMOVAL OPERATION



- Remove:
  - the bolts (3) of the exhaust gas recirculation rigid pipe bracket from the cylinder head,
  - the bolts (4) of the exhaust gas recirculation rigid pipe from the exhaust manifold,
  - the bolts (5) of the exhaust gas recirculation rigid pipe from the exhaust gas recirculation rigid pipe,
  - the exhaust gas recirculation rigid pipe,
  - the seal between the exhaust gas rigid pipe and the exhaust gas manifold,
  - the seal between the exhaust gas recirculation rigid pipe and the exhaust gas cooler.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- 

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

## Exhaust gas recirculation rigid pipe: Removal - Refitting

K9K, and 796

- Clean using **ABRASIVE PADS** :
  - the joint face of the exhaust gas recirculation assembly,
  - the exhaust manifold seal face.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see ) (04B, Consumables - Products) and **CLEAN CLOTHS** to degrease:
  - the exhaust manifold joint face,
  - the joint face of the exhaust gas recirculation assembly.
- parts always to be replaced: Exhaust gas recirculation rigid pipe.**
- parts always to be replaced: Exhaust gas recirculation pipe seal.**
- parts always to be replaced: exhaust gas recirculation pipe bolt**

**II - REFITTING OPERATION**

- Proceed in the reverse order to removal.
- Torque tighten:
  - the **bolts of the exhaust gas recirculation rigid pipe bracket on the cylinder head (21 N.m)**,
  - the **bolts of the exhaust gas recirculation rigid pipe on the exhaust manifold (36 N.m)**,
  - the **bolts of the exhaust gas recirculation rigid pipe on the exhaust gas recirculation assembly (12 N.m)**,
  - the **lifting eye bolts (10 N.m)**.

# STARTING - CHARGING

## Alternator: Removal - Refitting

# 16A

K9K

### Tightening torques


alternator bolts	21 N.m
alternator lead nut	14 N.m

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .

### II - REMOVAL OPERATION




- Remove:
  - the alternator lead nut (1) ,
  - the lead from the alternator.
- Disconnect the connector (2) .



- Remove the alternator upper bolt (3) .
- Loosen the alternator lower bolt (4) .
- Remove the alternator with its lower bolt.

## REFITTING

### I - REFITTING PREPARATION OPERATION



- Push in the alternator rings (5) to facilitate fitting.

# STARTING - CHARGING

## Alternator: Removal - Refitting

# 16A

K9K

### II - REFITTING OPERATION

- Refit:
  - the alternator with its lower bolt,
  - the alternator upper bolt.
- Torque tighten the **alternator bolts (21 N.m)**.
- Connect the connector to the alternator.
- Refit the alternator lead.
- Torque tighten the **alternator lead nut (14 N.m)**.

### III - FINAL OPERATION

- Refit the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2**).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK

# STARTING - CHARGING

## Alternator: Removal - Refitting

# 16A

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING


### Tightening torques

alternator bolts	21 N.m
alternator lead nut	14 N.m



## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .



- Remove:
  - the air deflector mounting pins (1) ,
  - the air deflector.



- Remove the upper mountings (4) from the engine cooling fan assembly (see **19A, Cooling, Engine cooling fan assembly: Removal - Refitting**, page 19A-27) .
- Extract the « engine cooling fan - cooling radiator - condenser » assembly from its lower mountings (3) and slide it to the left.


# STARTING - CHARGING

## Alternator: Removal - Refitting


# 16A

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

### II - REMOVAL OPERATION




- Remove:
  - the alternator lead nut,
  - the alternator lead (4) .
- Disconnect the alternator connector (5) .



- Remove the alternator upper bolt (6) .
- Loosen the alternator lower bolt (7) .
- Move the alternator away from the multifunction support using a screwdriver.
- Remove the alternator and its lower mounting bolt.

### REFITTING

#### I - REFITTING PREPARATION OPERATION



- Push the rings (8) to make fitting easier.

#### II - REFITTING OPERATION

- Refit the alternator.
- Torque tighten the **alternator bolts (21 N.m)**.
- Connect the connector to the alternator.
- Refit:
  - the lead to the alternator,
  - the alternator lead nut.
- Torque tighten the **alternator lead nut (14 N.m)**.

#### III - FINAL OPERATION

- Slide the « engine cooling fan - cooling radiator - condenser » assembly to the right and fit it in its lower mountings.
- Refit the upper mountings of the engine cooling fan assembly (see **19A, Cooling, Engine cooling fan assembly: Removal - Refitting, page 19A-27**) .
- Refit:
  - the air deflector,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2**) ,

# STARTING - CHARGING

## Alternator: Removal - Refitting

# 16A

K4M, and POWER ASSISTED STEERING, and AIR CONDITIONING

- the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK

# STARTING - CHARGING

## Alternator: Removal - Refitting

# 16A

K4M, and STANDARD HEATING RECIRCULATION

### Tightening torques

alternator bolts	21 N.m
positive terminal nut on the alternator	14 N.m

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .

### IMPORTANT


During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.


- Disconnect the fuel supply pipe union (3) on the injector rail.



108273

- Disconnect the alternator's electrical connections (4)
- Move aside the alternator wiring.

### II - REMOVAL OPERATION




113857

- Remove the alternator upper bolt (8) .
- Loosen the alternator lower bolt (9) .
- Move the alternator away from the multifunction support using a screwdriver.
- Remove the alternator with its lower bolt upwards.

K4M, and STANDARD HEATING RECIRCULATION

**REFITTING**

**I - REFITTING PREPARATION OPERATION**



- Push the rings (**10**) to make fitting easier.

**II - REFITTING OPERATION**

- Refit the alternator.
- Torque tighten the **alternator bolts (21 N.m)**.

**III - FINAL OPERATION**

- Connect the alternator electrical connections.
- Torque tighten the **positive terminal nut on the alternator (14 N.m)**.
- Connect the fuel supply pipe union on the injector rail.
- Refit:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2**),
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# STARTING - CHARGING

## Starter: Removal - Refitting

# 16A

K9K


### Tightening torques

starter bolts	44 N.m
nut on the starter solenoid lead	5 N.m
starter lead nut	8 N.m

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).



24811

- Unclip the intercooler duct on the fan assembly at (1).
- Move aside the intercooler duct.



24809

- Unclip the engine wiring at (2).

### II - REMOVAL OPERATION

- Remove:
  - the nut (3) on the starter solenoid lead,
  - the nut (4) on the starter lead,
  - the starter leads,
  - the starter bolts (5),
  - the starter.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Check that the starter centring dowel is in place.

### II - REFITTING OPERATION

- Refit the starter.
- Torque tighten the **starter bolts (44 N.m)**.
- Refit the starter leads.
- Torque tighten:
  - the **nut on the starter solenoid lead (5 N.m)**,
  - the **starter lead nut (8 N.m)**.

# STARTING - CHARGING

## Starter: Removal - Refitting

# 16A

K9K

### III - FINAL OPERATION

- Clip:
  - the engine wiring,
  - the intercooler duct on the fan assembly.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

Dacia Duster Explorers UK

# STARTING - CHARGING

## Starter: Removal - Refitting

# 16A

K4M

### Tightening torques


starter bolts	44 N.m
starter lead nut	8 N.m
nut on the starter sole-noid lead	5 N.m

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

JR5



118882



109149

- Unclip:
  - the gear control cables on the gearbox at (3) using a screwdriver,
  - the gearbox control cable sleeve stops by pressing at (4) .


# STARTING - CHARGING

## Starter: Removal - Refitting

# 16A

K4M

### II - REMOVAL OPERATION



Remove:

- the nut (5) on the starter solenoid lead,
- the nut (6) on the starter lead,
- the starter bolts (7) ,
- the starter from underneath the vehicle.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- Check that the centring dowel is in place.

#### II - REFITTING OPERATION

Refit:

- the starter from underneath the vehicle,
- the starter bolts.

- Torque tighten the **starter bolts (44 N.m)**.

Refit:

- the starter leads,
- the starter lead nut,
- the nut on the starter solenoid lead.

Torque tighten:

- the **starter lead nut (8 N.m)**,
- the **nut on the starter solenoid lead (5 N.m)**.

### III - FINAL OPERATION

JR5

Clip:

- the gearbox control cable sleeve stops on the gearbox,
- the control cables onto the gearbox.

- Refit the air resonator (see 12A, **Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# STARTING - CHARGING

## Alternator pulley: Removal - Refitting

# 16A

K4M

### Equipment required

pneumatic or electric wrench  
torque wrench  
open-ended spanner for torque wrench


### Tightening torques

alternator pulley	80 N.m
-------------------	--------

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) .
- Disconnect the battery (see **Battery: Removal - Refitting**) .
- Remove:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting, page 11A-2**) ,
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting, page 16A-1**) .

### II - REMOVAL OPERATION FOR ALTERNATOR PULLEY



- Unclip the alternator pulley protector (if equipped).
- Place the alternator in a vice jaw.

# STARTING - CHARGING

## Alternator pulley: Removal - Refitting


# 16A

K4M


Mot. 1732



110276



117672



117671


- Position the hexagonal socket (1) or the splined socket (2) from the kit in the alternator pulley (depending on the version).

# STARTING - CHARGING


## Alternator pulley: Removal - Refitting

# 16A

K4M



117670



117673

□

Note:

Always use a pneumatic or electric impact wrench to loosen the alternator pulley

Loosen the alternator pulley using a **pneumatic or electric wrench**.

□

Remove:

- the tools,

- the alternator pulley.

### III - REFITTING PREPARATION OPERATION

□ parts always to be replaced: Accessories belt

parts always to be replaced: Accessories fixed roller

parts always to be replaced: Accessories belt tensioning roller

parts always to be replaced: Accessories tensioning roller bolt

parts always to be replaced: Alternator pulley


# STARTING - CHARGING

## Alternator pulley: Removal - Refitting


# 16A

K4M

### IV - REFITTING OPERATION FOR THE ALTERNATOR PULLEY




110266




110271

- Tighten the new alternator pulley.



110269




110274

#### □ Position:

- the hexagonal socket (3) or the splined socket (6) in the alternator pulley (depending on the version),
- the end piece (4) in the recess of the alternator rotor,
- the end piece holder (5) on the end piece.

K4M



119770

- Immobilise the alternator rotor using the spanner (7).
- Torque tighten the **alternator pulley (80 N.m)** using the **torque wrench (8)** equipped with a **15mm open-ended spanner for torque wrench**.
- Remove the tools.
- Clip the new protector onto the alternator pulley (if equipped).

#### **V - FINAL OPERATION**

- Refit:
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .
- Connect the battery (see **Battery: Removal - Refitting**) .

# STARTING - CHARGING

## Alternator pulley: Removal - Refitting

# 16A

K9K

### Tightening torques

alternator pulley nut	80 N.m
-----------------------	--------


## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) .

### II - OPERATION FOR REMOVAL OF PART CONCERNED

- Unclip the alternator pulley protector (if equipped).



- Place the alternator in a vice jaw.



- Fit:
  - the splined socket (4) of the free wheel pulley (5) ,
  - the end piece and holder assembly (6) of the alternator shaft.
- Immobilise the splined socket (4) .
- Loosen the alternator shaft.
- 

#### Note:

Do not use a screwdriver to remove or refit the pulley. A damaged or deformed front bearing can lead to damage to the alternator.

- Remove the free wheel pulley.

## REFITTING

### I - REFITTING OPERATION FOR PART CONCERNED


- Refit the pulley to the alternator shaft

# STARTING - CHARGING

## Alternator pulley: Removal - Refitting

# 16A

K9K



- Fit:
  - the splined socket (4) of the free wheel pulley (5) ,
  - the end piece and holder assembly (6) of the alternator shaft.
- Immobilise the splined socket (4) .
- Torque tighten the **alternator pulley nut (80 N.m)**.
- Turn the pulley by hand to check that the rotor turns easily.
- Clip on the alternator pulley protector (if equipped).

### II - FINAL OPERATION

- Refit:
  - the alternator (see **16A, Starting - Charging, Alternator: Removal - Refitting**, page 16A-1) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

# IGNITION

## Coils: Removal - Refitting

# 17A


K4M

### Tightening torques

ignition coil bolts	14 N.m
---------------------	--------

## REMOVAL

### REMOVAL OPERATION



116655

- Disconnect the connectors (1) from the ignition coils.
- Remove:
  - the ignition coil bolts (2) ,
  - the ignition coils.

## REFITTING

### I - REFITTING PREPARATION OPERATION


- Always replace the **ignition coil bolts**.
- If necessary, replace the ignition coil O-rings.

# IGNITION

## Coils: Removal - Refitting

# 17A

K4M



106443

106443


- When refitting the ignition harness, it is essential to apply a bead of **FLUOSTAR 2L 2 mm** in diameter around the inner edge of the high-tension caps on the side of the spark plugs and coil (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables-Products).

### II - REFITTING OPERATION

- Refit:
  - the ignition coils,
  - the new ignition coil bolts.
- Torque tighten the **ignition coil bolts (14 N.m)**.
- Connect the ignition coil connectors.


## Petrol injection: List and location of components

K4M



116656

- (1) Air pressure sensor
- (2) Idle speed stepper motor
- (3) Air temperature sensor
- (4) Throttle position potentiometer
- (5) Ignition coil
- (6) Throttle valve
- (7) Upstream oxygen sensor
- (8) Downstream oxygen sensor
- (9) Injection computer
- (10) Relay unit
- (11) Crankshaft position sensor
- (12) Coolant temperature sensor
- (13) Pinking sensor
- (14) Injectors
- (15) Injector rail
- (16) Fuel vapour recirculation solenoid valve
- (17) Petrol vapour absorber




14843

- (1) Air pressure sensor
- (2) Idle speed stepper motor
- (3) Air temperature sensor

## Petrol injection: List and location of components


K4M

- (4) Throttle position potentiometer
- (5) Ignition coil



116635

- (6) Throttle valve
- (7) Upstream oxygen sensor




108424

- (8) Downstream oxygen sensor



145183

- (9) Injection computer




116570

- (10) Relay unit


## Petrol injection: List and location of components

K4M




116648

(11) Crankshaft position sensor




101493

(14) Injectors  
(15) Injector rail



101498

(12) Coolant temperature sensor  
(13) Pinking sensor



108415

(16) Fuel vapour recirculation solenoid valve  
(17) Petrol vapour absorber

# PETROL INJECTION

## Oxygen sensors: Removal - Refitting

# 17B

K4M

### Tightening torques

upstream oxygen sensor	45 N.m
downstream oxygen sensor	45 N.m

### WARNING

Do not use any product designed to improve the electrical contact in the injection computer and oxygen sensor connectors or on the bodies of the oxygen sensors.

Failure to respect this advice causes the oxygen sensor to malfunction and results in failure to comply with the emission control standard.

### WARNING

If the connections are corroded, repair the wiring (see **Wiring: Precautions for repair**) (Technical Note 6015A, 88A, Wiring).

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

#### 1 - Upstream oxygen sensor

Remove:


- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2),
- the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6).

#### 2 - Downstream oxygen sensor

Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).

### II - REMOVAL OPERATION

#### 1 - Upstream oxygen sensor




116635

- Disconnect the upstream oxygen sensor connector (1).
- Unclip the upstream oxygen sensor wiring.
- Remove the upstream oxygen sensor (2) using the.

K4M

## 2 - Downstream oxygen sensor



- Unclip the wiring from the downstream oxygen sensor at (6) .
- Remove the downstream oxygen sensor connector (7) from its mounting by sliding it (8) .
- Disconnect the downstream oxygen sensor connector.
- Remove the downstream oxygen sensor (5) using the.

## REFITTING

### I - REFITTING OPERATION

#### 1 - Upstream oxygen sensor

- Refit the upstream oxygen sensor.
- Torque tighten the **upstream oxygen sensor (45 N.m)** using the.
- Attach the upstream oxygen sensor wiring.
- Connect the upstream oxygen sensor connector.

#### 2 - Downstream oxygen sensor

- Refit the downstream oxygen sensor.
- Torque tighten the **downstream oxygen sensor (45 N.m)** using the tool.
- Connect the downstream oxygen sensor connector.
- Refit the downstream oxygen sensor connector in its support.

- Clip on the downstream oxygen sensor wiring at (6) .

### II - FINAL OPERATION

#### Upstream oxygen sensor

- Refit:
  - the air filter unit (see 12A, **Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the air resonator (see 12A, **Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

## Throttle valve potentiometer: Removal -Refitting

K4M


### Tightening torques

throttle valve potentiometer bolts	2.4 N.m
air filter unit bolts	9 N.m

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Remove the air resonator (see 12A, **Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .



14843

- Disconnect:
  - the connector (1) from the idle speed regulation stepping motor,
  - the connector (2) from the throttle valve potentiometer,
  - the petrol vapour recirculation pipe (3) .
- Remove the two bolts (4) from the air filter unit.
- Remove the air filter unit from the throttle valve.

### II - REMOVAL OPERATION



116566

- Remove:
  - the two bolts (5) from the throttle valve potentiometer,
  - the throttle valve potentiometer (6) .

## REFITTING

### I - REFITTING OPERATION

- Refit:
  - the throttle valve potentiometer,
  - the two throttle valve potentiometer bolts.
- Torque tighten the **throttle valve potentiometer bolts (2.4 N.m)** using the tool.

### II - FINAL OPERATION

- Refit the air filter unit in place.
- Refit the two air filter unit bolts.
- Torque tighten the **air filter unit bolts (9 N.m)**.
- Connect:
  - the petrol vapour recirculation pipe,
  - the connector from the throttle valve potentiometer,
  - the idle speed regulation stepping motor connector.
- Refit the air resonator (see 12A, **Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

## Petrol injection computer: Removal - Refitting

K4M

### Equipment required

Diagnostic tool

### Tightening torques

injection computer nuts **8 N.m**

### WARNING

Do not use any product designed to improve the electrical contact in the injection computer and oxygen sensor connectors or on the bodies of the oxygen sensors.

Failure to respect this advice causes the oxygen sensor to malfunction and results in failure to comply with the emission control standard.


### WARNING

If the connections are corroded, repair the wiring (see **Wiring: Precautions for repair**) (Technical Note 6015A, 88A, Wiring).

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).



145182

- Remove the bolt (4) from the channel (5) .
- Move aside the channel.

### II - REMOVAL OPERATION



145183

- Disconnect the two injection computer connectors (9) .
- Remove:
  - the injection computer nuts (7) ,
  - the injection computer.

## Petrol injection computer: Removal - Refitting

K4M

## REFITTING

## I - REFITTING OPERATION

- Refit the injection computer.
- Torque tighten the **injection computer nuts (8 N.m)**.
- Connect the two connectors of the injection computer.

## II - FINAL OPERATION

- Refit the channel.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## III - WHEN REPLACING THE INJECTION COMPUTER

- The computer supplied as a spare part is not operational (also known as "blank").
- After replacing the injection computer, program it using the **Diagnostic tool** (see **Technical Note 9869A, Procedure for programming and reprogramming the computer**).
- Carry out the configuration and/or necessary programming (see **Fault finding - Replacement of components**) (17B, Petrol injection).

## Crankshaft position sensor: Removal - Refitting

K4M

### Equipment required

Diagnostic tool

### Tightening torques


crankshaft position sensor bolts	<b>8 N.m</b>
----------------------------------	--------------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Remove the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

### II - REMOVAL OPERATION



116648

- Disconnect the crankshaft position sensor connector **(1)** .
- Remove the two bolts **(2)** from the crankshaft position sensor.
- Move aside the engine wiring harness mounting support **(3)** .
- Remove the crankshaft position sensor.

## REFITTING

### I - REFITTING OPERATION

- Refit the crankshaft position sensor.
- Refit the engine wiring harness mounting support.
- Refit the two bolts of the crankshaft position sensor.
- Torque tighten the **crankshaft position sensor bolts (8 N.m)**.

### II - FINAL OPERATION

- Refit the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

### III - WHEN REPLACING THE CRANKSHAFT POSITION SENSOR

- Program the flywheel target:
  - perform a deceleration with injection cut-off in second, third, fourth or fifth gear between **3500** and **3000 rpm**, for at least **2 seconds**,
  - perform a deceleration with injection cut-off in second, third, fourth or fifth gear between **2400** and **2000 rpm**, for at least **3 seconds**.
- Use the **Diagnostic tool** to check that this programming has been successfully completed, **ET060 Flywheel signal with engine running**.
- Read the fault codes.
- Repair if necessary.
- Clear the fault codes.
- Check that the vehicle is working correctly.

## Injector rail - Injectors: Removal - Refitting

K4M

### Tightening torques

injector rail bolts	<b>9 N.m</b>
injector rail protector nuts	<b>21 N.m</b>

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.


### IMPORTANT

Be careful when removing the injectors or the injection rail as there will be a quantity of fuel in the rail and the union.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).



101801

- Remove:

- the two nuts (1) from the injector rail protector,
- the injector rail protector (2) .




101802

- Disconnect the fuel supply pipe union (3) on the injector rail.
- Fit blanking plugs.


## Injector rail - Injectors: Removal - Refitting

K4M

### II - REMOVAL OPERATION



- Disconnect the injector connectors (4) .
- Remove:
  - the injector rail bolts (5) ,
  - the « injector rail-injector » assembly by pulling it carefully towards the front of the vehicle.



- Remove:
  - the retaining clips (6) from the injectors,
  - the injectors (7) .
- Insert the blanking plugs.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: injector clip on injector rail.
- parts always to be replaced: injector seal.
- Refit:
  - new seals on each injector,
  - the injectors on the injector rail,
  - a new clip on each injector.

#### II - REFITTING OPERATION


- Remove the blanking plugs.
- Fit the « injector rail-injector » assembly.
- Torque tighten the **injector rail bolts (9 N.m)**.

#### III - FINAL OPERATION

- Connect:
  - the injector connectors,
  - the fuel supply union onto the injector rail,
- Refit the injector rail protector.
- Torque tighten the two **injector rail protector nuts (21 N.m)**.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## Engine cooling system: Operating diagram

K9K, and 796



133248

133248

- |      |                          |
|------|--------------------------|
| (1)  | Engine                   |
| (2)  | Cooling radiator         |
| (3)  | Heater radiator          |
| (4)  | Expansion bottle         |
| (5)  | Water pump               |
| (6)  | Thermostat               |
| (7)  | Bleed screw              |
| (8)  | Oil-water heat exchanger |
| (9)  | Temperature switch       |
| (10) | EGR                      |

## Engine cooling system: Specifications

Vehicles in the current range have cooling systems with the following basic specifications:

- hermetically-sealed pressurised circuit (expansion chamber valve),
- circuit using a type "D" coolant,
- passenger compartment heating system via a "heater matrix" type radiator under the dashboard.

### I - GRADE AND QUANTITY OF COOLANT

Engine	Quantity (litres)	Grade
K4M	Approximately 5.45 (version with AC) Approximately 4.5 (version without AC)	<b>GLACEOL RX (TYPE D)</b> Use coolant only.
K9K		

#### Special notes:

- protection down to **-25°C ± 2** for cold and temperate countries,
- protection down to **-40°C ± 2** for very cold countries

### II - THERMOSTAT

Engine	Start of opening (°C)	End of opening (°C)
K4M	89	99 ± 2
K9K		

### IMPORTANT

When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).

### Note:

There are two procedures for checking the cooling system:

- the procedure using the
- the procedure using the

### Expansion bottle cap valve rating:


Expansion bottle cap with ...	Valve rating
... a brown circle	1.2 bar
... a yellow marking	1.4 bar
... a white marking	1.6 bar
... a grey marking	1.8 bar

### I - CHECKING THE COOLING SYSTEM USING THE TOOL (MOT. 1700)

#### WARNING

If the coolant is leaking from the expansion bottle cap, replace the valve.

### 1 - Checking the expansion bottle cap valve



107138

- Use the cooling system filling and diagnostic tool. Consult the user's manual for this tool (see **Cooling system filling and diagnostic tool: Use**) (Technical Note 3857A, 19A, Cooling).

### 2 - Checking the sealing of the cooling circuit


- Use the cooling system filling and diagnostic tool. Consult the user's manual for this tool (see **Cooling system filling and diagnostic tool: Use**) (Technical Note 3857A, 19A, Cooling).

### II - CHECKING THE COOLING SYSTEM USING THE TOOL (MS. 554-07)

#### WARNING

If the coolant is leaking from the expansion bottle cap, replace the valve.

## 1 - Checking the expansion bottle cap valve



97871

- Fit onto the tester, the adapter (**Ms. 554-06**).
- Fit the expansion bottle cap to the adapter (**Ms. 554-06**).

## Note:

The pressure should not drop; if it does, look for the leak.

- Pump with the, the pressure should stabilise at the expansion bottle cap valve rating with a test tolerance of  $\pm 0.1$  bar.

## 2 - Checking the sealing of the cooling circuit

- Replace the expansion bottle cap with the adapter (**Ms. 554-01**).
- Connect on the adapter (**Ms. 554-01**) the tool.
- Pump with the to put the cooling circuit under pressure.
- Stop pumping at **0.1 bar** below the valve rating for the expansion bottle cap valve.

## Note:

The pressure should not drop; if it does, look for the leak.

- Gradually unscrew the union of the to decompress the cooling system then remove the adapter (**Ms. 554-01**) and refit the expansion bottle cap.

## Engine cooling circuit: List and location of components


K4M

### I - LIST OF COMPONENTS

The engine cooling system is composed of:


- an engine cooling fan assembly (see 19A, **Cooling, Engine cooling fan assembly: Removal - Refitting**, page 19A-27) ,
- a cooling radiator (see 19A, **Cooling, Cooling radiator: Removal - Refitting**, page 19A-9) ,
- a coolant pump (see 19A, **Cooling, Coolant pump: Removal - Refitting**, page 19A-13) ,
- a thermostat (see 19A, **Cooling, Thermostat: Removal - Refitting**, page 19A-19) ,
- a water chamber (see 19A, **Cooling, Water chamber: Removal - Refitting**, page 19A-22) ,
- a coolant pump inlet pipe (see 19A, **Cooling, Coolant pump inlet pipe: Removal - Refitting**, page 19A-34) ,
- an expansion bottle (see 19A, **Cooling, Expansion bottle: Removal - Refitting**, page 19A-38) ,
- a coolant temperature sensor (see 19A, **Cooling, Coolant temperature sensor: Removal - Refitting**, page 19A-40) .

- (14) Expansion bottle
- (15) Bleed screw
- (16) Engine



132764

### II - LOCATION OF COMPONENTS



145103

- (9) Cooling radiator
- (10) Water pump
- (11) Thermostat
- (12) Water chamber
- (13) Heater radiator

- (17) Coolant temperature sensor

## Cooling system: Draining - Refilling

Special tooling required	
<b>Mot. 1448</b>	Remote operation pliers for hose clips.
<b>Car. 1363</b>	Set of trim removal levers.
Equipment required	
coolant recovery tray	
compressed air nozzle	

### IMPORTANT

When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).

### I - DRAINING

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the expansion bottle cap,
  - the engine undertray.
- Remove the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection).
- Position the **coolant recovery tray** under the vehicle.
- Remove the cooling radiator bottom hose clip using theoror (**Mot. 1448**).
- Open the cooling system by removing the cooling radiator bottom hose using the tool (**Car. 1363**).
- Use a **compressed air nozzle** to blow air into the system through the expansion bottle opening to remove as much coolant as possible.

### II - CLEANING

- Fill the cooling system with water through the expansion bottle.
- Let the water run until the water collected from the cooling radiator bottom hose becomes clear.

- Use a **compressed air nozzle** to blow air into the system through the expansion bottle opening to remove as much coolant as possible.
- Refit the cooling radiator bottom hose.

### III - FILLING

#### Note:

There are two procedures for filling the cooling system:

- the method using the tool, is recommended by Renault. It saves a considerable amount of time because it does not require the cooling system bleed screws to be opened,
- the procedure without a special tool.

#### 1 - Filling procedure with the tool (Mot. 1700)

- Fill the cooling system with engine coolant recommended by the manufacturer (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) using the tool. Consult the user's manual for this tool (see ) (Technical Note 3857A, 19A, Cooling).


#### 2 - Filling method without special tools

#### WARNING

It is essential to open all of the bleed screws to remove as much as air as possible in the cooling system. Failure to perform this procedure may prevent the cooling system from filling properly and may damage the engine.



## Cooling system: Draining - Refilling

K4M



- Open the bleed screw (2) .

K9K



- Open the bleed screws (4) and (5) .

- Fill the cooling system with engine coolant recommended by the manufacturer (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) via the expansion bottle until it overflows.
- Close all the bleed screws as soon as the coolant starts to flow in a continuous stream.

## Cooling system: Draining - Refilling

- Pressurise the system using the tool to check that there are no leaks (see **19A, Cooling, Engine cooling system: Check**, page 19A-3) .
- Refit the expansion bottle cap.
- Clean any surfaces soiled by the coolant.

## IV - BLEEDING

**WARNING**

Do not open the bleed screw whilst the engine is running; this would damage the engine.

Start the engine.

**K4M**

- Maintain the engine speed at **2,500 rpm** until the engine cooling fan starts for the third time (time required for automatic degassing).

**K9K**

- Maintain the engine speed at **1500 rpm** varying the engine speed rapidly (until the maximum engine speed is reached) 2 to 3 times approximately every **2 minutes** until the engine cooling fan starts for the second time.

- Check that the heating is operating correctly.
- Let the engine cool until it reaches a coolant temperature below **50°C**.
- Make sure the coolant fluid level is at the « Maximum » mark.
- Refit the expansion bottle cap.

## V - FINAL OPERATION

- Remove the **coolant recovery tray**.
- Refit the engine undertray.
- Refit the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection).

## Cooling radiator: Removal - Refitting

K4M

### Special tooling required

<b>Mot. 1448</b>	Remote operation pliers for hose clips.
<b>Car. 1363</b>	Set of trim removal levers.

### IMPORTANT

When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.

### WARNING

When carrying out a repair that requires a complete change, it is essential to flush the circuit with clean water, blast compressed air through the circuit to drive out the water, fill and bleed the circuit and then measure the effective protection.

The criteria to be met are:

- protection down to **-25°C ± 2** for cold and temperate countries,
- protection down to **-40°C ± 2** for "extreme cold" countries.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine undertray,
  - the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection),

- the injector rail protector (see **13B, Diesel injection, Injector rail: Removal - Refitting**, page 13B-25) ,
- the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
- the fan assembly (see **19A, Cooling, Engine cooling fan assembly: Removal - Refitting**, page 19A-27) .

- Drain the engine cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6)

### II - REMOVAL OPERATION

#### AIR CONDITIONING




145079


- Remove:
  - the air deflector mounting pins (1) ,
  - the air deflector.
- Attach the condenser to the front impact cross member using a safety strap.

## Cooling radiator: Removal - Refitting

K4M



- Remove the condenser bolts (2) .



- Remove the cooling radiator hose clips (3) using the tool (Mot. 1448).
- Disconnect the cooling radiator hoses using the (Car. 1363).
- Remove the engine cooling radiator from above the vehicle.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Always replace the cooling radiator hose clips.

## II - REFITTING OPERATION

- Proceed in the reverse order to removal.
- Refill and bleed the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## Cooling radiator: Removal - Refitting

K9K

### Special tooling required

**Mot. 1448** Remote operation pliers for hose clips.

**Car. 1363** Set of trim removal levers.

### IMPORTANT

When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.

### WARNING

When carrying out a repair that requires a complete change, it is essential to flush the circuit with clean water, blast compressed air through the circuit to drive out the water, fill and bleed the circuit and then measure the effective protection.

The criteria to be met are:

- protection down to **-25°C ± 2** for cold and temperate countries,
- protection down to **-40°C ± 2** for "extreme cold" countries.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine undertray,
  - the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection),

- the engine cover,
- the air intake sleeve,
- the intercooler (see **12B, Turbocharging, Intercooler: Removal - Refitting**, page 12B-8),
- the fan assembly (see **19A, Cooling, Engine cooling fan assembly: Removal - Refitting**, page 19A-27).

- Drain the engine cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6).

### II - REMOVAL OPERATION

#### AIR CONDITIONING




145079


- Remove:
  - the air deflector mounting pins (1),
  - the air deflector.
- Attach the condenser to the front impact cross member using a safety strap.

## Cooling radiator: Removal - Refitting

K9K



- Remove the condenser bolts (2) .



- Remove the cooling radiator hose clips (3) using the tool (Mot. 1448).
- Disconnect the cooling radiator hoses using the (Car. 1363).
- Remove the engine cooling radiator from above the vehicle.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- Always replace the cooling radiator hose clips.

## II - REFITTING OPERATION

- Proceed in the reverse order to removal.
- Refill and bleed the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## Coolant pump: Removal - Refitting

K9K, and 796

Tightening torques 	
bolts of the coolant pump	10 N.m
inner timing cover bolts	9 N.m
alternator bolts	21 N.m

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

Wear heat protective gloves during the operation.

### IMPORTANT

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns).

Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the engine undertray bolts,

- the engine undertray.

- Remove the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Remove:
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) .




102267

- Disconnect the electrical connections from the alternator.
- Remove the alternator upper bolt (1) .
- Loosen the alternator lower bolt.
- Tilt the alternator forward.

## Coolant pump: Removal - Refitting


K9K, and 796



102266

- Remove:
  - the inner timing cover bolts (2) ,
  - the inner timing cover.

## II - REMOVAL OPERATION



102262

- Remove:
  - the coolant pump bolts (3) ,
  - the coolant pump,
  - the coolant pump seal.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- parts always to be replaced: coolant pump seal.
- Use **SURFACE CLEANER** (see ) (04B, Consumables - Products) to clean and degrease:
  - the coolant pump sealing face if it is to be reused,
  - the cylinder block gasket face.

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Apply **SUPER CLEANER FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the areas to be cleaned.
  - Leave for approximately ten minutes.
  - Remove the residue using a wooden spatula.
  - Complete the cleaning of the parts using an abrasive pad.

**WARNING**


To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease the joint faces.
- Always replace the coolant pump seal.

## Coolant pump: Removal - Refitting

K9K, and 796

## II - REFITTING OPERATION



- Refit:
  - the coolant pump fitted with a new seal,
  - the coolant pump bolts.
- Torque tighten in order (1) (2) (3) (4) (5) the bolts of the coolant pump (10 N.m).
- Apply one or two drops of FRENETANCHE (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the coolant pump bolts.

## III - FINAL OPERATION

- Refit the inner timing cover.
- Tighten to torque the inner timing cover bolts (9 N.m).
- Refit the alternator.
- Torque tighten the alternator bolts (21 N.m).
- Connect the alternator electrical connections.
- Refit:
  - the timing belt (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the accessories belt (see 11A, **Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) .
- Fill the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Refit the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).

- Refit:
  - the engine undertray,
  - the engine undertray bolts,
  - the engine cover.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Bleed the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Coolant pump: Removal - Refitting

K4M

### Tightening torques

coolant pump M8 bolt	<b>27 N.m</b>
coolant pump M6 bolts	<b>10 N.m</b>

### IMPORTANT

When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.

### WARNING

When carrying out a repair that requires a complete change, it is essential to flush the circuit with clean water, blast compressed air through the circuit to drive out the water, fill and bleed the circuit and then measure the effective protection.

The criteria to be met are:

- protection down to **-25°C ± 2** for cold and temperate countries,
- protection down to **-40°C ± 2** for "extreme cold" countries.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),

- the accessories belt (see 11A, **Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,

- the timing belt (see 11A, **Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) .

- Drain the cooling system (see 19A, **Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

### II - REMOVAL OPERATION



14505

- Remove:
  - the coolant pump bolts (1) ,
  - the coolant pump.

## Coolant pump: Removal - Refitting

K4M

## REFITTING

## I - REFITTING PREPARATION OPERATION

□

**IMPORTANT**

Wear leaktight gloves (Nitrile type) for this operation.

**IMPORTANT**

Wear goggles with side protectors for this operation.

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Use **SUPER CLEANING AGENT FOR JOINT FACES** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean:


- the coolant pump sealing face if it is to be reused,
- the cylinder block gasket face.

- Apply the product to the surfaces to be cleaned.
- Leave for approximately ten minutes.
- Remove the residue using a wooden spatula.
- Complete the cleaning of the parts using an abrasive pad.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease the joint faces.



10063

□

**WARNING**


Applying excess sealant could cause it to be squeezed out when parts are tightened. A mixture of sealant and fluid could damage certain components (engine, radiator, etc.).

- Apply at (2) a bead of **RESIN ADHESIVE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) **0.6 to 1 mm** wide.

## Coolant pump: Removal - Refitting

K4M

## II - REFITTING OPERATION



14505

- Apply one to two drops of **FRENETANCHE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the coolant pump bolts (1) and (4) .
- Refit the coolant pump.
- Fit the coolant pump bolts in order until contact is made.
- Torque tighten in order:
  - the **coolant pump M8 bolt (27 N.m)** (1) .
  - the **coolant pump M6 bolts (10 N.m)** (2) to (8) .

## III - FINAL OPERATION

- Refit:
  - the timing belt (see **11A, Top and front of engine, Timing belt: Removal - Refitting**, page 11A-17) ,
  - the accessories belt (see **11A, Top and front of engine, Accessories belt: Removal - Refitting**, page 11A-2) ,
  - the front right-hand wheel (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres).
- Fill the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Thermostat: Removal - Refitting

K9K

- The thermostat is integral with the coolant outlet unit. The coolant outlet unit must be replaced to replace it (see **19A, Cooling, Water chamber: Removal - Refitting**, page **19A-22**).

Dacia Duster Explorers UK

K4M

**Special tooling required**

**Mot. 1448** Remote operation pliers for hose clips.

**IMPORTANT**


When working in the engine compartment, take care as the radiator fan(s) may start up unexpectedly (risk of being cut).

To avoid any risk of serious burns when the engine is hot:

- do not open the expansion bottle cap,
- do not drain the cooling system,
- do not open the bleed screw(s).


**REMOVAL****I - REMOVAL PREPARATION OPERATION**

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) ,
  - the engine undertray bolts,
  - the engine undertray.
- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

**II - OPERATION FOR REMOVAL OF PART CONCERNED**

132768

- Using the **(Mot. 1448)** or remove:
  - the cooling radiator top hose clip (1) ,
  - the clip (2) from the expansion bottle hose.
- Disconnect from the thermostat cover:
  - the cooling radiator top hose,
  - the expansion bottle hose.




132768

- Remove:
  - the thermostat cover bolts (3) ,

K4M

- the thermostat cover.



Remove:

- the thermostat (4) ,
- the thermostat seal (5) .

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease the thermostat housing.
- The thermostat seal must be replaced.

### II - REFITTING OPERATION FOR PART CONCERNED

- Refit:
  - a new seal on the thermostat,
  - the thermostat,
  - the thermostat cover.
- Connect the following to the thermostat cover:
  - the expansion bottle hose,
  - the cooling radiator top hose.
- Using the **(Mot. 1448)** ororfit:
  - the expansion bottle hose clip,
  - the cooling radiator top hose clip.

### III - FINAL OPERATION

- Fill and bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Refit:
  - the engine undertray,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

## Water chamber: Removal - Refitting

K9K, and 796

### Tightening torques

water chamber bolts	11 N.m
expansion bottle nuts	8 N.m

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns). Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the engine cover,
  - the engine undertray bolts,
  - the engine undertray.
- Remove the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6).
- Remove:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6),

- the expansion bottle nuts.

- Move aside the expansion bottle.




24814

- Disconnect:

- the union (1) on the vacuum pump,

- the air duct between the intercooler and the EGR assembly at (2).



146490

- Disconnect the EGR solenoid valve pipe at (3).

- Unclip:


- the EGR solenoid valve pipes at (4),

- the gearbox breather pipe at (5).

- Move aside the air duct between the intercooler and the EGR assembly.


## Water chamber: Removal - Refitting

K9K, and 796



146342


- Disconnect the EGR assembly outlet pipe at (6) .
- Move the EGR assembly outlet pipe aside.
- Disconnect the coolant temperature sensor connector.



146340

- Disconnect the cooling hoses on the water chamber at (7) .

### II - REMOVAL OPERATION



20070

- Remove:
  - the water chamber bolts (8) ,
  - the water chamber,
  - the water chamber seal.

### REFITTING

#### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Cylinder head coolant outlet unit seal.
- Use **SURFACE CLEANER** (see ) to clean and degrease:
  - the cylinder head joint face,
  - the water chamber seal housing if it is to be reused.

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

#### WARNING

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

## Water chamber: Removal - Refitting

K9K, and 796

## II - REFITTING OPERATION

- Refit:
  - a new water chamber seal in the water chamber housing,
  - the water chamber.
- Torque tighten the **water chamber bolts (11 N.m)**.
- Connect:
  - the cooling hoses to the water chamber,
  - the coolant temperature sensor connector,
  - the EGR assembly outlet pipe,
- Position the air duct between the intercooler and the EGR assembly.
- Connect:
  - the air duct on the EGR assembly,
  - the union to the vacuum pump.
- Connect the EGR solenoid valve pipe to the vacuum pump.
- Clip on:
  - the breather pipe from the gearbox,
  - the EGR solenoid valve pipes.
- Position the expansion bottle.
- Torque tighten the **expansion bottle nuts (8 N.m)**.

## III - FINAL OPERATION

- Refit the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Refit:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the engine undertray,
  - the engine cover.
- Fill and bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Water chamber: Removal - Refitting

K4M


### Tightening torques

coolant outlet unit bolts (initial torque)	4 N.m
water chamber bolts	12 N.m

## REMOVAL

### I - OPERATION FOR REMOVAL OF PART CONCERNED


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .
- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .



116637

- Disconnect:
  - the radiator top hose (1) from the water chamber,
  - the passenger compartment heater hose (2) ,
  - the expansion bottle hose (3) ,
  - the coolant temperature sensor (4) .
- Unclip the hoses from their support at (5) .

### II - REMOVAL OPERATION



116636

- Remove:
  - the water chamber bolts (6) ,
  - the water chamber.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: Cylinder head coolant outlet unit seal

#### WARNING

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).


- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease:
  - the cylinder head joint face,
  - the water chamber joint face, if being reused.

### II - REFITTING OPERATION

- Refit the water chamber.

## Water chamber: Removal - Refitting

K4M



116636

- Screw on the water chamber bolts without tightening them.
- Torque tighten in order:
  - the **coolant outlet unit bolts (initial torque) (4 N.m)**,
  - the **water chamber bolts (12 N.m)**.

**III - FINAL OPERATION**

- Connect:
  - the coolant temperature sensor,
  - the expansion bottle hose,
  - the passenger compartment heater hose,
  - the top hose to the water chamber.
- Refit the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .
- Fill the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Engine cooling fan assembly: Removal - Refitting


K4M

## REMOVAL


## I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the injector rail protector (see **13B, Diesel injection, Injector rail: Removal - Refitting**, page 13B-25) ,
  - the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

## II - REMOVAL OPERATION



144818




144819

- Unclip:
  - the power-assisted steering hoses on the fan assembly,
  - the power-assisted steering fluid reservoir from its support at (1) ,
  - the engine coolant hose at (2) .
- Press on the clips of the centring pins (3) on the engine cooling fan assembly using a screwdriver and pull them according to the direction of the arrow (4) .
- Secure the power-assisted steering fluid reservoir to the engine.
- Remove the power assisted steering fluid reservoir bracket.

## Engine cooling fan assembly: Removal - Refitting


K4M

### STANDARD HEATING RECIRCULATION



- Disconnect the cooling fan assembly connector (5).
- Unclip the engine cooling fan assembly wiring.
- Move aside the wiring of the engine cooling fan assembly.
- Remove the engine cooling radiator bolts (6).


### AIR CONDITIONING



- Disconnect:
  - the engine cooling fan assembly connector (7),
  - the engine cooling fan assembly resistor connector (8).
- Unclip the engine cooling fan assembly wiring.
- Move aside the wiring of the engine cooling fan assembly.
- Remove the engine cooling radiator bolts (6).

## Engine cooling fan assembly: Removal - Refitting

K4M



- Unclip the « condenser - expansion valve » connecting pipe at (9) .

### WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Pull the fan assembly according to the arrows (10) passing it under the « condenser - expansion valve » connecting pipe.

### Note:

Do not damage the cooling unit vanes (radiator, condenser, etc.) during handling.

- Remove the engine cooling fan assembly from above the vehicle.

### In the event of replacement

- Remove from the fan assembly:
  - the power-assisted steering hose clips,
  - the wiring clip.

## REFITTING

### I - REFITTING PREPARATION OPERATION

#### In the event of replacement

- Refit on the fan assembly:
  - the power-assisted steering hose clips,
  - the wiring clip.

### II - REFITTING OPERATION

- Proceed in the reverse order to removal.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

### III - CHECKING THE OPERATION OF THE FAN UNIT

- Start the engine.
- Disconnect the coolant temperature sensor connector.
- Check the operation of the fan assembly.
- Connect the coolant temperature sensor connector.
- Switch off the engine.

## Engine cooling fan assembly: Removal - Refitting


K9K

## REMOVAL

## I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the air intake sleeve,
  - the front bumper (see **Front bumper assembly: Exploded view**) (55A, Exterior protection).

## STANDARD HEATING RECIRCULATION



145497

- Unclip:
  - the power-assisted steering hoses on the fan assembly,
  - the power-assisted steering fluid reservoir (1) from its support at (2) .
- Secure the power-assisted steering fluid reservoir to the engine.
- Remove the power assisted steering fluid reservoir bracket.




145786

- Disconnect the intercooler duct at (3) .


## Engine cooling fan assembly: Removal - Refitting

K9K

## II - REMOVAL OPERATION




144817



144819

- Unclip the following from the support (4) :
  - the intercooler duct on the fan assembly,
  - the engine coolant hose.
- Press on the clips of the centring pins (5) on the engine cooling fan assembly using a screwdriver and pull them according to the direction of the arrow (6) .

## STANDARD HEATING RECIRCULATION




145561

- Disconnect the cooling fan assembly connector (7) .
- Unclip the engine cooling fan assembly wiring.
- Move aside the wiring of the engine cooling fan assembly.
- Remove the engine cooling radiator bolts (8) .


## Engine cooling fan assembly: Removal - Refitting

K9K

## AIR CONDITIONING



- Disconnect:
  - the engine cooling fan assembly connector (9) ,
  - the engine cooling fan assembly resistor connector (10) .
- Unclip the engine cooling fan assembly wiring.
- Move aside the wiring of the engine cooling fan assembly.
- Remove the engine cooling radiator bolts (8) .



- Unclip the « condenser - expansion valve » connecting pipe at (11) .

**WARNING**

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Pull the fan assembly according to the arrows (12) passing it under the « condenser - expansion valve » connecting pipe.

**Note:**

Do not damage the cooling unit vanes (radiator, condenser, etc.) during handling.

- Remove the engine cooling fan assembly from above the vehicle.

**In the event of replacement**

- Remove from the fan assembly:
  - the power-assisted steering hose clips,
  - the wiring clip,
  - the support of the intercooler duct and coolant hose on the fan assembly.

**Engine cooling fan assembly: Removal - Refitting**

K9K

**REFITTING****I - REFITTING PREPARATION OPERATION****In the event of replacement**

- Refit on the fan assembly:
  - the power-assisted steering hose clips,
  - the wiring clip,
  - the support of the intercooler duct and coolant hose on the fan assembly.

**II - REFITTING OPERATION**

- Proceed in the reverse order to removal.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

**III - CHECKING THE OPERATION OF THE FAN UNIT**

- Start the engine.
- Disconnect the coolant temperature sensor connector.
- Check the operation of the fan assembly.
- Connect the coolant temperature sensor connector.
- Switch off the engine.

## Coolant pump inlet pipe: Removal - Refitting

K9K, and 796

Tightening torques 	
coolant pump inlet pipe bolt	22 N.m
accelerometer	20 N.m

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

Wear heat protective gloves during the operation.

### IMPORTANT

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns).

Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.

### WARNING

Prepare for the flow of fluid, and protect the surrounding components.


## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove:
  - the engine cover,
  - the engine undertray bolts,
  - the engine undertray.

- Remove the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Drain the engine cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6).
- Remove the oil-water heat exchanger (see **10A, Engine and cylinder block assembly, Oil-coolant heat exchanger: Removal - Refitting**, page 10A-37).

### II - REMOVAL OPERATION



113896

- Disconnect:
  - the coolant hoses (1) from the coolant pump inlet pipe,
  - the accelerometer connector.
- Remove the accelerometer using.
- Remove:
  - the water pump inlet pipe bolt (2),
  - the coolant pump inlet pipe.
  - the coolant pump inlet pipe seal.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: seal between coolant pump inlet pipe and coolant pump**

## Coolant pump inlet pipe: Removal - Refitting

K9K, and 796

- Use **SURFACE CLEANER** (see ) (04B, Consumables - Products) to clean and degrease:
  - the coolant pump inlet pipe seal housing if it is being reused,
  - the seal housing in the cylinder block.

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

**WARNING**

Do not scrape the joint faces of the aluminium, any damage caused to the joint face will result in a risk of leaks.

- Replace the removed clips.

**II - REFITTING OPERATION**

- Refit the coolant pump inlet pipe to the cylinder block.
- Torque tighten the **coolant pump inlet pipe bolt (22 N.m)**.
- Refit the accelerometer using the tool.
- Tighten to torque the **accelerometer (20 N.m)**.
- Connect:
  - the accelerometer connector,
  - the coolant hoses onto the coolant pump inlet pipe.

**III - FINAL OPERATION**

- Refit the oil-water heat exchanger (see **10A, Engine and cylinder block assembly, Oil-coolant heat exchanger: Removal - Refitting**, page 10A-37) .
- Fill the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Refit the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).
- Refit:
  - the engine undertray,
  - the engine undertray bolts,
  - the engine cover.
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Coolant pump inlet pipe: Removal - Refitting

K4M


### Tightening torques

coolant pump inlet pipe bolt	22 N.m
------------------------------	--------

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the injector rail protector.
- Drain the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6).



116559

- Disconnect:
  - the cooling radiator bottom hose (1) ,
  - the heater hose (2) .
- Unclip the wiring on the coolant pump inlet pipe at (3) .
- Disconnect the connector from cylinder injector no. 3.

### II - OPERATION FOR REMOVAL OF PART CONCERNED



14492  
14492

- Remove:
  - the bolt (4) from the coolant pump inlet pipe,
  - the coolant pump inlet pipe,
  - the coolant pump inlet pipe seal.

## REFITTING

### I - REFITTING PREPARATION OPERATION

- parts always to be replaced: seal between coolant pump inlet pipe and coolant pump**
- Always replace the cooling hose clips.

### II - REFITTING OPERATION FOR PART CONCERNED

- Refit the coolant pump inlet pipe fitted with a new seal.
- Torque tighten the **coolant pump inlet pipe bolt (22 N.m)**.

### III - FINAL OPERATION

- Connect:
  - the connector to cylinder injector no. 3.
  - the heater hose on the coolant pump inlet pipe,
  - the cooling radiator bottom hose.
- Clip the wiring onto the coolant pump inlet pipe.

## Coolant pump inlet pipe: Removal - Refitting

K4M

- Refit the injector rail protector.
- Fill the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .
- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

Dacia Duster Explorers UK

## Expansion bottle: Removal - Refitting

### Special tooling required

<b>Ms. 583</b>	Pipe clamps.
<b>Mot. 1448</b>	Remote operation pliers for hose clips.

### Tightening torques

expansion bottle nuts	<b>8 N.m</b>
-----------------------	--------------

### IMPORTANT

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns).

Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.

### WARNING

The coolant helps to keep the engine running properly (heat exchange).


The system does not operate using pure water.

### WARNING

If the coolant is leaking from the expansion bottle cap, replace the valve.

## REMOVAL

### REMOVAL OPERATION



116643

- Remove the expansion bottle nuts (1) .
- Move aside the expansion bottle.
- Position hose clamps (**Ms. 583**) on the expansion bottle hoses.
- Remove the expansion bottle cap.
- Drain the coolant from the expansion bottle.
- Remove the following using the tool (**Mot. 1448**) or « CLIC » clip pliers:
  - the clamp of the top hose of the expansion bottle,
  - the clamp of the bottom hose of the expansion bottle.
- Disconnect:
  - the expansion bottle bottom hose,
  - the expansion bottle top hose.
- Remove the expansion bottle .

## REFITTING

### I - REFITTING PREPARATION OPERATION

- Always replace the « CLIC » type clips.

### II - REFITTING OPERATION

- Connect:
  - the expansion bottle top hose,

**Expansion bottle: Removal - Refitting**

- the expansion bottle bottom hose.
- Refit the following using the tool (**Mot. 1448**) or « CLIC » clip pliers:
  - the clamp of the top hose of the expansion bottle,
  - the clamp of the bottom hose of the expansion bottle.
- Fill the expansion bottle with coolant.
- Remove the hose clamps (**Ms. 583**).
- Refit the expansion bottle.
- Torque tighten the **expansion bottle nuts (8 N.m)**.

**III - FINAL OPERATION**

- Top up the coolant level in the expansion bottle.
- Refit the expansion bottle cap.
- Bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

## Coolant temperature sensor: Removal - Refitting

K9K

### Tightening torques

expansion bottle nuts	8 N.m
-----------------------	-------

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns).

Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.


### WARNING

Prepare for the flow of fluid, and protect the surrounding components.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) .
- Remove:
  - the engine cover,
  - the engine undertray bolts,
  - the engine undertray,
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page 12A-6) ,
  - the expansion bottle nuts.
- Move aside the expansion bottle.




24814

### Disconnect:

- the union (1) on the vacuum pump,
- the air duct between the intercooler and the EGR assembly at (2) .

K9K, and 796



146490

### Disconnect the EGR solenoid valve pipe at (3) .

### Unclip:


- the EGR solenoid valve pipes at (4) ,
- the gearbox breather pipe at (5) .

- Move aside the air duct between the intercooler and the EGR assembly.


## Coolant temperature sensor: Removal - Refitting

K9K

## II - REMOVAL OPERATION



120474



135076

- Disconnect the coolant temperature sensor connector (6) .
- Remove:
  - the coolant temperature sensor retaining clip (7) ,
  - the coolant temperature sensor,
  - the coolant temperature sensor O-ring.

## REFITTING

## I - REFITTING PREPARATION OPERATION

- parts always to be replaced: coolant temperature sensor seal.
- Use **SURFACE CLEANER** (see ) to clean and degrease:
  - the mating face of the coolant temperature sensor if it is to be reused,
  - the coolant outlet unit.

## II - REFITTING OPERATION

- Refit:
  - a new coolant temperature sensor seal on the coolant temperature sensor,
  - the coolant temperature sensor,
  - the coolant temperature sensor clip.
- Connect the coolant temperature sensor connector.

## III - FINAL OPERATION

- Position the air duct between the intercooler and the EGR assembly.
- Connect:
  - the air duct on the EGR assembly,
  - the union to the vacuum pump.

K9K, and 796

- Connect the EGR solenoid valve pipe to the vacuum pump.
- Clip on:
  - the breather pipe from the gearbox,
  - the EGR solenoid valve pipes.
- Position the expansion bottle.
- Torque tighten the **expansion bottle nuts (8 N.m)**.
- Refit:
  - the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page **12A-6**) ,
  - the engine undertray,
  - the engine undertray bolts,
  - the engine cover.

## Coolant temperature sensor: Removal - Refitting

K9K

- Perform the following operations:
  - top up the cooling system,
  - bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

Dacia Duster Explorers UK

## Coolant temperature sensor: Removal - Refitting

K4M

Tightening torques 

coolant temperature sensor	30 N.m
----------------------------	--------

**IMPORTANT**

The circuits are designed to be pressurised, so be careful at high temperatures (risk of serious burns).

Do not remove the cap from the expansion bottle while the engine is hot.

Take care when carrying out a repair under the bonnet, as the radiator fan(s) may start to operate without warning.

Do not open the bleed screw(s) with the engine running.

**WARNING**

Before the operation, protect the electrical accessories to prevent any risk of short circuiting and protect the belts to avoid damaging them.


**WARNING**

The coolant helps to keep the engine running properly (heat exchange).

The system does not operate using pure water.

**REMOVAL****I - REMOVAL PREPARATION OPERATION**

- Remove the air resonator (see 12A, **Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .

**II - OPERATION FOR REMOVAL OF PART CONCERNED**

132764

- Disconnect the coolant temperature sensor connector (3) .
- Remove the coolant temperature sensor.

**REFITTING****I - REFITTING PREPARATION OPERATION**

- 

## Note:

Apply 1 to 2 drops of **FRENETANCHE** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to the coolant temperature sensor thread (only if the sensor is to be reused).

- Use **SURFACE CLEANER** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean and degrease the mating face of the coolant temperature sensor on the water chamber.

**II - REFITTING OPERATION FOR PART CONCERNED**

- Refit the coolant temperature sensor.
- Torque tighten the **coolant temperature sensor (30 N.m)**.
- Connect the coolant temperature sensor connector.

**Coolant temperature sensor: Removal - Refitting**

K4M

**III - FINAL OPERATION**

- Refit the air resonator (see **12A, Fuel mixture, Air resonator: Removal - Refitting**, page 12A-2) .
- Perform the following operations:
  - top up the coolant level,
  - bleed the cooling system (see **19A, Cooling, Cooling system: Draining - Refilling**, page 19A-6) .

Dacia Duster Explorers UK

Dacia Duster Explorers UK


# EXHAUST

## Exhaust: List and location of components

# 19B

K4M

Dacia Duster Explorers UK



144509


144569

# EXHAUST

**19B**

## Exhaust: List and location of components

---

- |     |                              |
|-----|------------------------------|
| (A) | Area to be cut A             |
| (B) | Area to be cut B             |
| (1) | Exhaust system sealing ring  |
| (2) | Catalytic converter          |
| (3) | Downstream oxygen sensor     |
| (4) | Expansion chamber            |
| (5) | Expansion chamber rubber pad |
| (6) | Silencer                     |
| (7) | Silencer rubber pad          |
- 

Dacia Duster Explorers UK


# EXHAUST

## Exhaust: List and location of components

# 19B

K9K

Dacia Duster Explorers UK




144609

# EXHAUST

**19B**

## Exhaust: List and location of components

---

- |     |                              |
|-----|------------------------------|
| (A) | Area to be cut A             |
| (B) | Area to be cut B             |
| (1) | Exhaust system sealing ring  |
| (2) | Intermediate pipe            |
| (3) | Intermediate pipe rubber pad |
| (4) | Silencer                     |
| (5) | Silencer rubber pad          |
- 

Dacia Duster Explorers UK

## Exhaust: Precautions for the repair

### Special tooling required

<b>Mot. 1199-01</b>	Exhaust pipe cutter (diameter 35/50 mm and diameter 50/65mm). Complete kit in a case.
---------------------	---

### Equipment required

component jack

## I - PARTS AND CONSUMABLES FOR THE REPAIR

### 1 - Parts always to be replaced:

- the exhaust sleeve (if fitted)
- the seal or sealing ring on the connection between the catalytic converter or catalytic pre-converter and the rest of the exhaust system
- the exhaust clip(s) (if fitted)

### 2 - Consumables (see Part number in Technical Note 5068, 04B, Consumables - Products):

- exhaust mastic
- surface cleaner
- grey abrasive pads

## II - ADVICE TO OBSERVE

### IMPORTANT

Do not park and run the engine in a place where combustible substances and materials such as grass or leaves can come into contact with the hot exhaust system.

### IMPORTANT

Catalytic converters contain ceramic fibres, these are contained within a closed unit, and cannot disperse. Drilling or cutting catalytic converters is prohibited.

1 - During removal and refitting, the catalytic converter or catalytic pre-converter must not receive any knocks or impacts as this could damage it.

2 - The whole exhaust pipe is made of stainless steel.

3 - After working on the bracket between the catalytic converter or catalytic pre-converter and the rest of the exhaust system, ensure that the connection is perfectly sealed.

To do this:

- clean the bearing faces of the connection using **GREY ABRASIVE PADS**,
- degrease the bearing faces of the connection using **SURFACE CLEANER** and clean cloths,
- always replace the seal or sealing ring on the connection.

## III - SPECIAL NOTES ON THE SINGLE UNIT EXHAUST PIPE

### 1 - Cutting the single unit exhaust pipe

The exhaust pipe is a « single unit type » .

To replace different parts of the exhaust system it must be cut.


To do this be sure to carry out these precautions in the following order:

- correctly identify the area to be cut, as explained below,
- use the cutting tool correctly (**Mot. 1199-01**),
- position the exhaust sleeve correctly.

### 2 - Identifying the area of the exhaust system to be cut


Two marks made on the exhaust system define the area to be cut (see **Exhaust: Parts and consumables for the repair**) (see MR for vehicle concerned, 19B, Exhaust).

### Example of cutting area



99226

## Exhaust: Precautions for the repair




100649

Before cutting the exhaust system, draw a line (D) between the two marks (P1) and (P2).


The distance between the two marks on the exhaust pipe is (X1) : 80 mm.

### 3 - Operate tool Mot. 1199-01



14747

14747



102118

Fit the (Mot. 1199-01) (1) on the exhaust pipe.

Tighten the two bolts on the tool until they touch the pipe in order to clamp the tool onto the pipe.

Turn the cutting tool using the handle and pressing it against the pipe (as indicated in the diagram above).

Tighten the two bolts on the tool whilst cutting, until the pipe is completely cut.

#### Note:

Do not over-tighten the tool onto the pipe to avoid deforming it.

Once the pipe is cut, file and deburr the end of the pipe to be used on the vehicle again.


### 4 - Positioning the exhaust sleeve

#### WARNING

Do not reuse an old exhaust sleeve.


## Exhaust: Precautions for the repair

### Exhaust sleeve with 1 bolt



95478

### Exhaust sleeve with 2 bolts



119681

Fit the exhaust sleeve onto the part of the exhaust system fitted to the vehicle.

Position the pipe onto the lugs (2) inside the exhaust sleeve.


Tighten the exhaust sleeve bolt(s) slightly (depending on the version).

Position the second part of the exhaust system under the vehicle, fitting it in the exhaust sleeve.

#### Note:

If necessary, use a **component jack** to lift and hold the heavy and bulky components of the exhaust system.

Position the second exhaust pipe onto the lugs inside the exhaust sleeve.



99227

Check that the two cut marks (3) are aligned (if applicable).

Position the sleeve so that there is no risk of contact between its bolt or bolts and the heat shields.

Torque tighten:

- the **exhaust sleeve nut with 1 bolt (25 N.m)** (if fitted),
- the **exhaust sleeve nuts with 2 bolts (18 N.m)** (if fitted).

Check the following and deal with if necessary:

- no underbody contact between the exhaust system and the heat shields,
- all of the heat shields are present and secure.

#### Note:

Any damaged heat shields must be replaced.

Start the engine.

Check that there are no leaks: deal with any leaks.

## Exhaust: Precautions for the repair

---

Note:

If there are leaks from the **EXHAUST SLEEVES WITH 1 BOLT**, apply **EXHAUST MASTIC** to the sleeve (see part no. in Technical Note 5068, 04B, Consumables - Products).

If the application of exhaust mastic does not fix the leak:

- remove and replace the used exhaust sleeve,
- check the condition of the exhaust pipes (condition of the pipe surface, deburring of the area cut, damage to the pipes).
- fit the new sleeve in accordance with the instructions given before.

Dacia Duster Explorers UK

## Catalytic converter: Removal - Refitting

K9K, and 796

Tightening torques 	
turbocharger output studs	9 N.m
catalytic converter nuts on the turbocharger	28 N.m
upstream strut bolts on the engine	44 N.m
downstream strut bolt and nut on the gearbox	21 N.m
upstream strut bolts on the catalytic converter	26 N.m
downstream strut bolt on the catalytic converter	21 N.m
exhaust flange bolts	21 N.m

**IMPORTANT**

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

**IMPORTANT**

Wear cut-resistant gloves during the operation.

**IMPORTANT**

Catalytic converters contain ceramic fibres, these are contained within a closed unit, and cannot disperse. Drilling or cutting catalytic converters is prohibited.


**WARNING**

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

**REMOVAL****I - REMOVAL PREPARATION OPERATION**


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Remove the air filter unit (see **12A, Fuel mixture, Air filter unit: Removal - Refitting**, page **12A-6**).

**II - REMOVAL OPERATION**

- Remove the exhaust flange bolts (1).
- Withdraw the exhaust pipe.
- Attach the exhaust pipe to the front left-hand lower arm.


## Catalytic converter: Removal - Refitting

K9K, and 796




144536

- Remove the bolt from the downstream strut on the catalytic converter (2) .
- Loosen the downstream strut bolt and nut on the gearbox (3) .
- Remove the downstream strut.



144537


- Remove:
  - the bolts of the upstream strut (4) ,
  - the upstream strut.



145311

145311

- Remove the catalytic converter nuts on the turbocharger (5) .



144820

144820

- Remove:
  - the catalytic converter (6) ,
  - the seal between the turbocharger and the catalytic converter,
  - the exhaust flange sealing ring.

## Catalytic converter: Removal - Refitting

K9K, and 796

## REFITTING

## I - REFITTING PREPARATION OPERATION

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- Use **ABRASIVE PADS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to clean the joint face of:

- the intermediate pipe,
- the catalytic converter in case of reuse,
- the turbocharger.

- Use **SURFACE CLEANER** and **CLEAN CLOTHS** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products) to degrease the joint face of:

- the intermediate pipe,
- the catalytic converter in case of reuse,
- the turbocharger.



109399

- Always replace the exhaust flange sealing ring.
- parts always to be replaced: seal between turbocharger and catalytic converter**

## II - REFITTING OPERATION

## Note:

If a stud loosens during this operation, coat it with **HIGH STRENGTH THREAD LOCK** (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

Torque tighten the **turbocharger output studs (9 N.m)**.

- Fit:

- a new seal between the turbocharger and the catalytic converter,
- the catalytic converter on the turbocharger.

- Pretighten in order:

- the bolt and nut of the upstream strut on the engine,
- the downstream strut bolt and nut on the gearbox,
- the upstream strut bolts on the catalytic converter,
- the downstream strut bolt on the catalytic converter,
- the catalytic converter nuts on the turbocharger.

- Torque tighten in order:

- the **catalytic converter nuts on the turbocharger (28 N.m)**,
- the **upstream strut bolts on the engine (44 N.m)**,
- the **downstream strut bolt and nut on the gearbox (21 N.m)**,
- the **upstream strut bolts on the catalytic converter (26 N.m)**,
- the **downstream strut bolt on the catalytic converter (21 N.m)**.

- Make sure there is no contact between the catalytic converter and the turbocharger oil return pipe.

- Proceed in the reverse order to removal.

- Torque tighten the **exhaust flange bolts (21 N.m)**.

## III - FINAL OPERATION

- Check:

- that all the exhaust pipe heat shields are in place and properly attached,
- that there is no contact with the underbody.

- Start the vehicle.

K9K, and 796

- Check that there are no leaks and deal with them if necessary.

Dacia Duster Explorers UK

## Catalytic converter: Removal - Refitting

K4M, and 4X2 TRANSMISSION

## Special tooling required

**Mot. 1199-01** Exhaust pipe cutter (diameter 35/50 mm and diameter 50/65mm). Complete kit in a case.

## Equipment required

component jack

Tightening torques 

bolt of the exhaust flange	21 N.m
oxygen sensor	45 N.m

## IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

## IMPORTANT

Wear cut-resistant gloves during the operation.

## IMPORTANT

Catalytic converters contain ceramic fibres, these are contained within a closed unit, and cannot disperse. Drilling or cutting catalytic converters is prohibited.

## WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.


## REMOVAL

## I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## II - REMOVAL OPERATION




108424

- Remove the downstream oxygen sensor connector from its mounting by sliding it (1).
- Disconnect the downstream oxygen sensor connector.
- Put a **component jack** under the catalytic converter.
- Locate the area of the catalytic converter to be cut (see **19B, Exhaust, Exhaust: List and location of components**, page **19B-1**).
- Use the tool (**Mot. 1199-01**) to cut the exhaust pipe in the area to be cut (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

## Catalytic converter: Removal - Refitting

K4M, and 4X2 TRANSMISSION



135949

 Remove:

- the exhaust flange bolts (2) ,
- the catalytic converter,
- the exhaust flange ring.

## IF REPLACING THE CATALYTIC CONVERTER

- 
- Remove the downstream oxygen sensor on the catalytic converter (see ).

## REFITTING

## I - REFITTING PREPARATION OPERATION

**WARNING**

To ensure proper sealing, the gasket surfaces must be clean, dry and not greasy (avoid any finger marks).

- 
- Clean the bearing faces of the catalytic converter using
- ABRASIVE PADS**
- (see
- Vehicle: Parts and consumables for the repair**
- ) (04B, Consumables - Products).

- 
- Degrease the bearing faces of the catalytic converter using
- SURFACE CLEANER**
- and clean cloths (see
- Vehicle: Parts and consumables for the repair**
- ) (04B, Consumables - Products).



109399

- 
- parts always to be replaced: ring between exhaust manifold and catalytic converter

## II - REFITTING OPERATION

 Refit:

- the downstream oxygen sensor (if replacing the catalytic converter),
- the catalytic converter.

- 
- Fit a new After-Sales sleeve between the catalytic converter and the expansion chamber (see
- 19B, Exhaust, Exhaust: Precautions for the repair**
- , page
- 19B-6**
- ) .

**IMPORTANT**

Position the « nut and bolt securing the sleeve » assembly so that the assembly cannot come into contact with the underbody.

- 
- Tighten the sleeve bolt while guiding the exhaust pipe to ensure correct alignment.

 Torque tighten:

- the **bolt of the exhaust flange (21 N.m)**,
- the **oxygen sensor (45 N.m)**.

## III - FINAL OPERATION

- 
- Connect the battery (see
- Battery: Removal - Refitting**
- ) (80A, Battery).

 Check:

- that all the exhaust pipe heat shields are in place and properly attached,
- that there is no contact with the underbody.

- 
- Start the vehicle.

## Catalytic converter: Removal - Refitting

K4M, and 4X2 TRANSMISSION

- Check that there are no leaks and deal with them if necessary.

Dacia Duster Explorers UK

## Expansion chamber: Removal - Refitting

K4M, and 4X2 TRANSMISSION

## Special tooling required

<b>Mot. 1199-01</b>	Exhaust pipe cutter (diameter 35/50 mm and diameter 50/65mm). Complete kit in a case.
<b>Mot. 1857</b>	Pliers for removing exhaust pipe rubber mounting bushes

## Equipment required

component jack

## IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**) .

## WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

## IMPORTANT

Wear heat protective gloves during the operation.

## REMOVAL

## I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Place a **component jack** under the expansion chamber.

## II - REMOVAL OPERATION

- Locate the areas of the expansion chamber to be cut (see **19B, Exhaust, Exhaust: List and location of components**, page **19B-1**) .
- Cut the exhaust pipe using the tool (**Mot. 1199-01**) in the designated areas to be cut (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**)

- Remove the rubber pad from the expansion chamber using the tool (**Mot. 1857**).

## Note:

If the rubber pad is damaged, replace the rubber pad.

- Remove the expansion chamber.

## REFITTING

## I - REFITTING OPERATION

- Refit:
  - the expansion chamber,
  - the expansion chamber rubber pad.
- Fit new after-sales sleeves (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**) .

## IMPORTANT

Position the « nut and bolt securing the sleeve » assembly so that the assembly cannot come into contact with the underbody.

- Torque tighten the sleeve bolts while supporting the exhaust pipe to ensure alignment.

## II - FINAL OPERATION

- Check:
  - all the exhaust pipe heat shields are in place and properly attached.
  - that there is no contact with the underbody,
- Start the vehicle.
- Check that there are no leaks and deal with them if necessary.

## Intermediate pipe: Removal - Refitting

K9K

## Special tooling required

<b>Mot. 1199-01</b>	Exhaust pipe cutter (diameter 35/50 mm and diameter 50/65mm). Complete kit in a case.
<b>Mot. 1857</b>	Pliers for removing exhaust pipe rubber mounting bushes

## Equipment required

component jack

Tightening torques exhaust sleeve bolts **25 N.m**

## IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**)

## WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

## IMPORTANT


Wear heat protective gloves during the operation.

## REMOVAL


## I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Fit a **component jack** under the intermediate pipe.

## II - REMOVAL OPERATION



146344



146343

- Cut the exhaust pipe using the tool (**Mot. 1199-01**) in the centre of the areas to be cut (**4**) (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).
- Remove the rubber mounting bush (**5**) from the intermediate pipe using the tool (**Mot. 1857**).

## Note:

If the rubber mounting bush is damaged, it must always be replaced.

- Remove the intermediate pipe.

## Intermediate pipe: Removal - Refitting

K9K

## REFITTING

## I - REFITTING OPERATION

- Refit the intermediate pipe.
- Refit the exhaust sleeves (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

**WARNING**

Make sure:

- that the sleeve nut-bolt tightening assembly is vertical, with the nut facing downwards, to prevent any risk of underbody contact,
- that you position the new component in a way that the cutting area marks are aligned,
- that the two marks are flush with the two ends of the sleeve,
- that an old sleeve is not reused.

- Torque tighten the **exhaust sleeve bolts (25 N.m)**.
- Refit the rubber mounting bush of the intermediate pipe.

## II - FINAL OPERATION

- Check:
  - that all the exhaust pipe heat shields are in place and properly attached,
  - that there is no contact with the underbody.

# EXHAUST

## Silencer: Removal - Refitting

# 19B

4X2 TRANSMISSION

### Special tooling required

**Mot. 1199-01** Exhaust pipe cutter (diameter 35/50 mm and diameter 50/65mm). Complete kit in a case.

**Mot. 1857** Pliers for removing exhaust pipe rubber mounting bushes

### Equipment required

component jack

### IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

### WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

### IMPORTANT

Wear heat protective gloves during the operation.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Place a **component jack** under the silencer.

### II - REMOVAL OPERATION

- Locate the area of the silencer to be cut (see **19B, Exhaust, Exhaust: List and location of components**, page **19B-1**).
- Use the tool (**Mot. 1199-01**) to cut the exhaust pipe in the area to be cut (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

- Remove the rubber pad from the silencer using the tool (**Mot. 1857**).

#### Note:

If the rubber pad is damaged, replace the rubber pad.

- Remove the silencer.

## REFITTING

### I - REFITTING OPERATION

- Refit:
  - the silencer,
  - the silencer rubber pad.
- Fit a new After-Sales exhaust sleeve (see **19B, Exhaust, Exhaust: Precautions for the repair**, page **19B-6**).

### IMPORTANT

Position the « nut and bolt securing the sleeve » assembly so that the assembly cannot come into contact with the underbody.

- Tighten the sleeve while relieving the exhaust to ensure alignment.

### II - FINAL OPERATION

- Check:
  - that all the exhaust pipe heat shields are in place and properly attached,
  - that there is no contact with the underbody.
- Start the vehicle.
- Check that there are no leaks and deal with them if necessary.

# TANK

## Fuel tank: Draining

# 19C

### Special tooling required

**Mot. 1311-08** Union for taking fuel pressure measurements.

### Equipment required

pneumatic transfer pump for fuels

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

### IMPORTANT

Wear leaktight gloves (Nitrile type) for this operation.

### IMPORTANT

Wear goggles with side protectors for this operation.

### WARNING

To prevent impurities from entering the circuit, place protective plugs on all fuel circuit components exposed to the open air.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

## DRAINING


### I - DRAINING PREPARATION OPERATION

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

### II - DRAINING OPERATION

K4M

- Disconnect the fuel supply union from the injector rail (1).



145570

- Fit a T-union (**Mot. 1311-08**) at (2).
- Connect a **pneumatic transfer pump for fuels** to the T-union outlet (3).


K9K

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).

# TANK

## Fuel tank: Draining

# 19C




144823

### Remove:

- the front right-hand wheel arch liner bolts (4),
- the clip of the wheel arch liner (5),
- the diesel filter protector (see ).

### Disconnect the fuel outlet pipe from the fuel filter.



144827

### Connect a **pneumatic transfer pump for fuels** to the fuel filter.

### Prepare for fuel outflow.

### Drain the fuel tank.

### REFITTING

### Proceed in the reverse order to removal.

# TANK

## Fuel tank: Removal - Refitting

# 19C

4X2 TRANSMISSION

Tightening torques 	
fuel tank bolts	21 N.m
exhaust pipe bolts on the catalytic converter	21 N.m
catalytic converter bolts on the exhaust manifold	21 N.m
earth cable nut on the body	8 N.m

This method describes the removal - refitting procedure for the plastic tank

### IMPORTANT

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

### IMPORTANT

Wear goggles with side protectors for this operation.

### IMPORTANT

Wear leaktight gloves (nitrile type) for this operation.

### WARNING

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.


### WARNING

To prevent impurities from entering the circuit, place protective plugs on all fuel circuit components exposed to the open air.

## REMOVAL

### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Drain the tank (see **19C, Tank, Fuel tank: Draining**, page **19C-1**).
- Tilt the rear bench seat base (see ) (76A, Rear seat frames and runners).



- Remove the access flap to the fuel level sensor module on the floor.
- Disconnect the connector (1) from the fuel pump.


# TANK

## Fuel tank: Removal - Refitting

# 19C


4X2 TRANSMISSION

K4M




- Remove the body earth cable at (2) .

K4M



- Remove the oxygen sensor connector by sliding it from its support (in the direction of the arrow).
- Disconnect the oxygen sensor connector.



- Remove:
  - the heat shield pins (4) ,
  - the fuel tank heat shield.


# TANK

## Fuel tank: Removal - Refitting

# 19C


4X2 TRANSMISSION

K4M



- Remove the catalytic converter mountings (6) on the exhaust manifold.
- Detach the exhaust line assembly on the left-hand side.
- Attach the front section of the exhaust line assembly to the front lower arm on the left-hand side.


K9K




- Remove the exhaust pipe mountings (8) from the catalytic converter.
- Place the exhaust line assembly on the left-hand side.
- Attach the front section of the exhaust line assembly to the front lower arm on the left-hand side.
- Unclip the parking brake cables from:
  - the fuel tank,
  - on the body.

4X2 TRANSMISSION


## II - OPERATION FOR REMOVAL OF PART CONCERNED



- Remove the bolts (9) from the filler neck.



- Disconnect the snap-on unions (10) from the tank outlet pipes.
- Remove the external fuel filter (if fitted to the vehicle) (see **Fuel filter: Removal - Refitting**).




Note:

This operation requires two people.

- Remove the bolts (11) from the fuel tank.
- Lower the tank slightly.
- Remove the fuel tank.

## REFITTING

## I - REFITTING PREPARATION OPERATION



- It is essential to replace the sealing ring between the exhaust manifold and the catalytic converter.

## II - REFITTING OPERATION FOR PART CONCERNED

Note:

This operation requires two people.

## Fuel tank: Removal - Refitting

## 4X2 TRANSMISSION

- Refit the fuel tank.
- Refit the fuel tank bolts.
- Torque tighten the **fuel tank bolts (21 N.m)**.
- Refit the external fuel filter (if fitted to the vehicle) (see **Fuel filter: Removal - Refitting**) .
- Reconnect the snap-on unions to the tank outlet fuel pipes.
- Refit the filler neck bolts.

## III - FINAL OPERATION

- Clip the parking brake cables:
  - onto the body,
  - onto the fuel tank.

## K9K

- Refit the exhaust system assembly onto the catalytic converter.
- Torque tighten the **exhaust pipe bolts on the catalytic converter (21 N.m)**.

## K4M

- Refit the exhaust system assembly onto the exhaust manifold.
- Torque tighten the **catalytic converter bolts on the exhaust manifold (21 N.m)**.
- Connect the oxygen sensor connector.
- Refit:
  - the oxygen sensor connector to its support,
  - the earth cable on the body.
- Torque tighten the **earth cable nut on the body (8 N.m)**.
- Refit:
  - the fuel tank heat shield,
  - the heat shield pins.
- Reconnect the fuel level sensor module connector.
- Refit the access flap for the fuel level sensor module on the floor.
- Refit the rear bench seat base (see ) (76A, Rear seat frames and runners).

- Connect the battery (see **Battery: Removal - Refitting**) (80A, Battery).

## Fuel level sensor module: Removal - Refitting

K4M or K9K

## Special tooling required

<b>Car. 1363</b>	Set of trim removal levers.
<b>Mot. 1397</b>	Universal spanner for removing fuel gauge nuts.

**IMPORTANT**

During this operation, be sure to:

- refrain from smoking or bringing red hot objects close to the working area,
- be careful of fuel splashes when disconnecting the union.

**IMPORTANT**

Wear goggles with side protectors for this operation.

**IMPORTANT**

Wear leaktight gloves (Nitrile type) for this operation.

**WARNING**

To avoid any corrosion or damage, protect the areas on which fuel is likely to run.

**REMOVAL****I - REMOVAL PREPARATION OPERATION**

- Disconnect the battery (see **Battery: Removal - Refitting**) (80A, Battery).
- Tilt the rear bench seat base.


**II - REMOVAL OPERATION**

- Remove the blanking cover from the inspection flap using the tool (**Car. 1363**).

## Note:

Make provisions for the flow of fuel from the fuel supply and return pipes.

K9K



144821

144821


 Disconnect:

- the connector (1) ,
- the unions (2) .


## Fuel level sensor module: Removal - Refitting

K4M or K9K

K4M



- Disconnect:
  - the connector (3) ,
  - union (4) .



- Remove the nut from the fuel level sensor module using the tool (**Mot. 1397**) (5) ,
- Let the fuel drain from the fuel level sensor module.
- Remove:
  - the fuel level sensor module, taking care not to damage the float,
  - the fuel level sensor module seal.

**WARNING**

To prevent the tank from deforming, refit the fuel sender unit nut to the tank well immediately.

**REFITTING****I - REFITTING PREPARATION OPERATION**



- parts always to be replaced: Fuel level sensor module nut
- parts always to be replaced: Fuel level sensor module seal

## Fuel level sensor module: Removal - Refitting

K4M or K9K

## II - REFITTING OPERATION

K4M


 Position:

- the new seal (6) in the neck correctly,
- the fuel level sensor module on the fuel tank. A lug on the fuel level sensor module and a recess in the fuel tank ensure correct positioning in the fuel tank;

the mark (8) on the fuel level sensor module must be positioned opposite the mark on the fuel tank (10).


- Press the fuel level sensor module by hand (to prevent the seal from moving) and finger tighten the nut on the fuel tank.
- Then use the tool (**Mot. 1397**) to tighten the nut of the fuel level sensor module to the mark on the fuel tank.

K4M

- Tighten the nut (7) until the mark (9) on the nut is located opposite the mark (10) on the fuel tank using the tool (**Mot. 1397**).

- Proceed in the reverse order to removal.

K9K



103236

No.	Description	Tightening torque (N.m)
(1)	Right-hand suspended mounting support bolt on the body	62
(3)	Right-hand suspended mounting support bolt on the engine	62
(5)	Left-hand mounting bolt on the gearbox	62
(6)	Left-hand rubber pad mounting bolt on the body	21
(7)	Left-hand rubber pad bolt on the mounting	105
(8)	Stud on the gearbox mounting	180
(9)	Gearbox mounting nut on the rubber pad	62

No.	Description	Tightening torque (N.m)
(4)	Engine tie-bar bolt	180


Special tooling required	
<b>Mot. 1453</b>	Engine anchorage support with multiple adjustments and retaining straps.

Tightening torques 	
bolts mounting the left-hand suspended mounting on the gearbox	<b>62 N.m</b>
bolt of the power-assisted steering pipe on the left-hand suspended mounting	<b>21 N.m</b>
stud on the gearbox support	<b>180 N.m</b>
left-hand rubber pad mounting bolts on the body	<b>21 N.m</b>
rubber pad nuts on the left-hand suspended mounting	<b>105 N.m</b>
nut of the gearbox support on the rubber pad	<b>62 N.m</b>

## REMOVAL

### I - REMOVAL PREPARATION OPERATION


- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove:
  - the air inlet sleeve,
  - the battery (see **Battery: Removal - Refitting**) (80A, Battery),
  - the battery tray,
  - the injection computer (see **17B, Petrol injection, Petrol injection computer: Removal - Refitting**, page **17B-7**),
  - the engine undertray.



107930

- Fit the engine support tool (**Mot. 1453**) with the retaining belt, taking the flywheel end lifting eye as an anchoring point.
- Mark the position of the left-hand suspended engine mounting on the body.

### II - REMOVAL OPERATION



102112

- Remove the nut (1) from the gearbox support on the rubber pad.
- Strike the gearbox stud with a copper hammer to separate the engine and gearbox assembly from the body.
- Remove:
  - the nuts (2) from the rubber pad,
  - the rubber pad,

## Left-hand suspended engine mounting: Removal - Refitting

- the bolts (3) from the left-hand rubber pad mounting on the body,
- the left-hand rubber pad mounting,
- the power-assisted steering pipe bolt on the suspended mounting (if fitted to the vehicle),
- the left-hand suspended mounting bolts (4) on the gearbox,
- the left-hand suspended mounting on the gearbox.

- the battery tray,
- the battery (see **Battery: Removal - Refitting**) (80A, Battery),
- the air intake sleeve.

**REFITTING****I - REFITTING PREPARATION OPERATION**

- Always replace the self-locking nuts.

**II - REFITTING OPERATION**

- Refit:

- the left-hand suspended mounting on the gearbox,
- the power-assisted steering pipe bolt on the suspended mounting (if fitted to the vehicle),
- the left-hand rubber pad mounting,
- the rubber pad,
- the rubber pad nuts on the left-hand suspended mounting,
- the gearbox support nut on the rubber pad.

- Torque tighten:

- the **bolts mounting the left-hand suspended mounting on the gearbox (62 N.m)**,
- the **bolt of the power-assisted steering pipe on the left-hand suspended mounting (21 N.m)**,
- the **stud on the gearbox support (180 N.m)**,
- the **left-hand rubber pad mounting bolts on the body (21 N.m)**,
- the **rubber pad nuts on the left-hand suspended mounting (105 N.m)**,
- the **nut of the gearbox support on the rubber pad (62 N.m)**.

**III - FINAL OPERATION**

- Remove the engine support tool (**Mot. 1453**).

- Refit:

- the engine undertray,
- the injection computer (see **17B, Petrol injection, Petrol injection computer: Removal - Refitting, page 17B-7**),

K9K

### Special tooling required

**Mot. 1453** Engine anchorage support with multiple adjustments and retaining straps.

### Tightening torques


right-hand suspended engine mounting bolts on the engine	<b>62 N.m</b>
--	---------------

right-hand suspended engine mounting bolts on the body	<b>62 N.m</b>
--	---------------

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Remove the front engine cover.



24764

- Fit the engine support tool (**Mot. 1453**) with the retaining belt, taking the timing end lifting eye as an anchoring point.




146339

- Disconnect the fuel pipe at (1) ,
- Insert the blanking plugs.
- Unclip the fuel pipes at (2) ,
- Move the fuel pipes aside.

K9K

### II - REMOVAL OPERATION




145429

- Mark the position of the right-hand suspended engine mounting on the body.
- Remove:
  - the bolts (6) from the right-hand suspended engine mounting on the engine,
  - the right-hand suspended engine mounting bolts (7) on the body,
  - the right-hand suspended engine mounting.

### REFITTING

#### I - REFITTING OPERATION



145429

- Refit:
  - the right-hand suspended engine mounting observing the marks made on the body during removal,
  - the right-hand suspended engine mounting bolts on the engine,
  - the right-hand suspended engine mounting bolts on the body.
- Torque tighten in order the **right-hand suspended engine mounting bolts on the engine (62 N.m)**.
- Torque tighten the **right-hand suspended engine mounting bolts on the body (62 N.m)**.

#### II - FINAL OPERATION

- Position the fuel pipes.
- Clip on the fuel pipes at (2) .
- Remove the blanking plugs.
- Connect the fuel pipe at (1) .
- Remove the engine support tool (**Mot. 1453**) and the retaining strap.
- Refit the engine cover.

K4M

### Special tooling required

**Mot. 1453** Engine anchorage support with multiple adjustments and retaining straps.

### Tightening torques


right-hand suspended engine mounting bolts on the engine	<b>62 N.m</b>
--	---------------

right-hand suspended engine mounting bolts on the body	<b>62 N.m</b>
--	---------------

## REMOVAL


### I - REMOVAL PREPARATION OPERATION

- Remove the front engine cover.



- Fit the engine support tool (**Mot. 1453**) with the retaining belt, taking the timing end lifting eye as an anchoring point.

### II - REMOVAL OPERATION



- Detach at (2) :
  - the fuel supply pipe,
  - the petrol vapour recirculation pipe.
- Mark the position of the right-hand suspended engine mounting on the body.
- Remove:
  - the bolts (3) from the right-hand suspended engine mounting on the engine,
  - the right-hand suspended engine mounting bolts (4) on the body,
  - the right-hand suspended engine mounting.

## REFITTING

### I - REFITTING OPERATION

- Refit:
  - the right-hand suspended engine mounting observing the marks made on the body during removal,
  - the right-hand suspended engine mounting bolts on the engine,
  - the right-hand suspended engine mounting bolts on the body.
- Torque tighten:
  - the **right-hand suspended engine mounting bolts on the engine (62 N.m)**,
  - the **right-hand suspended engine mounting bolts on the body (62 N.m)**.
- Clip:
  - the fuel supply pipe,
  - the petrol vapour recirculation pipe.

# ENGINE MOUNTING

## Right-hand suspended engine mounting: Removal - Refitting

**19D**

K4M

### II - FINAL OPERATION

- Remove the engine support tool (**Mot. 1453**).
- Refit the engine cover.

Dacia Duster Explorers UK

# ENGINE MOUNTING

## Lower engine tie-bar: Removal - Refitting

# 19D

Tightening torques 	
rear suspended engine mounting bolt on the subframe	105 N.m
rear suspended engine mounting bolts on the gearbox	105 N.m


### REMOVAL

#### I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see **Vehicle: Towing and lifting**) (02A, Lifting equipment).
- Remove the engine undertray.

#### II - REMOVAL OPERATION

JR5



- Remove:
  - the rear suspended engine mounting bolt (1) from the subframe,
  - the rear suspended engine bolts (2) from the gearbox,
  - the rear suspended engine mounting.

### REFITTING

#### I - REFITTING OPERATION

- Refit:
  - the rear suspended engine mounting,
  - the rear suspended engine mounting bolts.
- Torque tighten:
  - the rear suspended engine mounting bolt on the subframe (105 N.m),
  - the rear suspended engine mounting bolts on the gearbox (105 N.m).

#### II - FINAL OPERATION

- Refit the engine undertray.
- Tighten the engine undertray bolts.